




Manual Number: MCVIEA01  
Edition (ECN): 2021482A

# Installation, Parts, and Service

## COELV00A





## Contents

1	General Service Information.....	3
	Limited Standard Warranty .....	4
	1.1 How to Get the Necessary Repair Components .....	5
	1.2 Trademarks .....	5
	1.3 Safety — Shuttle Conveyors .....	6
	1.3.1 Safety Alert Messages—Internal Electrical and Mechanical Hazards.....	6
	1.3.2 Safety Alert Messages—External Mechanical Hazards.....	6
	1.3.3 Safety Alert Messages—Unsafe Conditions .....	7
	1.3.3.1 Damage and Malfunction Hazards .....	7
	1.3.3.1.1 Hazards Resulting from Inoperative Safety Devices.....	7
	1.3.3.1.2 Hazards Resulting from Damaged Mechanical Devices .....	8
	1.3.3.2 Careless Use Hazards .....	8
	1.3.3.2.1 Careless Operation Hazards—Vital Information for Operator Personnel (see also operator hazards throughout manual) .....	8
	1.3.3.2.2 Careless Servicing Hazards—Vital Information for Service Personnel (see also service hazards throughout manuals).....	9
	1.4 Torque Requirements for Fasteners .....	9
	1.4.1 Torque Values .....	10
	1.4.1.1 Fasteners Made of Carbon Steel .....	10
	1.4.1.1.1 Without a Threadlocker .....	10
	1.4.1.1.2 With a Threadlocker .....	12
	1.4.1.2 Stainless Steel Fasteners .....	14
	1.4.2 Preparation.....	14
	1.4.3 How to Apply a Threadlocker .....	15
	1.4.3.1 Blind Holes.....	15
	1.4.3.2 Through Holes .....	16
2	Safety-Related Components and Assemblies.....	17
	Safety Placard Use and Placement COELV00A.....	18
	Safety Placard Use and Placement — ISO COELV00A .....	19
	Safety Pin All Elevating Shuttles and Pivoting Elevators. ....	20
3	Mechanical Components .....	21
	Stand & Air Cylinder COELV00A .....	22
	Lifting Frame COELV00A .....	24
	Lift Frame Balancing Assembly COELV00A .....	26
	Air Cylinder Lubricator & Shuttle Valve COELV00A.....	28
	Horizontal Beds 42”Wx62”L and 44”Wx65”L COELV00A111/112, COSHM1LP, COLF- J111A, COSHM111A, COLFM111A.....	30
4	Dimensional Drawings .....	32
	BDCOELV00AAE .....	33

## Figures

Figure 1	The Bolts in Milnor® Equipment.....	10
Figure 2	Apply Threadlocker in a Blind Hole.....	15
Figure 3	Apply Threadlocker in a Through Hole.....	16
Figure 4	Use heat for disassembly of fasteners with threadlocker.....	16

## Tables

Table 1	Trademarks .....	5
Table 2	Torque Values for Standard Fasteners with Maximum 5/16-inch Diameters and No Lubricant .....	10
Table 3	Torque Values for Standard Fasteners Larger Than 5/16-inch Diameters and No Lubricant .....	10
Table 4	Torque Values for Plated Fasteners with Maximum 5/16-inch Diameters and No Lubricant .....	11
Table 5	Torque Values for Plated Fasteners Larger Than 5/16-inch Diameters and No Lubricant .....	11
Table 6	Threadlocker by the Diameter of the Bolt (see below Note ) .....	12
Table 7	Torque Values if You Apply LocTite 222 .....	12
Table 8	Torque Values if You Apply LocTite 242 .....	12
Table 9	Torque Values if You Apply LocTite 262 .....	13
Table 10	Torque Values if You Apply LocTite 272 (High-Temperature) .....	13
Table 11	Torque Values if You Apply LocTite 277 .....	13
Table 12	Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller .....	14
Table 13	Torque Values for Stainless Steel Fasteners Larger Than 5/16-inch .....	14
Table 14	Parts List—Safety Placard Use and Placement COELV00A.....	18
Table 15	Parts List—Safety Placard Use and Placement ISO COELV00A .....	19
Table 16	Parts List—Safety Pin All Elevating Shuttles and Pivoting Elevators. ....	20
Table 17	Parts List—Stand & Air Cylinder COELV00A .....	23
Table 18	Parts List— COELV00A.....	24
Table 19	Parts List— COELV00A.....	26
Table 20	Parts List—Air Cylinder Lubricator & Shuttle Valve COELV00A .....	28
Table 21	Parts List—Horizontal Beds 42x62 and 44x65 COELV00A111/112, COSHM1LP, COLFJ111A, COSHM111A, COLFM111A .....	31

# 1 General Service Information

## **PELLERIN MILNOR CORPORATION LIMITED STANDARD WARRANTY**

We warrant to the original purchaser that MILNOR machines including electronic hardware/software (hereafter referred to as "equipment"), will be free from defects in material and workmanship for a period of one year from the date of shipment (unless the time period is specifically extended for certain parts pursuant to a specific MILNOR published extended warranty) from our factory with no operating hour limitation. This warranty is contingent upon the equipment being installed, operated and serviced as specified in the operating manual supplied with the equipment, and operated under normal conditions by competent operators.

Providing we receive written notification of a warranted defect within 30 days of its discovery, we will—at our option—repair or replace the defective part or parts, EX Factory (labor and freight specifically NOT included). We retain the right to require inspection of the parts claimed defective in our factory prior to repairing or replacing same. We will not be responsible, or in any way liable, for unauthorized repairs or service to our equipment, and this warranty shall be void if the equipment is tampered with, modified, or abused, used for purposes not intended in the design and construction of the machine, or is repaired or altered in any way without MILNOR's written consent.

Parts damaged by exposure to weather, to aggressive water, or to chemical attack are not covered by this warranty. For parts which require routine replacement due to normal wear—such as gaskets, contact points, brake and clutch linings, belts, hoses, and similar parts—the warranty time period is 90 days.

We reserve the right to make changes in the design and/or construction of our equipment (including purchased components) without obligation to change any equipment previously supplied.

ANY SALE OR FURNISHING OF ANY EQUIPMENT BY MILNOR IS MADE ONLY UPON THE EXPRESS UNDERSTANDING THAT MILNOR MAKES NO EXPRESSED OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE OR ANY OTHER WARRANTY IMPLIED BY LAW INCLUDING BUT NOT LIMITED TO REDHIBITION. MILNOR WILL NOT BE RESPONSIBLE FOR ANY COSTS OR DAMAGES ACTUALLY INCURRED OR REQUIRED AS A RESULT OF: THE FAILURE OF ANY OTHER PERSON OR ENTITY TO PERFORM ITS RESPONSIBILITIES, FIRE OR OTHER HAZARD, ACCIDENT, IMPROPER STORAGE, MIS-USE, NEGLIGENCE, POWER OR ENVIRONMENTAL CONTROL MALFUNCTIONS, DAMAGE FROM LIQUIDS, OR ANY OTHER CAUSE BEYOND THE NORMAL RANGE OF USE. REGARDLESS OF HOW CAUSED, IN NO EVENT SHALL MILNOR BE LIABLE FOR SPECIAL, INDIRECT, PUNITIVE, LIQUIDATED, OR CONSEQUENTIAL COSTS OR DAMAGES, OR ANY COSTS OR DAMAGES WHATSOEVER WHICH EXCEED THE PRICE PAID TO MILNOR FOR THE EQUIPMENT IT SELLS OR FURNISHES.

THE PROVISIONS ON THIS PAGE REPRESENT THE ONLY WARRANTY FROM MILNOR AND NO OTHER WARRANTY OR CONDITIONS, STATUTORY OR OTHERWISE, SHALL BE IMPLIED.

WE NEITHER ASSUME, NOR AUTHORIZE ANY EMPLOYEE OR OTHER PERSON TO ASSUME FOR US, ANY OTHER RESPONSIBILITY AND/OR LIABILITY IN CONNECTION WITH THE SALE OR FURNISHING OF OUR EQUIPMENT TO ANY BUYER.

BMP720097/19036

**BNUUUM01 / 2019342**

BNUUUM01 0000250121 B.3 1/2/20 2:14 PM Released

## 1.1 How to Get the Necessary Repair Components

BNUUUM01.C01 0000250120 B.2 B.3 A.3 1/2/20 2:14 PM Released

You can get components to repair your machine from the approved supplier where you got this machine. Your supplier will usually have the necessary components in stock. You can also get components from the Milnor® factory.

Tell the supplier the machine model and serial number and this data for each necessary component:

- The component number from this manual
- The component name if known
- The necessary quantity
- The necessary transportation requirements
- If the component is an electrical component, give the schematic number if known.
- If the component is a motor or an electrical control, give the nameplate data from the used component.

To write to the Milnor® factory:

Pellerin Milnor Corporation  
 Post Office Box 400  
 Kenner, LA 70063-0400  
 UNITED STATES

Telephone: 504-712-7775

Fax: 504-469-9777

Email: parts@milnor.com

**BNUUUU02 / 2021104A**

BNUUUU02 0000158094 F.2 3/3/21 9:47 AM Released

## 1.2 Trademarks

BNUUUU02.R01 0000158093 B.2 F.2 E.2 3/3/21 9:47 AM Released

These words are trademarks of Pellerin Milnor® Corporation and other entities:

**Table 1. Trademarks**

AutoSpot™	GreenFlex™	MilMetrix®	PulseFlow®
CBW®	GearTrace™	MilTouch™	RAM Command™
Drynet™	GreenTurn™	MilTouch-EX™	RecircONE®
E-P Express®	Hydro-cushion™	MILRAIL™	RinSave®
E-P OneTouch®	Mentor®	Miltrac™	SmoothCoil™
E-P Plus®	Mildata®	PBW™	Staph Guard®
Gear Guardian®	Milnor®		

## 1.3 Safety — Shuttle Conveyors

BNSUUS06.C01 0000275641 B.2 A.2 2/12/20 4:13 PM Released

### 1.3.1 Safety Alert Messages—Internal Electrical and Mechanical Hazards

BNSUUS01.C03 0000240137 B.2 A.3 1/2/20 2:04 PM Released

The following are instructions about hazards inside the machine and in electrical enclosures.



**WARNING: Electrocutation and Electrical Burn Hazards** — Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.



- ▶ Do not unlock or open electric box doors.
- ▶ Do not remove guards, covers, or panels.
- ▶ Do not reach into the machine housing or frame.
- ▶ Keep yourself and others off of machine.
- ▶ Know the location of the main machine disconnect and use it in an emergency to remove all electric power from the machine.



**WARNING: Entangle and Crush Hazards** — Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.



- ▶ Do not remove guards, covers, or panels.
- ▶ Do not reach into the machine housing or frame.
- ▶ Keep yourself and others off of machine.
- ▶ Know the location of all emergency stop switches, pull cords, and/or kick plates and use them in an emergency to stop machine motion.

### 1.3.2 Safety Alert Messages—External Mechanical Hazards

BNSUUS02.C03 0000240134 B.2 A.3 1/2/20 2:04 PM Released

The following are instructions about hazards around the front, sides, rear or top of the machine.



**CAUTION: Strike and Crush Hazards** — A traveling machine such as a shuttle can strike, crush, or entrap you if you ride on it or enter its path. Traveling machines or their components can move automatically in any direction. Placing a system machine on line by energizing the machine control may immediately summon a shuttle or other traveling machine.



- ▶ Keep yourself and others off of machine.
- ▶ Keep yourself and others clear of movement areas and paths.
- ▶ Understand the consequences of placing a system machine on line.
- ▶ Know the location of all emergency stop switches, pull cords, and/or kick plates and use them in an emergency to stop machine motion.



- ▶ Know the location of the main machine disconnect and use it in an emergency to remove all electric power from the machine.



**CAUTION: Crush and Entrap Hazards** — A traveling machine such as a shuttle can crush or entrap you if the bed or bucket descends while you are under it. The bed or bucket can descend with power off or on.



- ▶ Keep yourself and others clear of movement areas and paths.



**WARNING: Fall, Entangle, and Strike Hazards** — Machine motion can cause you to fall or become entangled in or struck by nearby objects if you stand, walk, or ride on the machine. Shuttles and conveyor belts move automatically.



- ▶ Keep yourself and others off of machine.

### 1.3.3 Safety Alert Messages—Unsafe Conditions

BNSUUS03.C01 0000240133 B.2 A.3 1/2/20 2:04 PM Released

#### 1.3.3.1 Damage and Malfunction Hazards

BNSUUS03.C02 0000240132 B.2 A.2 1/2/20 2:04 PM Released

##### 1.3.3.1.1 Hazards Resulting from Inoperative Safety Devices

BNSUUS03.C03 0000240131 B.2 A.4 1/2/20 2:04 PM Released



**WARNING: Multiple Hazards** — Operating the machine with an inoperative safety device can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.

- ▶ Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.



**WARNING: Electrocution and Electrical Burn Hazards** — Electric box doors—Operating the machine with any electric box door unlocked can expose high voltage conductors inside the box.



- ▶ Do not unlock or open electric box doors.



**WARNING: Entangle and Crush Hazards** — Guards, covers, and panels—Operating the machine with any guard, cover, or panel removed exposes moving components.



- ▶ Do not remove guards, covers, or panels.

### 1.3.3.1.2 Hazards Resulting from Damaged Mechanical Devices

BNSUUS03.C04 0000240130 B.2 A.3 1/2/20 2:04 PM Released



**WARNING: Multiple Hazards** — Operating a damaged machine can kill or injure personnel, further damage or destroy the machine, damage property, and/or void the warranty.

- ▶ Do not operate a damaged or malfunctioning machine. Request authorized service.



**WARNING: Crush Hazards** — Chain and hoist—A broken chain or a malfunctioning hoist can permit the belt/bucket assembly to fall or descend.

- ▶ Do not operate the machine with any evidence of damage or malfunction.

### 1.3.3.2 Careless Use Hazards

BNSUUS03.C05 0000240156 B.2 A.2 1/2/20 2:04 PM Released

#### 1.3.3.2.1 Careless Operation Hazards—Vital Information for Operator Personnel (see also operator hazards throughout manual)

BNSUUS03.C06 0000240155 B.2 A.2 1/2/20 2:04 PM Released



**WARNING: Multiple Hazards** — Careless operator actions can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.

- ▶ Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.
- ▶ Do not operate a damaged or malfunctioning machine. Request authorized service.
- ▶ Do not attempt unauthorized servicing, repairs, or modification.
- ▶ Do not use the machine in any manner contrary to the factory instructions.
- ▶ Use the machine only for its customary and intended purpose.
- ▶ Understand the consequences of operating manually.



**CAUTION: Goods Damage and Wasted Resources** — Entering incorrect cake data causes improper processing, routing, and accounting of batches.

- ▶ Understand the consequences of entering cake data.



**WARNING: Strike and Crush Hazards** — Carelessly moving the machine with manual controls can cause it to strike, crush, entrap, or entangle personnel. You have total control of machine movement immediately after setting the Manual/Automatic switch to manual.



- ▶ Keep yourself and others clear of movement areas and paths.
- ▶ Understand the consequences of operating manually.

**1.3.3.2.2 Careless Servicing Hazards—Vital Information for Service Personnel (see also service hazards throughout manuals)**

BNSUUS03.C07 0000240154 B.2 A.3 1/2/20 2:04 PM Released



**WARNING: Electrocution and Electrical Burn Hazards** — Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.



- ▶ Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.
- ▶ Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.



**WARNING: Entangle and Crush Hazards** — Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.



- ▶ Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.
- ▶ Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.



**WARNING: Crush and Entrap Hazards** — A traveling machine such as a shuttle can crush or entrap you if the bed or bucket descends while you are under it. The bed or bucket can descend with power off or on.



- ▶ Secure both red safety pins in accordance with the instructions furnished, then lock out and tag out power at the main machine disconnect before working under bed or bucket.



**WARNING: Strike and Crush Hazards** — A traveling machine such as a shuttle can strike, crush, or entrap you if you ride on it or enter its path. Traveling machines or their components can move automatically in any direction. Placing a system machine on line by energizing the machine control may immediately summon a shuttle or other traveling machine.



- ▶ Lock out and tag out power to the traveling machine at the main machine disconnect if you must work in the path of the traveling machine.

BNUUUN02 / 2019125

BNUUUN02 0000222452 B.3 1/2/20 2:14 PM Released

**1.4 Torque Requirements for Fasteners**

BNUUUN02.C01 0000222451 B.2 B.3 A.3 1/2/20 2:14 PM Released

The document about the assembly gives the torque requirements for other fasteners. **If fastener torque specifications or threadlocker requirements in an assembly document are different from this document, use the assembly document.**

**Figure 1. The Bolts in Milnor® Equipment**

The Marks on Bolt Heads	Legend
	<p><b>A</b> . . . SAE Grades 1 and 2, ASTM A307, and stainless steel</p> <p><b>B</b> . . . Grade BC, ASTM A354</p> <p><b>C</b> . . . SAE Grade 5, ASTM A449</p> <p><b>D</b> . . . SAE Grade 8 and ASTM A354 BD</p>

### 1.4.1 Torque Values

BNUUUN02.C02 0000222449 B.2 B.3 A.3 1/2/20 2:14 PM Released

These tables give the standard dimension, grade, threadlocker, and torque requirements for fasteners frequently used on Milnor® equipment.



**NOTE:** Data from the Pellerin Milnor® Corporation “Bolt Torque Specification” (bolt\_torque\_milnor.xls/2002096).

#### 1.4.1.1 Fasteners Made of Carbon Steel

BNUUUN02.C03 0000222448 B.2 B.3 A.3 1/2/20 2:14 PM Released

##### 1.4.1.1.1 Without a Threadlocker

BNUUUN02.C04 0000222447 B.2 B.3 A.3 1/2/20 2:14 PM Released

**Table 2. Torque Values for Standard Fasteners with Maximum 5/16-inch Diameters and No Lubricant**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	66	7	101	11	143	16	126	14
1/4 x 28	76	9	116	13	163	18	–	–
5/16 x 18	136	15	209	24	295	33	258	29
5/16 x 24	150	17	232	26	325	37	–	–

**Table 3. Torque Values for Standard Fasteners Larger Than 5/16-inch Diameters and No Lubricant**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
3/8 x 16	20	27	31	42	44	59	38	52
3/8 x 24	23	31	35	47	50	68	–	–
7/16 x 14	32	43	49	66	70	95	61	83
7/16 x 20	36	49	55	75	78	105	–	–
1/2 x 13	49	66	75	102	107	145	93	126
1/2 x 20	55	75	85	115	120	163	–	–
9/16 x 12	70	95	109	148	154	209	134	182
9/16 x 18	78	106	121	164	171	232	–	–
5/8 x 11	97	131	150	203	212	287	186	252
5/8 x 18	110	149	170	231	240	325	–	–
3/4 x 10	172	233	266	361	376	510	329	446

**Table 3 Torque Values for Standard Fasteners Larger Than 5/16-inch Diameters and No Lubricant (cont'd.)**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
3/14 x 16	192	261	297	403	420	569	–	–
7/8 x 9	167	226	429	582	606	821	531	719
7/8 x 14	184	249	473	641	668	906	–	–
1 x 8	250	339	644	873	909	1232	796	1079
1 x 12	274	371	704	954	994	1348	–	–
1 x 14	281	381	723	980	1020	1383	–	–
1 1/8 x 7	354	480	794	1077	1287	1745	1126	1527
1 1/8 x 12	397	538	891	1208	1444	1958	–	–
1 1/4 x 7	500	678	1120	1519	1817	2464	1590	2155
1 1/4 x 12	553	750	1241	1682	2012	2728	–	–
1 3/8 x 6	655	888	1469	1992	2382	3230	2085	2827
1 3/8 x 12	746	1011	1672	2267	2712	3677	–	–
1 1/2 x 6	869	1178	1949	2642	3161	4286	2767	3751
1 1/2 x 12	979	1327	2194	2974	3557	4822	–	–

**Table 4. Torque Values for Plated Fasteners with Maximum 5/16-inch Diameters and No Lubricant**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	49	6	76	9	107	12	95	11
1/4 x 28	56	6	88	10	122	14	–	–
5/16 x 18	102	12	156	18	222	25	193	22
5/16 x 24	113	13	174	20	245	28	–	–

**Table 5. Torque Values for Plated Fasteners Larger Than 5/16-inch Diameters and No Lubricant**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
3/8 x 16	15	20	23	31	33	44	29	38
3/8 x 24	17	23	26	35	37	49	–	–
7/16 x 14	24	32	37	50	52	71	46	61
7/16 x 20	27	36	41	55	58	78	–	–
1/2 x 13	37	49	56	76	80	106	70	93
1/2 x 20	41	55	64	85	90	120	–	–
9/16 x 12	53	70	81	110	115	153	101	134
9/16 x 18	59	79	91	122	128	174	–	–
5/8 x 11	73	97	113	150	159	212	139	186
5/8 x 18	83	110	127	172	180	240	–	–
3/4 x 10	129	173	200	266	282	376	246	329
3/14 x 16	144	192	223	297	315	420	–	–
7/8 x 9	125	166	322	430	455	606	398	531
7/8 x 14	138	184	355	474	501	668	–	–
1 x 8	188	250	483	644	682	909	597	796
1 x 12	205	274	528	716	746	995	–	–
1 x 14	210	280	542	735	765	1037	–	–
1 1/8 x 7	266	354	595	807	966	1288	845	1126
1 1/8 x 12	298	404	668	890	1083	1444	–	–
1 1/4 x 7	375	500	840	1120	1363	1817	1192	1590

**Table 5 Torque Values for Plated Fasteners Larger Than 5/16-inch Diameters and No Lubricant (cont'd.)**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
1 1/4 x 12	415	553	930	1261	1509	2013	–	–
1 3/8 x 6	491	655	1102	1470	1787	2382	1564	2085
1 3/8 x 12	559	758	1254	1672	2034	2712	–	–
1 1/2 x 6	652	870	1462	1982	2371	3161	2075	2767
1 1/2 x 12	733	994	1645	2194	2668	3557	–	–

**1.4.1.1.2 With a Threadlocker**

BNUUUN02.C05 0000222446 B.2 B.3 A.3 1/2/20 2:14 PM Released

**Table 6. Threadlocker by the Diameter of the Bolt (see below Note )**

LocTite Product	Dimension			
	1/4-inch	1/4- to 5/8-inch	5/8- to 7/8-inch	1-inch +
LocTite 222	OK			
LocTite 242		OK		
LocTite 262			OK	
LocTite 272			High temperature	
LocTite 277				OK



**NOTE:** The acceptable bolt size ranges for various LocTite® threadlocking products is the LocTite manufacturer’s **general** recommendation. Specific applications sometime require that a LocTite product is applied to a bolt size outside the ranges shown here. For example, Milnor® specifies LocTite 242 for use on certain 1" bolt applications and has confirmed this usage with the LocTite manufacturer. You may see variances such as this in the documentation for specific machine assemblies.

**Table 7. Torque Values if You Apply LocTite 222**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	60	7	96	11	132	15	108	12
1/4 x 28	72	8	108	12	144	16	–	–

**Table 8. Torque Values if You Apply LocTite 242**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
5/16 x 18	11	15	17	23	25	34	22	30
5/16 x 24	13	18	19	26	27	37	27	37
3/8 x 16	20	27	31	42	44	60	38	52
3/8 x 24	23	31	35	47	50	68	–	–
7/16 x 14	32	43	49	66	70	95	61	83
7/16 x 20	36	49	55	75	78	106	–	–
1/2 x 13	49	66	75	102	107	145	93	126
1/2 x 20	55	75	85	115	120	163	–	–
9/16 x 12	70	95	109	148	154	209	134	182
9/16 x 18	78	106	121	164	171	232	–	–

**Table 8 Torque Values if You Apply LocTite 242 (cont'd.)**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
5/8 x 11	97	132	150	203	212	287	186	252
5/8 x 18	110	149	170	230	240	325	–	–

**Table 9. Torque Values if You Apply LocTite 262**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
3/4 x 10	155	210	240	325	338	458	296	401
3/4 x 16	173	235	267	362	378	512	–	–
7/8 x 9	150	203	386	523	546	740	477	647
7/8 x 14	165	224	426	578	601	815	–	–

**Table 10. Torque Values if You Apply LocTite 272 (High-Temperature)**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
1 x 8	350	475	901	1222	1272	1725	1114	1510
1 x 12	383	519	986	1337	1392	1887	–	–
1 x 14	393	533	1012	1372	1428	1936	–	–
1-1/8 x 7	496	672	1111	1506	1802	2443	1577	2138
1-1/8 x 12	556	754	1247	1691	2022	2741	–	–
1-1/4 x 7	700	949	1568	2126	2544	3449	2226	3018
1-1/4 x 12	774	1049	1737	2355	2816	3818	–	–
1-3/8 x 6	917	1243	2056	2788	3335	4522	2919	3958
1-3/8 x 12	1044	1415	2341	3174	3797	5148	–	–
1-1/2 x 6	1217	1650	2729	3700	4426	6001	3873	5251
1-1/2 x 12	1369	1856	3071	4164	4980	6752	–	–

**Table 11. Torque Values if You Apply LocTite 277**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
1 x 8	325	441	837	1135	1181	1601	1034	1402
1 x 12	356	483	916	1242	1293	1753	–	–
1 x 14	365	495	939	1273	1326	1798	–	–
1-1/8 x 7	461	625	1032	1399	1674	2270	1464	1985
1-1/8 x 12	516	700	1158	1570	1877	2545	–	–
1-1/4 x 7	650	881	1456	1974	2362	3202	2067	2802
1-1/4 x 12	719	975	1613	2187	2615	3545	–	–
1-3/8 x 6	851	1154	1909	2588	3097	4199	2710	3674
1-3/8 x 12	970	1315	2174	2948	3526	4781	–	–
1-1/2 x 6	1130	1532	2534	3436	4110	5572	3597	4877
1-1/2 x 12	1271	1723	2852	3867	4624	6269	–	–

### 1.4.1.2 Stainless Steel Fasteners

BNUUUN02.C06 0000222445 B.2 B.3 A.3 1/2/20 2:14 PM Released

**Table 12. Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller**

Dimension	316 Stainless		18-8 Stainless		18-8 Stainless with Loctite 767	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	79	9	76	9	45	5
1/4 x 28	100	11	94	11	56	6
5/16 x 18	138	16	132	15	79	9
5/16 x 24	148	17	142	16	85	10

**Table 13. Torque Values for Stainless Steel Fasteners Larger Than 5/16-inch**

Dimension	316 Stainless		18-8 Stainless		18-8 Stainless with Loctite 767	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
3/8 x 16	21	28	20	27	12	16
3/8 x 24	23	31	22	29	13	18
7/16 x 14	33	44	31	42	19	25
7/16 x 20	35	47	33	45	20	27
1/2 x 13	45	61	43	58	26	35
1/2 x 20	47	64	45	61	27	37
9/16 x 12	59	81	57	77	34	46
9/16 x 18	66	89	63	85	38	51
5/8 x 11	97	131	93	125	56	75
5/8 x 18	108	150	104	141	62	84
3/4 x 10	132	179	128	173	77	104
3/4 x 16	130	176	124	168	75	101
7/8 x 9	203	275	194	263	116	158
7/8 x 14	202	273	193	262	116	157
1 x 8	300	406	287	389	172	233
1 x 14	271	367	259	351	156	211
1-1/8 x 7	432	586	413	560	248	336
1-1/8 x 12	408	553	390	529	234	317
1-1/4 x 7	546	740	523	709	314	425
1-1/4 x 12	504	683	480	651	288	390
1-1/2 x 6	930	1261	888	1204	533	722
1-1/2 x 12	732	992	703	953	422	572

### 1.4.2 Preparation

BNUUUN02.T01 0000222511 B.2 B.3 A.3 1/2/20 2:14 PM Released



**WARNING: Fire Hazard** — Some solvents and primers are flammable.



- ▶ Use threadlocker and primers with sufficient airflow.
- ▶ Do not use flammable material near ignition sources.

1. Clean all threads with a wire brush or a different tool.
2. Remove the grease from the fasteners and the mating threads with solvent. Make the parts dry.





**NOTE:** LocTite 7649 Primer™ or standard solvents will remove grease from parts.

3. Apply a spray of LocTite 7649 Primer™ or equal on the fasteners and the mating threads. Let the primer dry for one minute minimum.

### 1.4.3 How to Apply a Threadlocker

BNUUUN02.T02 0000222508 B.2 B.3 A.3 11/26/19 2:48 PM Released




**CAUTION: Malfunction Hazard** — Heat, vibration, or mechanical shocks can let the fasteners loosen if you do not apply the threadlocker correctly. Loose fasteners can cause malfunctions of the equipment.



- ▶ Read the threadlocker manufacturer's instructions and warnings. Obey these instructions.

Apply the threadlocker only to the areas where the fastener threads and the mating threads engage.

**Figure 2. Apply Threadlocker in a Blind Hole**



#### 1.4.3.1 Blind Holes

BNUUUN02.T03 0000222507 B.2 B.3 A.3 1/2/20 2:14 PM Released


1. Apply the threadlocker down the threads to the bottom of the hole.
2. Apply the threadlocker to the bolt.
3. Tighten the bolt to the value shown in the correct table ([Table 6: Threadlocker by the Diameter of the Bolt](#) (see below Note ), page 12 to [Table 12: Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller](#), page 14 ).

### 1.4.3.2 Through Holes

BNUUUN02.T04 0000222506 B.2 B.3 A.3 11/26/19 2:51 PM Released

1. Put the bolt through the assembly.
2. Apply the threadlocker only to the bolt thread area that will engage the nut.
3. Tighten the bolt to the value shown in the correct table ([Table 6: Threadlocker by the Diameter of the Bolt](#) (see below Note ), page 12 to [Table 12: Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller](#), page 14 ).

**Figure 3. Apply Threadlocker in a Through Hole**




### 1.4.3.3 Disassembly

BNUUUN02.C07 0000222444 B.2 B.3 A.3 11/26/19 2:59 PM Released

For high-strength threadlocker, apply heat for five minutes. Disassemble with hand tools while the parts are hot.

For low-strength and moderate-strength threadlocker, disassemble with hand tools.

**Figure 4. Use heat for disassembly of fasteners with threadlocker.**




# 2 Safety-Related Components and Assemblies

# Safety Placard Use and Placement

COELV00A



**NOTICE:** Replace placard immediately, if removed or unreadable. Approximate locations of placards are shown. If aluminum placard, mounting holes are provided on machine. Use #8 self-tapping screws.



**Table 14. Parts List—Safety Placard Use and Placement**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Components				
all	1	01 10375B	NPLT:ELEC HAZARD SMALL-TCATA	
all	2	01 10564A	NPLT:COSHA HAZARDS-TCATA	
all	3	01 10699A	NPLT:SERV HZRD-PLYEST-TCATA	

BPVIEM02 / 2021433A

BPVIEM02.1 0000399333 B.2 C.2 10/20/21 4:10 PM Released


# Safety Placard Use and Placement — ISO

1 Sheet

COELV00A



**NOTE:** Replace placard immediately, if removed or unreadable. Approximate locations of placards are shown. If aluminum placard, mounting holes are provided on machine. Use #8 self-tapping screws.




**Table 15. Parts List—Safety Placard Use and Placement ISO**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Components				
all	1	01 10375	NPLTE:"WARNING" 2X2	
all	2	01 10564X	WARNINGS:SHUTTLE ISO	

# Safety Pin

All Elevating Shuttles and Pivoting Elevators.

	<p style="text-align: center;"><b>Legend</b></p> <p><b>A</b> . . . Side Slider</p> <p><b>B</b> . . . Safety Pin, 2 instances, left and right</p> <p><b>C</b> . . . Vertical frame member</p>
---	--


**Table 16. Parts List—Safety Pin**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Components				
all	1	04 21496	SAFETY PIN-COSHA	

# 3 Mechanical Components

# Stand & Air Cylinder

COELV00A





# Stand & Air Cylinder

2 Sheet


COELV00A

Table 17. Parts List—Stand &amp; Air Cylinder

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	ALC420270	ELEV COINC STAND ASSY	
Components				
all	1	04 24687	VERTICAL RAIL BASE-ELEV COINC	
all	2	04 24688	ELEV COINC VERTICAL RAIL-LF	
all	3	04 24688A	ELEV COINC VERTICAL RAIL-RT	
all	4	04 24689	ELEV COINC VERT RAIL CHANNEL	
all	5	04 24690	BOTTOM BEAM-ELEV COINC	
all	6	04 24694	TOP BEAM-ELEV COINC	
all	7	04 21293	VERTRAIL AIRCYL MTG BRKT	
all	8	27C320	AIRCYL 3.25"BOREX20"STK X1"ROD 2"THD	
all	9	17A045F	ROD EYE 3/4-16 CYC-COMP#RE-07	
all	10	54AA00PFRE	FEM ROD END ALIN#VF-12G 3/4"	
all	11	15K230	HEXCAPSCR 3/4-16X1+3/4 GR8 ZIN	
all	12	15G239S	HEXJAMNUT 3/4-16UNF2 SS18-8	
all	13	15U321H	FLTWASH 3/4 HARD ASTM F436	
all	14	17A045	CLEVIS PIN 3/4"X 3" DRILLED +	
all	15	15H051	STDCOTTERPIN 1/8X1+1/2ZINCPL	
all	16	96DG050	CHECKVAL PILTOPR ALADCO 1/2NPT	
all	17	27A005B	MUFFLER 1/2" BANTAM B48	
all	18	04 24704	VERTICAL RAIL SIDE COVER	
all	19	04 24705	AIR VALVES MTG BRKT	
all	20	04 24703	FOOT=ELEVATING COINC	

# Lifting Frame

COELV00A



### Legend

A-A. Cross Section View of Slider Bar

**Table 18. Parts List—**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	ALC420271	ELEV COINC LIFTING FRAME ASSY	
Components				
all	1	04 24692	SLIDER CHANNEL-ELEV COINC	
all	2	04 24693	ELEV COINC BED LIFTING BEAM	
all	3	04 24691	ELEV COINC BED MTG-LF	
all	4	04 24691A	ELEV COINC BED MTG-RT	
all	5	04 24695	BED BALANCING BRKT-ELEV COINC	
all	6	X4 22341	BED LIFTING SHAFT-DBLCHAIN	
all	7	X4 22342	LIFTING SHAFT CHAIN CONN	
all	8	X4 24526	DRILLBUSHING FOR #50 CHAIN	
all	9	X4 23391	TRACK SLIDER UHMW BAR	

# Lifting Frame

2 Sheet

COELV00A

Table 18 Parts List— (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	10	04 24696	BED LIFTING BRKT-ELEV COINC	
all	11	15A058SZ	CARBOLT 1/2-13X1.25 ZINCGR2	
all	12	15K162	HXCAPSCR 1/2-13UNC2AX1.5 GR5 P	
all	13	15G222B	HEXFLGNUT 1/2-13 ZINC SERRATED	
all	14	15A011	CARBOLT 3/8-16UNC2X1 ZINC GR2	
all	15	27B25002SZ	SPCRROLL.39ID.125L.048T STLZNC	
all	16	15K095	HXCPCSCR 3/8-16UNC2AX1 GR5 ZINC	
all	17	15U200	FLATWASHER(USS STD) 5/16"ZNC P	
all	18	15G218	HXLOKNUT NYL 3/8-16 STL/ZNC	


BPVIEF03 / 2021482A

BPVIEF03.1 0000399124 B.2 11/29/21 1:52 PM Released

# Lift Frame Balancing Assembly

2 Sheet

COELV00A



**Table 19. Parts List—**

Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	ALC420272	LIFT FRAME BALANCING ASSY	
Components				
all	1	04 24697	TOP SPROCKET CHAIN GUARD	
all	2	04 24702	TOP SPROCKET MTG BRKT	
all	3	04 24701	LOWER CHAIN GUARD-LF	
all	4	04 24701A	LOWER CHAIN GUARD-RT	
all	5	04 24699	BOTTOM SPROCKET BRKT-LF	
all	6	04 24699A	BOTTOM SPROCKET BRKT-RT	
all	7	X4 24700	COINC BED BALANCING SHAFT	

# Lift Frame Balancing Assembly

2 Sheet

COELV00A

Table 19 Parts List— (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	8	54N050B17	SPROCKET 17T MARTIN#D50ATB17H (1610)	
all	9	56Q1A1610	1.0" BUSH VPUL TPRLOCK1610TL	
all	10	54N050B15B	SPRKT, IDLER 51E15 #102054	
all	11	X4 24698	IDLER SPROCKET 1.25 LG SPACER	
all	12	54AF10001	FLG BRG 1" BROWN#VF2S-116M (2BOLT FLG)	
all	13	54JH11000A	SHAFTCOLLAR 1" CLPTYPE CFG#16A	
all	14	54G050F	CONN LINK-COTTERED STYLE CONNECTING LINK	
all	15	54G050C129	50-1 ROLCHN 129 PITCH=80.63"	

# Air Cylinder Lubricator & Shuttle Valve

COELV00A



**Legend**

A . . . Components shown above and listed on the parts list are correct for the COELV00A, but the pictures are not of the lubricator installed to the COELV00A.

**Table 20. Parts List—Air Cylinder Lubricator & Shuttle Valve**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	ALC420094	AIR CYL LUBRICATOR ASSY	
Components				
all	1	30N600C	1/2" AIRLINE LUBE FA4-L4P W/ MTG BRKT	
all	2	30N601C	1/2" AIRLINE FILTER FA4-F4PM W/ MTG BRKT	
all	3	20H035	MARVEL MYSTY.OIL-1GAL PAIL	
all	4	96N0013HU	SHUTLVLV 1/4" 4WAY CENTER-OFF	
all	5	27A005A	MUFFLER 1/4" ALLIED B-28 BANTAM	
all	6	5SB0K0EBEO	NPTHEXBUSH 1/2X1/4 BRASS 125#	
all	7	30N102	PRESSGAUGE 1/4BOTCON.0-150PSI	
all	8	53A031B	BODY-EL90MALE.25X1/8 #269C-42B	
all	9	53A040B	BODY=EL90MALE5/16X.25#B69A-5B	
all	100	53A023	MALECON3/8X.25COMP ANCHR#68-64	
all	11	60E004NT	TUBING (NYL.)CLR.1/4"ODX1/8"	

This page intentionally blank


BPVIEN01 / 2021422A

BPVIEN01.1 0000397707 B.2 A.3 10/12/21 8:28 AM Released

# Horizontal Bed 42Wx62L, 44Wx65L

2 Sheet

COELV00A111/112, COSHM1LP, COLFJ111A, COSHM111A, COLFM111A





## Horizontal Beds 42"Wx62"L and 44"Wx65"L


COELV00A111/112, COSHM1LP, COLFJ111A, COSHM111A, COLFM111A

2 Sheet


Table 21. Parts List—Horizontal Beds 42x62 and 44x65

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	ALC50097	HORZ 111BED ASSY 44WX62LG	COSHM/COLFM111A, COSHM1LP, COLFJ111A
	B	ALC50097A	HORZ 111BED ASSY 44WX65LG	COELV00A
Components				
A	1A	ALC50081	BED FRAME 44WX62LG ASSEMBLY	
B	1BA	04 22215	BED HALF 40WX62LG-RT SIDE	
B	1BB	04 22215A	BED HALF 40WX62LG-LF SIDE	
B	1BC	04 22292	SS BED LINER-COINC11K	
all	2	04 22269	SIDE UPPER HORZ 62"BED-RT	
all	3	04 22269A	SIDE UPPER HORZ 62"BED-LF	
all	4	04 22276	TORQARM LOWER HORZBED	
all	6	04 22233	TORQUE ARM GROMET MTG BRKT	
all	7	ALC420063	TORQUE ARM BUSHING ASSEMBLY	
all	8	Y4 20832E	DRVROLLER 4.50D X 53" OAL	
all	9	Y4 20832G	IDLER ROLLER 4.50D X 44.5" OAL	
A	10A	ALC50164	BELT+LACING FOR 'M' BED	
B	10BA	54C420GV	BELT 42" X 200' GREY WDGEGRIP W/VGUIDE SPLAWN	
B	10BB	54G201D	CLIPPER LACE #UX-1-36S	
B	10BC	54G302C	CONNECTING PIN # NYS065C EA=1FT	
all	11	04 23421A	BED SIDE MTG CHAN-COSHM111	
all	12	03 BF2X4W	MOUNT PLT=PHOTO REFLECTOR	
all	13	09RPE001A	REFLECTOR 3"DIA CLEAR	
all	14	09RPE011	PHOTOEYE VALU-BEAM 10-30DC	
all	15	04 22220	BRNGCARR 3.5H FRAME-LOADEND	
all	16	04 22221	BRNGCARR 3.5H FR-UNLOAD END	
all	17	54AF10001	FLG BRG 1" BROWN#VF2S-116M (2BOLT FLG)	
all	18	54JH11000A	SHAFTCOLLAR 1" CLPTYPE CFG#16A	
all	19	15U241MB	FLAT WASHER-1.50D 1+1/32ID 10G	
all	20	15K091H	HEXFLGSCR 3/8-16X3/4 ZN GRD.5	
all	21	15U245A	FLTWASH 25/64IDX1.25ODX3/32 S/	


# 4 Dimensional Drawings




PLAN VIEW



LEFT VIEW



FRONT VIEW



RIGHT VIEW

F1	ANCHOR BOLT HOLES 3/4" [19] DIAMETER, 4 PLACES, FOR
	5/8"x4" MINIMUM ANCHOR BOLTS, NOT SUPPLIED
E2	EMERGENCY STOP
E1	MAIN ELECTRIC CONNECTION
A1	COMPRESSED AIR INLET, 1/2" NPT
ITEM	LEGEND

**NOTES**

6 AS OF THIS WRITING, THE MINIMUM CLEARANCE REQUIRED BY U.S. NATIONAL ELECTRIC CODES, FROM ELECTRIC BOX TO ANY OBJECT IS:  
 36 [914] IF OBJECT IS AN UNGROUNDED (INSULATED) WALL  
 42 [1067] IF OBJECT IS A GROUNDED WALL (e.g. BARE CONCRETE, BRICK, ETC.)  
 48 [1219] IF OBJECT IS ANY LIVE PART.  
 CHECK LOCAL ELECTRIC CODES FOR FURTHER RESTRICTIONS.

5 CUSTOMER TO SUPPLY CIRCUIT BREAKER OR FUSED BRANCH CIRCUIT DISCONNECT (SAFETY) SWITCHES WITH LAG TYPE FUSES FROM POWER SOURCE TO MACHINE. A SEPARATE GROUND WIRE MUST BE CONNECTED FROM DISCONNECT TO EQUIPMENT.

4 BASELINE "Z" IS THE REFERENCE FOR ALL VERTICAL DIMENSIONS. ON MACHINES WITH FIXED BASE PADS, BASELINE "Z" CORRESPONDS TO THE BOTTOM OF THE BASE PAD. ON MACHINES WITH ADJUSTABLE FEET, BASELINE "Z" CORRESPONDS TO THE BOTTOM OF THE FEET WHEN ADJUSTED SO THAT THE MACHINE IS AT ITS MINIMUM ACCEPTABLE HEIGHT. ON TRAVELING SHUTTLES, BASELINE "Z" CORRESPONDS TO THE BOTTOM OF THE BOTTOM RAIL. THE DISTANCE BETWEEN BASELINE "Z" AND THE FINISHED FLOOR WILL VARY AS REQUIRED TO ENSURE BASELINE "Z" IS HORIZONTAL AND ANY INTERFACING MACHINES REQUIRING GROUT ARE SET ON A MINIMUM 1" [25] THICK GROUT BED.

3 USE REFERENCE LINES "X", "Y", AND "Z" TO LOCATE ALL SERVICE CONNECTIONS.

2 NUMBERS IN BRACKETS [ ] DENOTE DIMENSIONS IN MILLIMETERS.

1 ALL DIMENSIONS SHOWN ARE APPROXIMATE, SUBJECT TO NORMAL MANUFACTURING TOLERANCES, AND TO OCCASIONAL CHANGES WITHOUT NOTICE THROUGH REDESIGN AND/OR RELOCATION OF COMPONENTS, ETC. DO NOT USE FOR CONSTRUCTION UNLESS CERTIFIED, AND IN NO EVENT PRE-PIPE CLOSER THAN FIVE FEET FROM MACHINE. FACTORY MUST BE CONSULTED FOR DIMENSIONS IF MACHINE IS TO BE MOVED THROUGH NARROW OR LOW CORRIDORS OR OPENINGS.

**ATTENTION**  
 MOST REGULATORY AUTHORITIES (INCLUDING OSHA IN THE USA) HOLD THE OWNER/USER ULTIMATELY RESPONSIBLE TO MAINTAIN A SAFE WORKING ENVIRONMENT. ACCORDINGLY, THE OWNER/USER MUST RECOGNIZE ALL FORESEEABLE SAFETY HAZARDS, FURNISH SAFETY INSTRUCTIONS AND GUIDANCE TO ALL PERSONNEL WHO MAY COME IN CONTACT WITH THE INSTALLATION, AND PROVIDE ALL NECESSARY ADDITIONAL SAFETY GUARDS, FENCES, RESTRAINTS, DEVICES, ETC., NOT FURNISHED BY THE EQUIPMENT MANUFACTURER OR VENDOR.

**ATTENTION**  
 THE FLOOR AND/OR OTHER SUPPORT COMPONENTS MUST HAVE SUFFICIENT STRENGTH (AND RIGIDITY WITH DUE CONSIDERATION FOR NATURAL OR RESONANT FREQUENCY THEREOF) TO WITHSTAND THE FULLY LOADED WEIGHT OF THE MACHINE INCLUDING THE GOODS, THE WATER, AND ANY REPEATED SINUSOIDAL (ROTATING) FORCES GENERATED DURING ITS OPERATION. WRITE THE FACTORY FOR ADDITIONAL MACHINE DATA FOR USE BY A COMPETENT SOIL AND/OR STRUCTURAL ENGINEER.

COELV00A HORIZ ELEVATING COINC

2021426D  
 BDCOELV00AAE  
**MILNOR** PELLERIN MILNOR CORPORATION  
 P.O. Box 400 Kenner, LA 70063, USA, Phone 504/487-9591,  
 FAX 504/488-3094, Email: milnor@milnor.com