



Manual Number: MCWG7M01  
Edition (ECN): 2023352A

# Mechanical Parts and Service

## 72044SR2, SR3







|         |  |     |
|---------|--|-----|
| 2.2.2   | How to Do a Friction Pad Replacement .....   | 43  |
| 2.2.3   | How to Do a Caliper Overhaul .....   | 45  |
| 2.2.4   | How to Change Hydraulic Fluid and Remove (Bleed) Air from the Brake<br>Circuit .....                     | 46  |
| 2.2.5   | How to Adjust the Connection between the Brake Cylinder and the Air<br>Cylinder .....                    | 50  |
| 2.2.6   | Operation of Brake Systems .....   | 52  |
| 2.2.6.1 | How to Apply the Brake for Machines with a "Break Release"<br>Output .....                               | 52  |
| 2.2.6.2 | How to Release the Brake for Machines with a "Brake Release"<br>Output .....                             | 53  |
| 2.2.6.3 | How to Apply and then Release the Brake Quickly .....  | 53  |
| 2.2.6.4 | How the Brake Operates on Divided Cylinder Machines .....  | 53  |
| 2.2.6.5 | The Second Brake .....   | 54  |
|         | Drive Chart 72044SR2, SR3 .....  | 55  |
|         | Drive Base 72044SR2 .....  | 58  |
|         | Jackshaft 72044WR2, 72044SR2 .....   | 63  |
|         | Air Clutch 72044WR2, 72044SR2 .....  | 66  |
|         | Reducer Air Seal .....   | 67  |
|         | Upper Brake Assembly 72044SR2/SR3 .....  | 68  |
| 2.3     | Main Bearing and Seal Replacement for Divided Cylinder Machines .....                                    | 70  |
| 2.3.1   | Removing the Bearing (Front or Rear) .....   | 71  |
| 2.3.2   | Removing the Bearing Housing (Bearing and Seal Carrier), Seal Sleeve, and<br>Seals (Front or Rear) ..... | 72  |
| 2.3.3   | Precautions for Bearing Replacement .....  | 73  |
| 2.3.4   | Replacing the Bearing Housing, Seal Sleeve, and Seals (Front or Rear) .....                              | 74  |
| 2.3.5   | Measuring Unmounted Clearance and Setting Bearing (Front or Rear) .....                                  | 76  |
| 2.3.6   | Tightening Bearing(s) (Front and/or Rear) .....  | 78  |
|         | Shaft and Bearing Components 72044WR2, 72044WR3, 72044SR2, 72044SR3 .....                                | 80  |
|         | Autospot Drive Motor 72044WR2, 72044SR2 .....  | 84  |
|         | 4 Inch Idler Shaft Bearing 72044SR2 .....  | 86  |
|         | Lower Disc Brake Installation 6044SR2, 6044SR3, 7244SR2 .....  | 89  |
|         | Lower Disc Brake Split Bearing Parts and Assembly 6044SR2, 72044SR2/SR3 .....                            | 94  |
|         | Assembly Procedure .....   | 95  |
| 3       | Frame & Suspension .....   | 99  |
| 3.1     | Suspension Adjustments for Divided Cylinder Machines .....   | 99  |
| 3.1.1   | How Shell Adjustments are Made .....   | 99  |
| 3.1.2   | Shell Hanging Dimensions and Adjustment Procedures .....   | 100 |
| 3.1.3   | Push-Down Travel Dimensions and Adjustment Procedures .....  | 102 |
| 3.1.3.1 | 42" Divided Cylinder Machines .....  | 102 |
| 3.1.3.2 | 60" Divided Cylinder Machines .....  | 103 |
|         | Hold Down Adjustment 6044SR2/SR3, 6044WR2/WR3, 72044SR2/SR3, 72044WR2/WR3 .....                          | 106 |
|         | Push Down Components 72044WR2, SR2 .....   | 108 |
|         | Suspension Cylinder Assemblies 42031,42044,52038,60044,72044 .....                                       | 111 |
|         | Suspension Cylinder Locations .....  | 114 |
| 4       | Shell, Cylinder & Door .....   | 116 |
|         | Shell Doors 72044WR3, 72044SR2 .....   | 118 |
|         | Door Latch .....   | 121 |

|   |     |
|---|-----|
| Cylinder Assembly and Cylinder Door Installation 6044SR2, 7244SR2.....                                | 122 |
| Cylinder Doors 3 pocket 7244WR3, 7244SR3 .....  | 127 |
| 5 Staph Guard® .....  | 132 |
| Staph Barrier Cleanside 6044SR2, 72044SR2.....  | 134 |
| Staphairtrol 60044SR2, 72044SR2 .....   | 136 |
| 6 Control & Sensing .....   | 139 |
| Air Operated Autospot and Sensing Unit 72044SR2.....  | 140 |
| Excursion Switch 6044SR2, 6044SR3, 7244SR2 .....  | 144 |
| Air Chamber Level Switch 42044WR2,WR3,SR2,SR3; 6044WR2,WR3,SR2, SR3; 72044WR2,<br>WR3, SR2, SR3 ..... | 145 |
| Air Chamber Level Switch with Overflow Pressure Switch 72044WR2,WR3,SR3<br>72046M5K, 48040M7K.....    | 148 |
| Temperature Probe 6044WR2,WR3,SR2 72044WR2,WR3,SR3 .....  | 150 |
| Centrifugal Switch Assembly 72044SR2, 72044SR3 .....  | 151 |
| 6.1 Vibration Safety Switch Adjustments .....   | 153 |
| 6.1.1 What the Vibration Safety Switch Does.....  | 153 |
| 6.1.2 Adjustments.....  | 153 |
| Vibration Safety Switch .....   | 155 |
| 7 Chemical Supply Devices.....  | 156 |
| Peristaltic Supply Manifold 72044WR2, 72044SR2.....   | 157 |
| Soap Chute 72044SR2 .....   | 158 |
| Five Compartment Supply 72044SP2, 72044SR2, 7244WP2, 7244WR2.....                                     | 160 |
| 8 Water & Steam .....   | 166 |
| Water Inlets 72044SR2.....  | 167 |
| Steam Components 72044SR2.....  | 170 |
| 8”X10” Stainless Dump Valve 42044WR2/WR3/SR2/SR3; 60044WR2/WR3/SR2/SR3;<br>72044WR2/WR3/SR2/SR3 ..... | 174 |
| Drain Valve Body with Two Valves 72044WR2, 72044SR2 .....   | 177 |
| 9 Pneumatic .....   | 181 |
| 9.1 Servicing Air Cylinders .....   | 181 |
| Brake Air Cylinder .....  | 184 |

## Figures

|           |   |    |
|-----------|---|----|
| Figure 1  | Soil Side.....  | 20 |
| Figure 2  | Clean Side.....   | 21 |
| Figure 3  | The Bolts in Milnor® Equipment.....   | 23 |
| Figure 4  | Apply Threadlocker in a Blind Hole.....   | 29 |
| Figure 5  | Apply Threadlocker in a Through Hole.....   | 30 |
| Figure 6  | Use heat for disassembly of fasteners with threadlocker.....  | 30 |
| Figure 7  | Examples of drives this instruction applies to: one or more V-belts, at-<br>tached V-belts and tooth belts..... | 31 |
| Figure 8  | Pulley Groove Condition .....   | 32 |
| Figure 9  | Pulley and Shaft Position.....  | 33 |
| Figure 10 | Run-out .....   | 34 |
| Figure 11 | Typical Pulley Assembly .....   | 34 |
| Figure 12 | Types of Belt Damage.....   | 35 |
| Figure 13 | A Tension Mechanism that will not Change the Angle of the Pulleys .....   | 37 |

|           |  |     |
|-----------|--|-----|
| Figure 14 | Some Pairs of Tension Mechanisms that Can Change the Angle of the Pulleys.....   | 37  |
| Figure 15 | Use a straight edge, a string, or a laser to make sure that all pulleys are in the same plane.....                         | 39  |
| Figure 16 | Use a level to make sure that the pulleys are at the same slope. ....  | 40  |
| Figure 17 | Dial indicator used to find the axial and radial run-out of a pulley. ....   | 40  |
| Figure 18 | A typical hydraulic brake system.....  | 41  |
| Figure 19 | The Caliper Components .....   | 45  |
| Figure 20 | Pumps Used to Remove Hydraulic Fluid Quickly.....  | 48  |
| Figure 21 | Typical Tools to Remove Air (Bleed) Brakes and Used Hydraulic Fluid .....  | 48  |
| Figure 22 | The Connection between the Brake Cylinder and the Air Cylinder .....   | 50  |
| Figure 23 | The Adjustment between the Brake Rod and the Air Cylinder .....  | 51  |
| Figure 24 | A Typical First and Second Brake on a Divided Cylinder Machine.....  | 53  |
| Figure 25 | Drive Chart .....  | 55  |
| Figure 26 | Drive Chart - Rear View and Top View.....  | 56  |
| Figure 27 | Cross Section Views .....  | 63  |
| Figure 28 | Detail Views.....  | 64  |
| Figure 29 | Cross Section View of Front and Rear Bearing Assemblies (Bearing Assembly for 60" and 72" WED Shown. Others similar.)..... | 70  |
| Figure 30 | Connection From Hydraulic Pump to Assist in Bearing Removal.....   | 72  |
| Figure 31 | Two Bearing Housing Guide Rods in Position.....  | 72  |
| Figure 32 | Bearing Housing Pulling Fixture in Position.....   | 72  |
| Figure 33 | Installing Seals in Bearing Housing.....   | 74  |
| Figure 34 | Installing Seal Sleeve in Bearing Housing .....  | 74  |
| Figure 35 | Installing the Bearing Housing Setting Fixture onto Housing (42" machine shown).....                                       | 75  |
| Figure 36 | Pushing the Bearing Housing into the Shell (60" Rapid-load machine shown).....   | 75  |
| Figure 37 | Tightening the Bearing Housing into the Shell (42" machine shown) .....  | 76  |
| Figure 38 | Measuring Bearing Unmounted Clearance (bridge for 42" machine shown).....  | 77  |
| Figure 39 | Tightening the Bearing Lock nut (42" machine shown).....   | 79  |
| Figure 40 | Measuring the Mounted Internal Clearance of the Bearing (42" machine shown).....   | 79  |
| Figure 41 | Shaft and Bearing Components .....   | 80  |
| Figure 42 | Front Bearing (Models: 72044WR2, 72044WR3) .....   | 80  |
| Figure 43 | Front Bearing (Models: 72044SR2, 72044SR3).....  | 81  |
| Figure 44 | Rear Bearing (Models: 72044WR2, 72044WR3, 72044SR2, 72044SR3).....   | 81  |
| Figure 45 | Cross section views.....   | 86  |
| Figure 46 | Bearing Components.....  | 94  |
| Figure 47 | Hydro-cushion™ Upper Shaft and Adjusting Nuts.....   | 100 |
| Figure 48 | Shell Hanging for Divided Cylinder Machines (Left side view of 60044WE shown) .....  | 101 |
| Figure 49 | Push-down Travel Adjustment: 42" Div-cyls (42" Staph Guard®) .....   | 103 |
| Figure 50 | Ring Weldments.....  | 104 |
| Figure 51 | Push Down installation and pneumatic fittings .....  | 108 |
| Figure 52 | Push Down installation and pneumatic fittings .....  | 109 |

|           |  |     |
|-----------|--|-----|
| Figure 53 | Exploded Views .....                                     | 118 |
| Figure 54 | Detail View .....  | 119 |
| Figure 55 | Cylinder Assembly and Cylinder Door Installation .....   | 122 |
| Figure 56 | Cylinder Doors Installed.....                            | 123 |
| Figure 57 | Detail Views.....  | 124 |
| Figure 58 | Section Views .....                                      | 127 |
| Figure 59 | Cylinder Doors.....                                      | 128 |
| Figure 60 | Additional Views .....                                   | 129 |
| Figure 61 | Exploded View .....                                      | 136 |
| Figure 62 | Installed View .....                                     | 137 |
| Figure 63 | Sensing Unit Installation and Drive Components.....      | 140 |
| Figure 64 | Sensing Unit: Switch Assembly and Cam .....              | 141 |
| Figure 65 | Vibration Switch .....                                   | 154 |
| Figure 66 | Installed view .....                                     | 160 |
| Figure 67 | Supply box components.....                               | 161 |
| Figure 68 | Water inlet and manifold piping .....                    | 162 |
| Figure 69 | Hot, Cold, and Third Water Inlets.....                   | 167 |
| Figure 70 | Piping to Drain Sump .....                               | 168 |
| Figure 71 | Reserve Air Pressure Tank and Dual Drain Valve.....      | 177 |
| Figure 72 | Cross Section of one valve of the Dual Drain Valves..... | 178 |
| Figure 73 | Using Threaded Rods.....                                 | 182 |
| Figure 74 | Ensuring Correct Piston Cup Shape.....                   | 182 |

## Tables

|          |   |    |
|----------|---|----|
| Table 1  | Trademarks .....  | 9  |
| Table 2  | Parts List—Safety Placard Use and Placement 60044SR2, 60044SR3,<br>72044SR2 .....               | 17 |
| Table 3  | Parts List—Safety Placard Use and Placement ISO 60044SR2, 60044SR3,<br>72044SR2 .....           | 19 |
| Table 4  | Parts List—Belt Guards 72044SR2.....  | 21 |
| Table 5  | Torque Values for Standard Fasteners with Maximum 5/16-inch Diameters and<br>No Lubricant ..... | 23 |
| Table 6  | Torque Values for Standard Fasteners Larger Than 5/16-inch Diameters and<br>No Lubricant .....  | 24 |
| Table 7  | Torque Values for Plated Fasteners with Maximum 5/16-inch Diameters and<br>No Lubricant .....   | 24 |
| Table 8  | Torque Values for Plated Fasteners Larger Than 5/16-inch Diameters and No<br>Lubricant .....    | 25 |
| Table 9  | Threadlocker by the Diameter of the Bolt (see below Note ) .....                                | 25 |
| Table 10 | Torque Values if You Apply LocTite 222 .....  | 26 |
| Table 11 | Torque Values if You Apply LocTite 242 .....  | 26 |
| Table 12 | Torque Values if You Apply LocTite 262 .....  | 26 |
| Table 13 | Torque Values if You Apply LocTite 272 (High-Temperature) .....                                 | 26 |
| Table 14 | Torque Values if You Apply LocTite 277 .....  | 27 |
| Table 15 | Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller .....                         | 27 |
| Table 16 | Torque Values for Stainless Steel Fasteners Larger Than 5/16-inch .....                         | 28 |
| Table 17 | Typical Tools for Pulley and Belt Maintenance .....   | 37 |

|          |  |     |
|----------|--|-----|
| Table 18 | Parts List—Drive Chart 72044SR2, SR3.....  | 57  |
| Table 19 | Parts List—Drive Base 72044SR2 .....   | 61  |
| Table 20 | Parts List—Jackshaft 72044WR2, 72044SR2 .....  | 65  |
| Table 21 | Parts List—Air Clutch 72044WR2, 72044SR2 .....   | 66  |
| Table 22 | Parts List—Reducer Air Seal .....  | 67  |
| Table 23 | Parts List—Upper Brake Assembly 72044SR2/SR3 .....   | 69  |
| Table 24 | Table of Bearing Clearances .....  | 78  |
| Table 25 | Parts List—Shaft and Bearing Components 72044WR2, 72044WR3, 72044SR2,<br>72044SR3 .....                          | 82  |
| Table 26 | Parts List—Autospot Drive Motor 72044WR2, 72044SR2 .....   | 85  |
| Table 27 | Parts List—4 Inch Idler Shaft Bearing 72044SR2 .....   | 87  |
| Table 28 | Parts List—Lower Disc Brake Installation 6044SR2, 6044SR3, 7244SR2 .....   | 92  |
| Table 29 | Parts List—Lower Disc Brake Split Bearing Parts and Assembly 6044SR2,<br>72044SR2/SR3.....                       | 94  |
| Table 30 | Hanging Dimensions .....   | 101 |
| Table 31 | Parts List—Hold Down Adjustment 6044SR2/SR3, 6044WR2/WR3, 72044SR2/SR3,<br>72044WR2/WR3 .....                    | 107 |
| Table 32 | Parts List—Push Down Components 72044WR2, SR2.....   | 110 |
| Table 33 | Parts List—Suspension Cylinder Assemblies<br>42031,42044,52038,60044,72044 .....                                 | 112 |
| Table 34 | Parts List—Shell Doors 72044WR3, 72044SR2 .....  | 119 |
| Table 35 | Parts List—Door Latch .....  | 121 |
| Table 36 | Parts List—Cylinder Assembly and Cylinder Door Installation 6044SR2,<br>7244SR2 .....                            | 125 |
| Table 37 | Parts List—Cylinder Doors 3 pocket 7244WR3, 7244SR3 .....  | 130 |
| Table 38 | Parts List—Staph Barrier Cleanside 6044SR2, 72044SR2.....  | 135 |
| Table 39 | Parts List—Staphairtrol 60044SR2, 72044SR2 .....   | 137 |
| Table 40 | Parts List—Air Operated Autospot and Sensing Unit 72044SR2.....  | 142 |
| Table 41 | Parts List—Excursion Switch 6044SR2, 6044SR3, 7244SR2 .....  | 144 |
| Table 42 | Parts List—Air Chamber Level Switch 42044WR2,WR3,SR2,SR3; 6044WR2,WR3,<br>SR2, SR3; 72044WR2, WR3, SR2, SR3..... | 145 |
| Table 43 | Parts List—Air Chamber Level Switch with Overflow Pressure Switch<br>72044WR2,WR3,SR3 72046M5K, 48040M7K .....   | 149 |
| Table 44 | Parts List—Temperature Probe 6044WR2,WR3,SR2 72044WR2,WR3,SR3 .....  | 150 |
| Table 45 | Parts List—Centrifugal Switch Assembly 72044SR2, 72044SR3 .....  | 151 |
| Table 46 | Effect of Tripping Vibration Safety Switch .....   | 153 |
| Table 47 | Parts List—Vibration Safety Switch .....   | 155 |
| Table 48 | Parts List—Peristaltic Supply Manifold 72044WR2, 72044SR2.....   | 157 |
| Table 49 | Parts List—Soap Chute 72044SR2.....  | 158 |
| Table 50 | Parts List—Five Compartment Supply 72044SP2, 72044SR2, 7244WP2,<br>7244WR2.....                                  | 163 |
| Table 51 | Parts List—Water Inlets 72044SR2.....  | 169 |
| Table 52 | Parts List—Steam Components 72044SR2.....  | 172 |
| Table 53 | Parts List—8”X10” Stainless Dump Valve 42044WR2/WR3/SR2/SR3; 60044WR2/<br>WR3/SR2/SR3; 72044WR2/WR3/SR2/SR3..... | 175 |
| Table 54 | Parts List—Drain Valve Body with Two Valves 72044WR2, 72044SR2 .....   | 179 |
| Table 55 | Parts List—Brake Air Cylinder .....  | 185 |



# 1 General Service & Safety-Related Components

## **PELLERIN MILNOR CORPORATION LIMITED STANDARD WARRANTY**

We warrant to the original purchaser that MILNOR machines including electronic hardware/software (hereafter referred to as "equipment"), will be free from defects in material and workmanship for a period of one year from the date of shipment (unless the time period is specifically extended for certain parts pursuant to a specific MILNOR published extended warranty) from our factory with no operating hour limitation. This warranty is contingent upon the equipment being installed, operated and serviced as specified in the operating manual supplied with the equipment, and operated under normal conditions by competent operators.

Providing we receive written notification of a warranted defect within 30 days of its discovery, we will—at our option—repair or replace the defective part or parts, EX Factory (labor and freight specifically NOT included). We retain the right to require inspection of the parts claimed defective in our factory prior to repairing or replacing same. We will not be responsible, or in any way liable, for unauthorized repairs or service to our equipment, and this warranty shall be void if the equipment is tampered with, modified, or abused, used for purposes not intended in the design and construction of the machine, or is repaired or altered in any way without MILNOR's written consent.

Parts damaged by exposure to weather, to aggressive water, or to chemical attack are not covered by this warranty. For parts which require routine replacement due to normal wear—such as gaskets, contact points, brake and clutch linings, belts, hoses, and similar parts—the warranty time period is 90 days.

We reserve the right to make changes in the design and/or construction of our equipment (including purchased components) without obligation to change any equipment previously supplied.

ANY SALE OR FURNISHING OF ANY EQUIPMENT BY MILNOR IS MADE ONLY UPON THE EXPRESS UNDERSTANDING THAT MILNOR MAKES NO EXPRESSED OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE OR ANY OTHER WARRANTY IMPLIED BY LAW INCLUDING BUT NOT LIMITED TO REDHIBITION. MILNOR WILL NOT BE RESPONSIBLE FOR ANY COSTS OR DAMAGES ACTUALLY INCURRED OR REQUIRED AS A RESULT OF: THE FAILURE OF ANY OTHER PERSON OR ENTITY TO PERFORM ITS RESPONSIBILITIES, FIRE OR OTHER HAZARD, ACCIDENT, IMPROPER STORAGE, MIS-USE, NEGLIGENCE, POWER OR ENVIRONMENTAL CONTROL MALFUNCTIONS, DAMAGE FROM LIQUIDS, OR ANY OTHER CAUSE BEYOND THE NORMAL RANGE OF USE. REGARDLESS OF HOW CAUSED, IN NO EVENT SHALL MILNOR BE LIABLE FOR SPECIAL, INDIRECT, PUNITIVE, LIQUIDATED, OR CONSEQUENTIAL COSTS OR DAMAGES, OR ANY COSTS OR DAMAGES WHATSOEVER WHICH EXCEED THE PRICE PAID TO MILNOR FOR THE EQUIPMENT IT SELLS OR FURNISHES.

THE PROVISIONS ON THIS PAGE REPRESENT THE ONLY WARRANTY FROM MILNOR AND NO OTHER WARRANTY OR CONDITIONS, STATUTORY OR OTHERWISE, SHALL BE IMPLIED.

WE NEITHER ASSUME, NOR AUTHORIZE ANY EMPLOYEE OR OTHER PERSON TO ASSUME FOR US, ANY OTHER RESPONSIBILITY AND/OR LIABILITY IN CONNECTION WITH THE SALE OR FURNISHING OF OUR EQUIPMENT TO ANY BUYER.

BMP720097/19036

**BNUUUM01 / 2019342**

BNUUUM01 0000250121 B.3 1/2/20, 2:14 PM Released

## 1.1 How to Get the Necessary Repair Components

BNUUUM01.C01 0000250120 D.2 B.3 A.3 1/2/20, 2:14 PM Released

You can get components to repair your machine from the approved supplier where you got this machine. Your supplier will usually have the necessary components in stock. You can also get components from the Milnor® factory.

Tell the supplier the machine model and serial number and this data for each necessary component:

- The component number from this manual
- The component name if known
- The necessary quantity
- The necessary transportation requirements
- If the component is an electrical component, give the schematic number if known.
- If the component is a motor or an electrical control, give the nameplate data from the used component.

To write to the Milnor® factory:

Pellerin Milnor Corporation  
 Post Office Box 400  
 Kenner, LA 70063-0400  
 UNITED STATES

Telephone: 504-712-7775

Fax: 504-469-9777

Email: parts@milnor.com

**BNUUUU02 / 2023296**

BNUUUU02 0000158094 G.2 7/20/23, 10:58 AM Released

## 1.2 Trademarks

BNUUUU02.R01 0000158093 D.2 G.2 F.2 7/20/23, 10:57 AM Released

These words are trademarks of Pellerin Milnor® Corporation and other entities:

**Table 1. Trademarks**

|               |                |              |              |
|---------------|----------------|--------------|--------------|
| AutoSpot™     | GreenFlex™     | MilMetrix®   | PulseFlow®   |
| CBW®          | GearTrace™     | MilTouch™    | RAM Command™ |
| Drynet™       | GreenTurn™     | MilTouch-EX™ | RecircONE®   |
| E-P Express®  | Hydro-cushion™ | MilRAIL®     | RinSave®     |
| E-P OneTouch® | Mentor®        | Miltrac™     | SmoothCoil™  |

**Table 1 Trademarks (cont'd.)**

|                |          |            |              |
|----------------|----------|------------|--------------|
| E-P Plus®      | Mildata® | MilVision™ | Staph Guard® |
| Gear Guardian® | Milnor®  | PBW™       |              |

BNWVUS08 / 2020122 BNWVUS08 0000279016 A.2 3/16/20, 3:40 PM Released

## 1.3 Safety — Divided Cylinder and Staph Guard® Washer-Extractors

BNWVUS08.C01 0000279015 D.2 A.2 3/16/20, 3:40 PM Released

### 1.3.1 Safety Alert Messages—Internal Electrical and Mechanical Hazards

BNWVUS01.C03 0000235064 D.2 A.2 A.3 1/2/20, 2:19 PM Released

The following are instructions about hazards inside the machine and in electrical enclosures.



**WARNING: Electrocutation and Electrical Burn Hazards** — Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.



- ▶ Do not unlock or open electric box doors.
- ▶ Do not remove guards, covers, or panels.
- ▶ Do not reach into the machine housing or frame.
- ▶ Keep yourself and others off of machine.
- ▶ Know the location of the main machine disconnect and use it in an emergency to remove all electric power from the machine.



**WARNING: Entangle and Crush Hazards** — Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.



- ▶ Do not remove guards, covers, or panels.
- ▶ Do not reach into the machine housing or frame.
- ▶ Keep yourself and others off of machine.
- ▶ Know the location of all emergency stop switches, pull cords, and/or kick plates and use them in an emergency to stop machine motion.

### 1.3.2 Safety Alert Messages—External Mechanical Hazards

BNWVUS02.C03 0000235097 D.2 A.2 A.3 1/2/20, 2:19 PM Released

The following are instructions about hazards around the front, sides, rear or top of the machine.



**WARNING: Crush Hazards** — Suspended machines only—Spaces between the shell and housing can close and crush or pinch your limbs. The shell moves within the housing during operation.



- ▶ Do not reach into the machine housing or frame.
- ▶ Keep yourself and others clear of movement areas and paths.

### 1.3.3 Safety Alert Messages—Cylinder and Processing Hazards

BNWVJUS03.C03 0000235094 D.2 A.2 A.3 1/2/20, 2:19 PM Released

The following are instructions about hazards related to the cylinder and laundering process.



**WARNING: Crush Hazards** — Contact with the turning cylinder can crush your limbs. The cylinder will repel any object you try to stop it with, possibly causing the object to strike or stab you. The turning cylinder is normally isolated by the locked cylinder door.



- ▶ Do not attempt to open the door or reach into the cylinder until the cylinder is stopped.
- ▶ Do not place any object in the turning cylinder.
- ▶ Do not operate the machine with a malfunctioning door interlock.
- ▶ Divided cylinder machines only—Keep yourself and others clear of cylinder and goods during inching or Autospot operation.
- ▶ Do not operate the machine with malfunctioning two-hand manual controls.



**WARNING: Confined Space Hazards** — Confinement in the cylinder can kill or injure you. Hazards include but are not limited to panic, burns, poisoning, suffocation, heat prostration, biological contamination, electrocution, and crushing.



- ▶ Do not attempt unauthorized servicing, repairs, or modification.



**WARNING: Explosion and Fire Hazards** — Flammable substances can explode or ignite in the cylinder, drain trough, or sewer. The machine is designed for washing with water, not any other solvent. Processing can cause solvent-containing goods to give off flammable vapors.



- ▶ Do not use flammable solvents in processing.
- ▶ Do not process goods containing flammable substances. Consult with your local fire department/public safety office and all insurance providers.

## 1.3.4 Safety Alert Messages—Unsafe Conditions

BNWVUS04.C01 0000235093 D.2 A.2 A.3 12/11/20, 8:32 AM Released

### 1.3.4.1 Damage and Malfunction Hazards

BNWVUS04.C02 0000235092 D.2 A.2 A.3 12/11/20, 8:32 AM Released

#### 1.3.4.1.1 Hazards Resulting from Inoperative Safety Devices

BNWVUS04.C03 0000235091 D.2 A.2 A.4 12/11/20, 8:32 AM Released



**DANGER:** **Entangle and Sever Hazards** — Cylinder door interlock—Operating the machine with a malfunctioning door interlock can permit opening the door when the cylinder is turning and/or starting the cycle with the door open, exposing the turning cylinder.



- ▶ Do not operate the machine with any evidence of damage or malfunction.



**WARNING:** **Multiple Hazards** — Operating the machine with an inoperative safety device can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.

- ▶ Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.



**WARNING:** **Electrocution and Electrical Burn Hazards** — Electric box doors—Operating the machine with any electric box door unlocked can expose high voltage conductors inside the box.



- ▶ Do not unlock or open electric box doors.



**WARNING:** **Entangle and Crush Hazards** — Guards, covers, and panels—Operating the machine with any guard, cover, or panel removed exposes moving components.



- ▶ Do not remove guards, covers, or panels.

#### 1.3.4.1.2 Hazards Resulting from Damaged Mechanical Devices

BNWVUS04.C04 0000235090 D.2 A.2 A.4 12/11/20, 8:32 AM Released



**WARNING:** **Multiple Hazards** — Operating a damaged machine can kill or injure personnel, further damage or destroy the machine, damage property, and/or void the warranty.

- ▶ Do not operate a damaged or malfunctioning machine. Request authorized service.



**WARNING:** **Explosion Hazards** — Cylinder—A damaged cylinder can rip apart during extraction, puncturing the shell and discharging metal fragments at high speed.



- ▶ Do not operate the machine with any evidence of damage or malfunction.



**WARNING: Explosion Hazards** — Inner door latches (divided cylinder machines)—A damaged or improperly seated latch can cause the inner door to open during operation, damaging the cylinder and shell. A damaged cylinder can rip apart during extraction, puncturing the shell and discharging metal fragments at high speed.



- ▶ Ensure that the inner door is securely latched after loading and unloading.

- ▶ Do not operate the machine with any evidence of damage or malfunction.



**WARNING: Explosion Hazards** — Clutch and speed switch (multiple motor machines)—A damaged clutch or speed switch can permit the low speed motor to engage during extract. This will over-speed the motor and pulleys and can cause them to rip apart, discharging metal fragments at high speed.



- ▶ Stop the machine immediately if any of these conditions occur: • abnormal whining sound during extract • skidding sound as extract ends • clutches remain engaged or re-engage during extract

### 1.3.4.2 Careless Use Hazards

BNWVUS04.C05 0000235127 D.2 A.2 A.3 12/11/20, 8:32 AM Released

#### 1.3.4.2.1 Careless Operation Hazards—Vital Information for Operator Personnel (see also operator hazards throughout manual)

BNWVUS04.C06 0000235126 D.2 A.2 A.4 12/11/20, 8:32 AM Released



**WARNING: Multiple Hazards** — Careless operator actions can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.


- ▶ Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.
- ▶ Do not operate a damaged or malfunctioning machine. Request authorized service.
- ▶ Do not attempt unauthorized servicing, repairs, or modification.
- ▶ Do not use the machine in any manner contrary to the factory instructions.
- ▶ Use the machine only for its customary and intended purpose.
- ▶ Understand the consequences of operating manually.

#### 1.3.4.2.2 Careless Servicing Hazards—Vital Information for Service Personnel (see also service hazards throughout manuals)

BNWVUS04.C07 0000235125 D.2 A.2 A.4 12/11/20, 8:32 AM Released



**WARNING: Electrocution and Electrical Burn Hazards** — Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.



- ▶ Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.
- ▶ Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.



**WARNING: Entangle and Crush Hazards** — Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.



- ▶ Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.
- ▶ Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.



**WARNING: Confined Space Hazards** — Confinement in the cylinder can kill or injure you. Hazards include but are not limited to panic, burns, poisoning, suffocation, heat prostration, biological contamination, electrocution, and crushing.



- ▶ Do not enter the cylinder until it has been thoroughly purged, flushed, drained, cooled, and immobilized.



This page intentionally blank

BPWG6M01 / 2020125

BPWG6M01.1 0000278949 D.2 A.5 3/19/20, 10:13 AM Released


## Safety Placard Use and Placement

2 Sheets

60044SR2, 60044SR3, 72044SR2



**NOTE:** Replace placard immediately, if removed or unreadable. Approximate locations of placards are shown. If aluminum placard, mounting holes are provided on machine. Use #8 self-tapping screws.



## Safety Placard Use and Placement

2 Sheets

60044SR2, 60044SR3, 72044SR2

**Table 2. Parts List—Safety Placard Use and Placement**


| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                               |          |
|---|------|-------------|-------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature      | Comments |
| Components  |      |             |                               |          |
| all   | 10   | 01 10627A   | NPLT:DIV-CYL/STAPH WARN-TCATA |          |
| all   | 20   | 01 10377A   | NPLT:ELEC HAZARD LG-TCATA     |          |
| all   | 30   | 01 10689A   | NPLT:BELT HAZARD SM TCATA     |          |
| all   | 40   | 01 10648A   | NPLT:GEAR HAZARD-TCATA        |          |
| all   | 50   | 01 10685A   | NPLT:BURN HAZARD-TCATA        |          |
| all   | 60   | 01 10699B   | NPLT:SERV HZRD-ALUM-TCATA     |          |

**Safety Placard Use and Placement ISO**

60044SR2, 60044SR3, 72044SR2



**NOTE:** Replace placard immediately, if removed or unreadable. Approximate locations of placards are shown. If aluminum placard, mounting holes are provided on machine. Use #8 self-tapping screws.



## Safety Placard Use and Placement ISO

2 Sheets

60044SR2, 60044SR3, 72044SR2

**Table 3. Parts List—Safety Placard Use and Placement ISO**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| Components  |      |             |                                |          |
| all   | 10   | 01 10627X   | NPLT:DIVCYL SG WARNING FRT ISO |          |
| all   | 20   | 01 10377    | NPLTE:"WARNING" 4X4            |          |
| all   | 30   | 01 10628X   | NPLT:NONTILT W/E WARNING SIDE  |          |
| all   | 40   | 01 10648X   | NPLT:ACTUATED VALVE WARN-ISO   |          |
| all   | 50   | 01 10649X   | NPLT:HOT BEHIND CVR WARN-ISO   |          |

BPWG7M01 / 2020212


BPWG7M01.1 0000292166 D.2 A.3 5/18/20, 3:31 PM Released

**Belt Guards**

3 Sheets

72044SR2

**Figure 1. Soil Side**



**Legend**


- A-A . . Detail view, typical
- B-B . . Detail view, typical
- C-C . . Detail view, typical
- D . . . Inside

**Belt Guards**

3 Sheets

72044SR2

**Figure 2. Clean Side**



**Table 4. Parts List—Belt Guards**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| Reference Assemblies  |      |             |                                |          |
|   | A    | AD 36 027   | BLTGUARD ASSY-SOILSIDE=72"SG   |          |
| Components  |      |             |                                |          |
| all   | 1    | 03 06273    | HOOD COVER=BELTGUARD SS        |          |
| all   | 2    | 03 06274A   | BOTTOM FILLER BELTGRD 72SGSS   |          |
| all   | 3    | 03 06275    | COVER UPPER-BELTGUARD SS       |          |
| all   | 4    | W3 06276    | *BELTGUARD WELDMENT SS         |          |
| all   | 5    | 03 06278    | TOP FILLER=BELTGUARD SS        |          |
| all   | 6    | 03 06279    | BOTTOM WELD COVER SS           |          |
| all   | 7    | 03 06282    | SUPPORT=BOTTOM-BELTGUARD SS    |          |
| all   | 8    | 60C075      | TRUCK BUMPER 2+1/2ODW3/8HO.613 |          |
| all   | 9    | 02 175039   | DRIP SHEILD=BELTGD=60+72 SG    |          |
| all   | 10   | 03 06416    | AUTOSPOT COVER BELTGUARD CS    |          |

**Belt Guards**

3 Sheets

72044SR2

**Table 4 Parts List—Belt Guards (cont'd.)**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| all   | 11   | 03 06269    | RIGHT SIDE J=BELTGUARD SS      |          |
| all   | 12   | 03 06271    | LEFT SIDE J=BELTGUARD SS       |          |
| all   | 13   | 03 06272    | HOOD =BELTGUARD SS             |          |
| all   | 14   | 15K085      | HEXCAPSCR 3/8-16UNC2AX3/4 GR5  |          |
| all   | 15   | 15G205      | HXNUT 3/8-16UNC2B ZINC GR2     |          |
| all   | 16   | 15U255      | LOCKWASHER MEDIUM 3/8 ZINCPL   |          |
| all   | 17   | 15U240      | FLATWASHER(USS STD) 3/8" ZNC P |          |
| all   | 18   | 15P200      | TRDCUT-F HXWASHD 3/8-16X3/4NIK |          |
| all   | 19   | 15K110      | HEXCAPSCR 3/8-16UNC2AX1.5 GR5- |          |
| all   | 20   | 17N071      | NUT J-TYP #C33896-3816-3B 3/8" |          |
| all   | 21   | 15K105      | HXCAPSCR 3/8-16UNC2A1.25 GR5 P |          |
| all   | 22   | W3 06270    | *BELTGUARD=WELD CS             |          |
| all   | 23   | 03 06274    | BOTTOM FILLER BELTGUARD SS     |          |
| all   | 24   | 03 06277    | BELTGUARD WELD COVER CS        |          |
| all   | 25   | 03 06281    | SUPPORT=BOTTOM BELT GUARD      |          |



BNUUUN02 / 2019125


BNUUUN02 0000222452 B.3 1/2/20, 2:14 PM Released

## 1.4 Torque Requirements for Fasteners

BNUUUN02.C01 0000222451 D.2 B.3 A.3 1/2/20, 2:14 PM Released

The document about the assembly gives the torque requirements for other fasteners. **If fastener torque specifications or threadlocker requirements in an assembly document are different from this document, use the assembly document.**

**Figure 3. The Bolts in Milnor® Equipment**

| The Marks on Bolt Heads   | Legend   |
|---|--|
|  | <p><b>A</b> . . . SAE Grades 1 and 2, ASTM A307, and stainless steel</p> <p><b>B</b> . . . Grade BC, ASTM A354</p> <p><b>C</b> . . . SAE Grade 5, ASTM A449</p> <p><b>D</b> . . . SAE Grade 8 and ASTM A354 BD</p> |

### 1.4.1 Torque Values

BNUUUN02.C02 0000222449 D.2 B.3 A.3 1/2/20, 2:14 PM Released

These tables give the standard dimension, grade, threadlocker, and torque requirements for fasteners frequently used on Milnor® equipment.



**NOTE:** Data from the Pellerin Milnor® Corporation “Bolt Torque Specification” (bolt\_torque\_milnor.xls/2002096).

#### 1.4.1.1 Fasteners Made of Carbon Steel

BNUUUN02.C03 0000222448 D.2 B.3 A.3 1/2/20, 2:14 PM Released

##### 1.4.1.1.1 Without a Threadlocker

BNUUUN02.C04 0000222447 D.2 B.3 A.3 1/2/20, 2:14 PM Released

**Table 5. Torque Values for Standard Fasteners with Maximum 5/16-inch Diameters and No Lubricant**

| Dimension | The Grade of the Bolt |     |              |     |              |     |              |     |
|-----------|-----------------------|-----|--------------|-----|--------------|-----|--------------|-----|
|           | Grade 2               |     | Grade 5      |     | Grade 8      |     | Grade BC     |     |
|           | Pound-Inches          | N-m | Pound-Inches | N-m | Pound-Inches | N-m | Pound-Inches | N-m |
| 1/4 x 20  | 66                    | 7   | 101          | 11  | 143          | 16  | 126          | 14  |
| 1/4 x 28  | 76                    | 9   | 116          | 13  | 163          | 18  | –            | –   |
| 5/16 x 18 | 136                   | 15  | 209          | 24  | 295          | 33  | 258          | 29  |
| 5/16 x 24 | 150                   | 17  | 232          | 26  | 325          | 37  | –            | –   |

**Table 6. Torque Values for Standard Fasteners Larger Than 5/16-inch Diameters and No Lubricant**

| Dimension  | The Grade of the Bolt |      |            |      |            |      |            |      |
|------------|-----------------------|------|------------|------|------------|------|------------|------|
|            | Grade 2               |      | Grade 5    |      | Grade 8    |      | Grade BC   |      |
|            | Pound-Feet            | N-m  | Pound-Feet | N-m  | Pound-Feet | N-m  | Pound-Feet | N-m  |
| 3/8 x 16   | 20                    | 27   | 31         | 42   | 44         | 59   | 38         | 52   |
| 3/8 x 24   | 23                    | 31   | 35         | 47   | 50         | 68   | –          | –    |
| 7/16 x 14  | 32                    | 43   | 49         | 66   | 70         | 95   | 61         | 83   |
| 7/16 x 20  | 36                    | 49   | 55         | 75   | 78         | 105  | –          | –    |
| 1/2 x 13   | 49                    | 66   | 75         | 102  | 107        | 145  | 93         | 126  |
| 1/2 x 20   | 55                    | 75   | 85         | 115  | 120        | 163  | –          | –    |
| 9/16 x 12  | 70                    | 95   | 109        | 148  | 154        | 209  | 134        | 182  |
| 9/16 x 18  | 78                    | 106  | 121        | 164  | 171        | 232  | –          | –    |
| 5/8 x 11   | 97                    | 131  | 150        | 203  | 212        | 287  | 186        | 252  |
| 5/8 x 18   | 110                   | 149  | 170        | 231  | 240        | 325  | –          | –    |
| 3/4 x 10   | 172                   | 233  | 266        | 361  | 376        | 510  | 329        | 446  |
| 3/14 x 16  | 192                   | 261  | 297        | 403  | 420        | 569  | –          | –    |
| 7/8 x 9    | 167                   | 226  | 429        | 582  | 606        | 821  | 531        | 719  |
| 7/8 x 14   | 184                   | 249  | 473        | 641  | 668        | 906  | –          | –    |
| 1 x 8      | 250                   | 339  | 644        | 873  | 909        | 1232 | 796        | 1079 |
| 1 x 12     | 274                   | 371  | 704        | 954  | 994        | 1348 | –          | –    |
| 1 x 14     | 281                   | 381  | 723        | 980  | 1020       | 1383 | –          | –    |
| 1 1/8 x 7  | 354                   | 480  | 794        | 1077 | 1287       | 1745 | 1126       | 1527 |
| 1 1/8 x 12 | 397                   | 538  | 891        | 1208 | 1444       | 1958 | –          | –    |
| 1 1/4 x 7  | 500                   | 678  | 1120       | 1519 | 1817       | 2464 | 1590       | 2155 |
| 1 1/4 x 12 | 553                   | 750  | 1241       | 1682 | 2012       | 2728 | –          | –    |
| 1 3/8 x 6  | 655                   | 888  | 1469       | 1992 | 2382       | 3230 | 2085       | 2827 |
| 1 3/8 x 12 | 746                   | 1011 | 1672       | 2267 | 2712       | 3677 | –          | –    |
| 1 1/2 x 6  | 869                   | 1178 | 1949       | 2642 | 3161       | 4286 | 2767       | 3751 |
| 1 1/2 x 12 | 979                   | 1327 | 2194       | 2974 | 3557       | 4822 | –          | –    |

**Table 7. Torque Values for Plated Fasteners with Maximum 5/16-inch Diameters and No Lubricant**

| Dimension | The Grade of the Bolt |     |              |     |              |     |              |     |
|-----------|-----------------------|-----|--------------|-----|--------------|-----|--------------|-----|
|           | Grade 2               |     | Grade 5      |     | Grade 8      |     | Grade BC     |     |
|           | Pound-Inches          | N-m | Pound-Inches | N-m | Pound-Inches | N-m | Pound-Inches | N-m |
| 1/4 x 20  | 49                    | 6   | 76           | 9   | 107          | 12  | 95           | 11  |
| 1/4 x 28  | 56                    | 6   | 88           | 10  | 122          | 14  | –            | –   |
| 5/16 x 18 | 102                   | 12  | 156          | 18  | 222          | 25  | 193          | 22  |
| 5/16 x 24 | 113                   | 13  | 174          | 20  | 245          | 28  | –            | –   |

**Table 8. Torque Values for Plated Fasteners Larger Than 5/16-inch Diameters and No Lubricant**

| Dimension  | The Grade of the Bolt |     |            |      |            |      |            |      |
|------------|-----------------------|-----|------------|------|------------|------|------------|------|
|            | Grade 2               |     | Grade 5    |      | Grade 8    |      | Grade BC   |      |
|            | Pound-Feet            | N-m | Pound-Feet | N-m  | Pound-Feet | N-m  | Pound-Feet | N-m  |
| 3/8 x 16   | 15                    | 20  | 23         | 31   | 33         | 44   | 29         | 38   |
| 3/8 x 24   | 17                    | 23  | 26         | 35   | 37         | 49   | –          | –    |
| 7/16 x 14  | 24                    | 32  | 37         | 50   | 52         | 71   | 46         | 61   |
| 7/16 x 20  | 27                    | 36  | 41         | 55   | 58         | 78   | –          | –    |
| 1/2 x 13   | 37                    | 49  | 56         | 76   | 80         | 106  | 70         | 93   |
| 1/2 x 20   | 41                    | 55  | 64         | 85   | 90         | 120  | –          | –    |
| 9/16 x 12  | 53                    | 70  | 81         | 110  | 115        | 153  | 101        | 134  |
| 9/16 x 18  | 59                    | 79  | 91         | 122  | 128        | 174  | –          | –    |
| 5/8 x 11   | 73                    | 97  | 113        | 150  | 159        | 212  | 139        | 186  |
| 5/8 x 18   | 83                    | 110 | 127        | 172  | 180        | 240  | –          | –    |
| 3/4 x 10   | 129                   | 173 | 200        | 266  | 282        | 376  | 246        | 329  |
| 3/4 x 16   | 144                   | 192 | 223        | 297  | 315        | 420  | –          | –    |
| 7/8 x 9    | 125                   | 166 | 322        | 430  | 455        | 606  | 398        | 531  |
| 7/8 x 14   | 138                   | 184 | 355        | 474  | 501        | 668  | –          | –    |
| 1 x 8      | 188                   | 250 | 483        | 644  | 682        | 909  | 597        | 796  |
| 1 x 12     | 205                   | 274 | 528        | 716  | 746        | 995  | –          | –    |
| 1 x 14     | 210                   | 280 | 542        | 735  | 765        | 1037 | –          | –    |
| 1 1/8 x 7  | 266                   | 354 | 595        | 807  | 966        | 1288 | 845        | 1126 |
| 1 1/8 x 12 | 298                   | 404 | 668        | 890  | 1083       | 1444 | –          | –    |
| 1 1/4 x 7  | 375                   | 500 | 840        | 1120 | 1363       | 1817 | 1192       | 1590 |
| 1 1/4 x 12 | 415                   | 553 | 930        | 1261 | 1509       | 2013 | –          | –    |
| 1 3/8 x 6  | 491                   | 655 | 1102       | 1470 | 1787       | 2382 | 1564       | 2085 |
| 1 3/8 x 12 | 559                   | 758 | 1254       | 1672 | 2034       | 2712 | –          | –    |
| 1 1/2 x 6  | 652                   | 870 | 1462       | 1982 | 2371       | 3161 | 2075       | 2767 |
| 1 1/2 x 12 | 733                   | 994 | 1645       | 2194 | 2668       | 3557 | –          | –    |

**1.4.1.1.2 With a Threadlocker**

BNUUUN02.C05 0000222446 D.2 B.3 A.3 1/2/20, 2:14 PM Released

**Table 9. Threadlocker by the Diameter of the Bolt (see below Note )**

| LocTite Product | Dimension |                  |                  |                  |
|-----------------|-----------|------------------|------------------|------------------|
|                 | 1/4-inch  | 1/4- to 5/8-inch | 5/8- to 7/8-inch | 1-inch +         |
| LocTite 222     | OK        |                  |                  |                  |
| LocTite 242     |           |                  | OK               |                  |
| LocTite 262     |           |                  |                  | OK               |
| LocTite 272     |           |                  |                  | High temperature |
| LocTite 277     |           |                  |                  | OK               |



**NOTE:** The acceptable bolt size ranges for various LocTite® threadlocking products is the LocTite manufacturer’s **general** recommendation. Specific applications sometime require that a LocTite product is applied to a bolt size outside the ranges shown here. For example, Milnor® specifies LocTite 242 for use on certain 1" bolt applications and has confirmed this usage with the LocTite manufacturer. You may see variances such as this in the documentation for specific machine assemblies.

**Table 10. Torque Values if You Apply LocTite 222**

| Dimension | The Grade of the Bolt |     |              |     |              |     |              |     |
|-----------|-----------------------|-----|--------------|-----|--------------|-----|--------------|-----|
|           | Grade 2               |     | Grade 5      |     | Grade 8      |     | Grade BC     |     |
|           | Pound-Inches          | N-m | Pound-Inches | N-m | Pound-Inches | N-m | Pound-Inches | N-m |
| 1/4 x 20  | 60                    | 7   | 96           | 11  | 132          | 15  | 108          | 12  |
| 1/4 x 28  | 72                    | 8   | 108          | 12  | 144          | 16  | –            | –   |

**Table 11. Torque Values if You Apply LocTite 242**

| Dimension | The Grade of the Bolt |     |            |     |            |     |            |     |
|-----------|-----------------------|-----|------------|-----|------------|-----|------------|-----|
|           | Grade 2               |     | Grade 5    |     | Grade 8    |     | Grade BC   |     |
|           | Pound-Feet            | N-m | Pound-Feet | N-m | Pound-Feet | N-m | Pound-Feet | N-m |
| 5/16 x 18 | 11                    | 15  | 17         | 23  | 25         | 34  | 22         | 30  |
| 5/16 x 24 | 13                    | 18  | 19         | 26  | 27         | 37  | 27         | 37  |
| 3/8 x 16  | 20                    | 27  | 31         | 42  | 44         | 60  | 38         | 52  |
| 3/8 x 24  | 23                    | 31  | 35         | 47  | 50         | 68  | –          | –   |
| 7/16 x 14 | 32                    | 43  | 49         | 66  | 70         | 95  | 61         | 83  |
| 7/16 x 20 | 36                    | 49  | 55         | 75  | 78         | 106 | –          | –   |
| 1/2 x 13  | 49                    | 66  | 75         | 102 | 107        | 145 | 93         | 126 |
| 1/2 x 20  | 55                    | 75  | 85         | 115 | 120        | 163 | –          | –   |
| 9/16 x 12 | 70                    | 95  | 109        | 148 | 154        | 209 | 134        | 182 |
| 9/16 x 18 | 78                    | 106 | 121        | 164 | 171        | 232 | –          | –   |
| 5/8 x 11  | 97                    | 132 | 150        | 203 | 212        | 287 | 186        | 252 |
| 5/8 x 18  | 110                   | 149 | 170        | 230 | 240        | 325 | –          | –   |

**Table 12. Torque Values if You Apply LocTite 262**

| Dimension | The Grade of the Bolt |     |            |     |            |     |            |     |
|-----------|-----------------------|-----|------------|-----|------------|-----|------------|-----|
|           | Grade 2               |     | Grade 5    |     | Grade 8    |     | Grade BC   |     |
|           | Pound-Feet            | N-m | Pound-Feet | N-m | Pound-Feet | N-m | Pound-Feet | N-m |
| 3/4 x 10  | 155                   | 210 | 240        | 325 | 338        | 458 | 296        | 401 |
| 3/4 x 16  | 173                   | 235 | 267        | 362 | 378        | 512 | –          | –   |
| 7/8 x 9   | 150                   | 203 | 386        | 523 | 546        | 740 | 477        | 647 |
| 7/8 x 14  | 165                   | 224 | 426        | 578 | 601        | 815 | –          | –   |

**Table 13. Torque Values if You Apply LocTite 272 (High-Temperature)**

| Dimension | The Grade of the Bolt |     |            |      |            |      |            |      |
|-----------|-----------------------|-----|------------|------|------------|------|------------|------|
|           | Grade 2               |     | Grade 5    |      | Grade 8    |      | Grade BC   |      |
|           | Pound-Feet            | N-m | Pound-Feet | N-m  | Pound-Feet | N-m  | Pound-Feet | N-m  |
| 1 x 8     | 350                   | 475 | 901        | 1222 | 1272       | 1725 | 1114       | 1510 |
| 1 x 12    | 383                   | 519 | 986        | 1337 | 1392       | 1887 | –          | –    |

**Table 13 Torque Values if You Apply LocTite 272 (High-Temperature) (cont'd.)**

| Dimension  | The Grade of the Bolt |      |            |      |            |      |            |      |
|------------|-----------------------|------|------------|------|------------|------|------------|------|
|            | Grade 2               |      | Grade 5    |      | Grade 8    |      | Grade BC   |      |
|            | Pound-Feet            | N-m  | Pound-Feet | N-m  | Pound-Feet | N-m  | Pound-Feet | N-m  |
| 1 x 14     | 393                   | 533  | 1012       | 1372 | 1428       | 1936 | –          | –    |
| 1-1/8 x 7  | 496                   | 672  | 1111       | 1506 | 1802       | 2443 | 1577       | 2138 |
| 1-1/8 x 12 | 556                   | 754  | 1247       | 1691 | 2022       | 2741 | –          | –    |
| 1-1/4 x 7  | 700                   | 949  | 1568       | 2126 | 2544       | 3449 | 2226       | 3018 |
| 1-1/4 x 12 | 774                   | 1049 | 1737       | 2355 | 2816       | 3818 | –          | –    |
| 1-3/8 x 6  | 917                   | 1243 | 2056       | 2788 | 3335       | 4522 | 2919       | 3958 |
| 1-3/8 x 12 | 1044                  | 1415 | 2341       | 3174 | 3797       | 5148 | –          | –    |
| 1-1/2 x 6  | 1217                  | 1650 | 2729       | 3700 | 4426       | 6001 | 3873       | 5251 |
| 1-1/2 x 12 | 1369                  | 1856 | 3071       | 4164 | 4980       | 6752 | –          | –    |

**Table 14. Torque Values if You Apply LocTite 277**

| Dimension  | The Grade of the Bolt |      |            |      |            |      |            |      |
|------------|-----------------------|------|------------|------|------------|------|------------|------|
|            | Grade 2               |      | Grade 5    |      | Grade 8    |      | Grade BC   |      |
|            | Pound-Feet            | N-m  | Pound-Feet | N-m  | Pound-Feet | N-m  | Pound-Feet | N-m  |
| 1 x 8      | 325                   | 441  | 837        | 1135 | 1181       | 1601 | 1034       | 1402 |
| 1 x 12     | 356                   | 483  | 916        | 1242 | 1293       | 1753 | –          | –    |
| 1 x 14     | 365                   | 495  | 939        | 1273 | 1326       | 1798 | –          | –    |
| 1-1/8 x 7  | 461                   | 625  | 1032       | 1399 | 1674       | 2270 | 1464       | 1985 |
| 1-1/8 x 12 | 516                   | 700  | 1158       | 1570 | 1877       | 2545 | –          | –    |
| 1-1/4 x 7  | 650                   | 881  | 1456       | 1974 | 2362       | 3202 | 2067       | 2802 |
| 1-1/4 x 12 | 719                   | 975  | 1613       | 2187 | 2615       | 3545 | –          | –    |
| 1-3/8 x 6  | 851                   | 1154 | 1909       | 2588 | 3097       | 4199 | 2710       | 3674 |
| 1-3/8 x 12 | 970                   | 1315 | 2174       | 2948 | 3526       | 4781 | –          | –    |
| 1-1/2 x 6  | 1130                  | 1532 | 2534       | 3436 | 4110       | 5572 | 3597       | 4877 |
| 1-1/2 x 12 | 1271                  | 1723 | 2852       | 3867 | 4624       | 6269 | –          | –    |

### 1.4.1.2 Stainless Steel Fasteners

BNUUUN02.C06 0000222445 D.2 B.3 A.3 1/2/20, 2:14 PM Released

**Table 15. Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller**

| Dimension | 316 Stainless |     | 18-8 Stainless |     | 18-8 Stainless with Loctite 767 |     |
|-----------|---------------|-----|----------------|-----|---------------------------------|-----|
|           | Pound-Inches  | N-m | Pound-Inches   | N-m | Pound-Inches                    | N-m |
| 1/4 x 20  | 79            | 9   | 76             | 9   | 45                              | 5   |
| 1/4 x 28  | 100           | 11  | 94             | 11  | 56                              | 6   |
| 5/16 x 18 | 138           | 16  | 132            | 15  | 79                              | 9   |
| 5/16 x 24 | 148           | 17  | 142            | 16  | 85                              | 10  |

**Table 16. Torque Values for Stainless Steel Fasteners Larger Than 5/16-inch**

| Dimension  | 316 Stainless |      | 18-8 Stainless |      | 18-8 Stainless with Loctite 767 |     |
|------------|---------------|------|----------------|------|---------------------------------|-----|
|            | Pound-Feet    | N-m  | Pound-Feet     | N-m  | Pound-Feet                      | N-m |
| 3/8 x 16   | 21            | 28   | 20             | 27   | 12                              | 16  |
| 3/8 x 24   | 23            | 31   | 22             | 29   | 13                              | 18  |
| 7/16 x 14  | 33            | 44   | 31             | 42   | 19                              | 25  |
| 7/16 x 20  | 35            | 47   | 33             | 45   | 20                              | 27  |
| 1/2 x 13   | 45            | 61   | 43             | 58   | 26                              | 35  |
| 1/2 x 20   | 47            | 64   | 45             | 61   | 27                              | 37  |
| 9/16 x 12  | 59            | 81   | 57             | 77   | 34                              | 46  |
| 9/16 x 18  | 66            | 89   | 63             | 85   | 38                              | 51  |
| 5/8 x 11   | 97            | 131  | 93             | 125  | 56                              | 75  |
| 5/8 x 18   | 108           | 150  | 104            | 141  | 62                              | 84  |
| 3/4 x 10   | 132           | 179  | 128            | 173  | 77                              | 104 |
| 3/4 x 16   | 130           | 176  | 124            | 168  | 75                              | 101 |
| 7/8 x 9    | 203           | 275  | 194            | 263  | 116                             | 158 |
| 7/8 x 14   | 202           | 273  | 193            | 262  | 116                             | 157 |
| 1 x 8      | 300           | 406  | 287            | 389  | 172                             | 233 |
| 1 x 14     | 271           | 367  | 259            | 351  | 156                             | 211 |
| 1-1/8 x 7  | 432           | 586  | 413            | 560  | 248                             | 336 |
| 1-1/8 x 12 | 408           | 553  | 390            | 529  | 234                             | 317 |
| 1-1/4 x 7  | 546           | 740  | 523            | 709  | 314                             | 425 |
| 1-1/4 x 12 | 504           | 683  | 480            | 651  | 288                             | 390 |
| 1-1/2 x 6  | 930           | 1261 | 888            | 1204 | 533                             | 722 |
| 1-1/2 x 12 | 732           | 992  | 703            | 953  | 422                             | 572 |

## 1.4.2 Preparation

BNUUUN02.T01 0000222511 D.2 B.3 B.2 4/20/23, 9:05 AM Released



**WARNING: Fire Hazard** — Some solvents and primers are flammable.



- ▶ Use threadlocker and primers with sufficient airflow.
- ▶ Do not use flammable material near ignition sources.

1. Clean all threads with a wire brush or a different tool.
2. Remove the grease from the fasteners and the mating threads with solvent. Make the parts dry.



**NOTE:** Loctite 7649 Primer™ or standard solvents will remove grease from parts.


3. Apply a spray of LocTite 7649 Primer™ or equal on the fasteners and the mating threads. Let the primer dry for one minute minimum.

### 1.4.3 How to Apply a Threadlocker

BNUUUN02.T02 0000222508 D.2 B.3 B.2 4/20/23, 9:09 AM Released




**CAUTION: Malfunction Hazard** — Heat, vibration, or mechanical shocks can let the fasteners loosen if you do not apply the threadlocker correctly. Loose fasteners can cause malfunctions of the equipment.



- Read the threadlocker manufacturer's instructions and warnings. Obey these instructions.

Apply the threadlocker only to the areas where the fastener threads and the mating threads engage.

**Figure 4. Apply Threadlocker in a Blind Hole**



#### 1.4.3.1 Blind Holes

BNUUUN02.T03 0000222507 D.2 B.3 A.3 1/2/20, 2:14 PM Released

1. Apply the threadlocker down the threads to the bottom of the hole.
2. Apply the threadlocker to the bolt.
3. Tighten the bolt to the value shown in the correct table ([Table 9: Threadlocker by the Diameter of the Bolt](#) (see below Note ), page 25 to [Table 15: Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller](#), page 27 ).


#### 1.4.3.2 Through Holes

BNUUUN02.T04 0000222506 D.2 B.3 A.3 11/26/19, 2:51 PM Released

1. Put the bolt through the assembly.
2. Apply the threadlocker only to the bolt thread area that will engage the nut.

- Tighten the bolt to the value shown in the correct table ([Table 9: Threadlocker by the Diameter of the Bolt](#) (see below Note ), page 25 to [Table 15: Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller](#), page 27 ).

**Figure 5. Apply Threadlocker in a Through Hole**




### 1.4.3.3 Disassembly

BNUUUN02.C07 0000222444 D.2 B.3 A.3 11/26/19, 2:59 PM Released

For high-strength threadlocker, apply heat for five minutes. Disassemble with hand tools while the parts are hot.

For low-strength and moderate-strength threadlocker, disassemble with hand tools.

**Figure 6. Use heat for disassembly of fasteners with threadlocker.**






# 2 Drive Assemblies

## 2.1 Drive Pulley and Belt Maintenance

Figure 7. Examples of drives this instruction applies to: one or more V-belts, attached V-belts and tooth belts



**NOTICE:** "Remove power from the machine" means use the necessary safety procedure for your location. In the USA, this is the OSHA lockout/tagout (LOTO) procedure. More local requirements can also apply.



**WARNING: Risk of Injury or death** — A machine in operation without safety guards is dangerous. Drive belts can pull in your body or clothing.



- ▶ Remove power from the machine when you do work on the mechanisms.
- ▶ Stay out of the machine frame when you do a test on the machine.
- ▶ Replace all covers before you put the machine into operation.



**TIP:** Read these documents from the Gates Corporation ([www.gates.com](http://www.gates.com)) to know more about pulley and belt maintenance: "Belt Drive Preventive Maintenance & Safety Manual" and "Preserve your investment - Check Engine Belts Often."

### 2.1.1 Pulley Requirements

- Keep pulleys free of dirt, oil and other contamination.
- Replace pulleys with groove damage.
- Align pulleys and shafts.
- Keep run-out in tolerance.


### 2.1.1.1 Condition of Grooves on Pulleys

BNUUUM02.C03 0000274611 D.2 B.2 A.2 2/4/20, 8:08 AM Released

Replace a pulley if:

- the grooves have burrs, cracks, or worn areas that can cause damage to the belts.
- the belts touch the bottom of the groove at any point (Figure 8, page 32).

**Figure 8. Pulley Groove Condition**




### 2.1.1.2 Pulley and Shaft Position

BNUUUM02.C04 0000274609 D.2 B.2 A.2 2/4/20, 8:08 AM Released

**Align** To adjust parts until they are in a correct position to other parts.

- Always align components when you replace a motor, bearing housing, pulley, or belt.
- The belts must not twist or make unusual noises or show vibration.

Figure 9. Pulley and Shaft Position




### 2.1.1.3 Keep Run-Out in Tolerance

BNUUUM02.C05 0000274606 D.2 B.2 A.2 2/4/20, 8:08 AM Released


**Axial run-out** The difference between the minimum and maximum distance between the face of a pulley and a plane perpendicular to the pulley shaft (Figure 10, page 34, item 1). Incorrect installation or damage can cause a pulley to be not at a 90 degree angle to the shaft.

**Radial run-out** The difference between the minimum and maximum diameter in one turn (Figure 10, page 34, item 2). If a force causes damage to a pulley, it can bend. It will not have a circular shape.

**Figure 10. Run-out**



**Figure 11. Typical Pulley Assembly**



## 2.1.2 Belt Requirements


BNUUUM02.C06 0000274605 D.2 B.2 A.2 2/4/20, 8:08 AM Released

- Replace damaged belts.
- The pulleys must stay aligned when you adjust the belt tension.
- Do not use belts made from cut belts.

- For a drive with more than one belt:
  - Replace all of the belts together.
  - Do not mix new and used belts.
  - Do not mix belts from more than one manufacturer.



**CAUTION:** Risk of damage — A screwdriver or metal tool can cause damage to the belt.



- ▶ Do not push the belt on with a tool.

### 2.1.2.1 Condition of Belts

BNUUUM02.C07 0000274604 D.2 B.2 A.2 2/4/20, 8:08 AM Released

**Slippage** when the pulley turns more quickly than the belt can move

Slippage occurs if belts are not aligned (see [Section 2.1.1.2](#), page 32) or by incorrect tension explained in [Section 2.1.1.2](#), page 32. Slippage can cause belts to become too hot. Belts must not have a temperature more than than 140F (60° C).




**TIP:** The belt storage area must be cool and dry with no sun light.



**TIP:** New and used belts can look the same. These belts will have different strength properties and a small difference in length.

**Figure 12. Types of Belt Damage**



### 2.1.2.2 Tension of Belts

BNUUUM02.C08 0000274657 D.2 B.2 A.2 2/4/20, 8:08 AM Released

This data does not apply to belts where a spring holds the correct belt tension. Manual tension adjustment is not necessary for this type of drive.

**The correct belt tension is the lowest tension that prevents belt slippage with a full load condition.** If the belt is too tight, this can cause damage to the belt, the pulleys, bearings, and other drive components. If the belt is too loose, this can cause belt slippage. Incorrect belt tension or belt slippage can cause components to make an unusual noise.

When you install a new belt, use these rules to get the correct belt tension:

- Set the tension of the belt when you replace a motor, bearing housing, pulley, or belt.
- Replace all belts on a pair of pulleys when you replace one of them.
- After adjustment, operate the machine in all of its standard conditions to make sure that the belt operates correctly. For example, operate a washer-extractor in its full speed range with a full load of wet goods.
- Adjust the tension when you first install a belt. Do the adjustment again after 24 and 48 hours of operation. All belts will become longer after a short time. A V-belt will move down in the grooves of the pulleys. These conditions will cause the tension to decrease.

When you do scheduled maintenance, examine the belts for correct tension. With operation, belts become longer.

### 2.1.3 The pulleys must stay aligned when you adjust the belt tension


BNUUUM02.C09 0000274654 D.2 B.2 A.2 2/4/20, 8:08 AM Released

Some tension mechanisms do not have an effect on pulley and shaft requirements. Pulleys will stay aligned when you adjust them. [Figure 13, page 37](#) is an example of these. Where tension mechanisms are a pair of threaded rods, you must adjust the nut, on each rod carefully. If not, the pulleys will not stay aligned. Examples of this type are shown in [Figure 14, page 37](#).

**Figure 13. A Tension Mechanism that will not Change the Angle of the Pulleys**



**Figure 14. Some Pairs of Tension Mechanisms that Can Change the Angle of the Pulleys**



## 2.1.4 How to Do Maintenance on Pulleys and Belts

BNUUUM02.C10 0000274653 D.2 B.2 8/23/23, 9:45 AM Released

**Table 17. Typical Tools for Pulley and Belt Maintenance**

| Tool                            | Function   | Related Data  |
|---------------------------------|--|---|
| Torque wrench                   | Make the bushing bolts the same torque to get the minimum axial run-out. | Figure 11, page 34, item 2  |
| Laser, straight edge, or string | Align pulleys  | Tools are listed in order of preference. Section 2.1.1.2 , page 32 and Figure 15, page 39 |
| Bubble level                    | Align shafts   | Section 2.1.1.2 , page 32 and Figure 16, page 40  |
| Dial indicator                  | Measure run-out  | Section 2.1.1.3 , page 33 and Figure 17, page 40  |

**Table 17 Typical Tools for Pulley and Belt Maintenance (cont'd.)**

| Tool                 | Function                 | Related Data                               |
|----------------------|--------------------------|--|
| Sheave (pulley) gage | Examine pulley wear      | <a href="#">Figure 8, page 32.</a>         |
| Infrared thermometer | Examine belt temperature | <a href="#">Section 2.1.2.1 , page 35.</a> |

### 2.1.4.1 Typical Steps to Replace Pulleys and Belts

BNUUUM02.C11 0000274652 D.2 B.2 A.2 2/4/20, 8:08 AM Released

**Preparation** Remove power from the machine.

**Belt removal** Use the belt tension mechanism to decrease the distance between the pulleys until you have sufficient clearance. [Figure 13, page 37](#) and [Figure 14, page 37](#) show typical belt tension mechanisms.

**Pulley removal** On the typical type of pulley and bushing shown in [Figure 11, page 34](#), use the push-off holes to remove the pulley easily. On special types of pulleys (example: large drive pulley and cone), look at the parts document in the maintenance manual for more data. Some pulleys are too heavy for only one person to hold.

**Pulley installation** [Figure 11, page 34](#) shows the typical pulley and bushing components. Make sure that you keep run-out tolerances when you assemble and tighten the components.

**Belt installation** Decrease the distance between the pulleys to put the belt on easily. Assemble the components carefully. Make sure that the components are aligned. Adjust the belt tension so the belt is tight.


**Test** Before you connect power again, make sure that you remove all tools. Operate the machine with a full load. If the belts slip, increase belt tension with the machine shut down and power removed. Then test again. Make sure that the machine is safe before you put it into regular operation.




## 2.1.4.2 Examples of Procedures Used at the Milnor® Factory to Align Pulleys

BNUUUM02.C12 0000274686 D.2 B.2 A.3 3/6/20, 4:49 PM Released


**Figure 15.** Use a straight edge, a string, or a laser to make sure that all pulleys are in the same plane.



**Figure 16. Use a level to make sure that the pulleys are at the same slope.**



**Figure 17. Dial indicator used to find the axial and radial run-out of a pulley.**



BNWUUM03 / 2020125

BNWUUM03 0000277540 A.7 3/19/20, 8:51 AM Released

## 2.2 Disk Brake Maintenance

BNWUUM03.C01 0000277539 D.2 A.7 A.2 2/27/20, 1:48 PM Released



**NOTICE:** "Remove power from the machine" means use the necessary safety procedure for your location. In the USA, this is the OSHA lockout/tagout (LOTO) procedure. More local requirements can also apply.

You can do these types of maintenance on the disk brake:

- do an inspection of the brake as specified in the maintenance schedule,
- replace the friction pads,

- do an overhaul on the calipers,
- replace the hydraulic fluid,
- adjust the connection between the brake cylinder and the air cylinder.

For the first four types of maintenance, you must remove air from (bleed) the hydraulic circuit.

[Section 2.2.6 : Operation of Brake Systems, page 52](#) tells how to operate the disk brakes. You can use it in some of the types of maintenance in this procedure.



**WARNING: Risk of injury or death** — A machine in operation without safety guards is dangerous.




- ▶ You must be an approved maintenance technician.
- ▶ Use special caution when this instruction tells you to do work with electrical power on. Remove power from the machine for all other maintenance. Obey safety codes.
- ▶ Replace all guards and covers.




**TIP:** During parts of this procedure when you open up the calipers or hydraulic lines, put a cloth under the calipers to catch hydraulic fluid and parts that will fall. For safety, fully remove spilled hydraulic fluid after brake maintenance. This will help you easily identify leaks.

**Figure 18. A typical hydraulic brake system**



A typical hydraulic brake system (cont'd.)



### 2.2.1 The Inspection of the Brake

BNWUUM03.T01 0000277536 D.2.A.7 A.3 3/17/20, 11:57 AM Released



**NOTE:** The brakes shown in this document can look different from your equipment.



**NOTE:** Do this inspection when the maintenance schedule tells it is necessary. Do this inspection after you replace friction pads or do a caliper overhaul.

1. Examine the fluid in the reservoir. Change the hydraulic fluid if it smells, has contamination, or has an unusual color. See [Section 2.2.4 : How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit](#) , page 46.



**NOTE:** Brake fluid can become defective from heat in the brake system. Brake fluid absorbs water from air. Water in the brake system causes corrosion.

If necessary, add new DOT 3 fluid to 0.25 inch (6.35 millimeters) from the top of the reservoir. Follow the precautions on the container.

2. Examine the rotor disk surface ([Figure 18: A typical hydraulic brake system, page 41](#) , item 5). Replace the disk if it is worn or if it is not flat.
3. Examine the brake pads ([Figure 19: The Caliper Components, page 45](#) , item 4). To do this, you will remove/replace the calipers and bleed the hydraulic system. See [Section 2.2.3 : How](#)

to [Do a Caliper Overhaul, page 45](#) and [Section 2.2.4 : How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit , page 46](#).

- a. **Remove power from the machine (see above notice).**
  - b. Remove the bolts ([Figure 18, page 41, item 9](#)) that attach the caliper halves ([Figure 18, page 41, item 7](#)).
  - c. Remove the caliper halves.
  - d. Replace the pads as told in [Section 2.2.2 : How to Do a Friction Pad Replacement, page 43](#) if
    - the pads make an unusual noise when you apply the brake
    - if the rotor is worn or damaged
    - if the pad thickness is less than 1/16 inches (2 mm) ([Figure 19, page 45, item 14](#)) above the mounting screw ([Figure 19, page 45, item 3](#)). Always replace the two brake pads at the same time.
  - e. Put the caliper halves in their positions on the brake assembly. Tighten the mounting bolts to 30 foot-pounds (41 Newton-meters).
  - f. Bleed the hydraulic systems as told in [Section 2.2.4 : How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit , page 46](#).
  - g. Supply electrical power to the machine.
4. Examine the condition of all of the brake system.
- a. Make sure that brake mounting components are tightly installed.
  - b. Make sure that fittings are tight. Make sure that there are no leaks.

## 2.2.2 How to Do a Friction Pad Replacement

BNWUUM03.T02 0000277566 D.2 A.7 A.5 3/17/20, 11:57 AM Released

You must have the necessary replacement friction pads for your machine. Refer to the brake parts document in your machine manual. You will find part numbers for components or overhaul/repair kits. The overhaul/repair kit contains O-rings, pads, and other components.

1. **Remove power from the machine (see above notice).**
2. Remove the used fluid. See [Section 2.2.4 : How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit , page 46](#).
3. Remove the two bolts that attach the caliper ([Figure 18, page 41, item 9](#)) and the two caliper halves ([Figure 18, page 41, item 3](#)) to get access to the friction pads. Do not disconnect the hydraulic line ([Figure 18, page 41, item 6](#)).
4. If there are leaks, see [Section 2.2.3 : How to Do a Caliper Overhaul, page 45](#) before you continue.
5. Replace each friction pad:
  - a. Remove the brass screw ([Figure 19, page 45, item 3](#)) that attaches the pad to the piston.
  - b. Attach the new pad to the piston. Tighten the screw.
  - c. Make sure that the screw head is fully in the recess in the pad.

6. Make sure that the connection o-rings are clean and in their positions ([Figure 19, page 45, item 7](#)).
7. Put the caliper halves in their positions on the brake assembly. Tighten the mounting bolts to 30 foot-pounds (41 Newton-meters).
8. Bleed the brake. See [Section 2.2.4 : How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit , page 46](#).
9. Supply electrical power to the machine.

## 2.2.3 How to Do a Caliper Overhaul

BNWUUM03.T03 0000277561 D.2 A.7 A.3 3/17/20, 11:57 AM Released

Figure 19. The Caliper Components

|  |  |
|--|--|
| <p><b>The Expanded View (Shows the Piston and the O-rings)</b></p>  | <p><b>Legend</b></p> <ol style="list-style-type: none"> <li>1. The bolts to attach the caliper (Figure 18, page 41, item 9)</li> <li>2. Caliper body halves (Figure 18, page 41, item 3)</li> <li>3. Brass screw</li> <li>4. Friction pad</li> <li>5. Piston</li> <li>6. The Piston O-ring</li> <li>7. The connection O-ring and its position</li> <li>8. Plug for the hydraulic inlet</li> <li>9. A hydraulic inlet (connected on one caliper, a plug (item 8) on the other)</li> <li>10. The hole in the spacer</li> <li>11. Washer</li> <li>12. One of the four valves to bleed the fluid</li> <li>13. Nut</li> <li>14. The pad thickness must be more than than 1/16 inches (2 mm) above item 3</li> </ol> |
| <p><b>The Caliper and the Pad</b></p>                              | <p><b>Look at the pad thickness above the top of the screw</b></p>   |
| <p><b>Fittings for the Hydraulic Inlet</b></p>                    |  |



**TIP:** Hydraulic fluid flows from one caliper to the other caliper. Fluid flows through the connection O-rings (Figure 19, page 45, item 7) and the hole in the spacer (Figure 19, page 45, item 10). When you disconnect the calipers, hydraulic fluid can flow from the hole at the connection O-rings. Air can get in the line. After you connect the calipers, you must bleed the system.

You must have the necessary kit for the overhaul of your machine. Refer to the brake parts document in your machine's manual.

1. **Remove power from the machine (see above notice).**
2. Get access to the caliper halves (see [Section 2.2.2 : How to Do a Friction Pad Replacement, page 43](#)).
3. Do an overhaul on each caliper:
  - a. Remove and discard the connection O-rings ([Figure 19, page 45](#), item 7) on the caliper bodies.
  - b. Apply compressed air to the fitting for the hydraulic inlets (see [Figure 19, page 45](#), item 8) to push the pistons out.
  - c. Replace the piston O-rings ([Figure 19, page 45](#), item 6).
  - d. Put the pistons in the caliper body. Carefully tap the pistons with a wood or rubber hammer to install it.
  - e. Replace the connection O-rings. ([Figure 19, page 45](#), item 7)
  - f. Replace the friction pads (see [Section 2.2.2 : How to Do a Friction Pad Replacement, page 43](#)).
4. Replace the caliper halves as specified in [Section 2.2.2 : How to Do a Friction Pad Replacement, page 43](#).
5. Bleed the brake circuit (see [Section 2.2.4 : How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit , page 46](#)).
6. Supply electrical power to the machine.

## 2.2.4 How to Change Hydraulic Fluid and Remove (Bleed) Air from the Brake Circuit

BNWUUM03.T04 0000277589 D.2 A.7 A.3 3/17/20, 11:57 AM Released

### Risks and Precautions




**WARNING:** Risk of injury — Machine power must be on for these procedures.



- ▶ Stay away from operating mechanisms.



**CAUTION:** Risk of injury and damage — This procedure releases pressurized brake fluid.




- ▶ Keep brake fluid out of your eyes and mouth. Wear eye protection.
- ▶ Follow procedures carefully to prevent damage to the face of the disk or the pistons.





**CAUTION:** **Risk of malfunction** — Air in hydraulic fluid will compress. Compressed air in the brake line will cause brake malfunctions.



► Remove (bleed) air from the brake circuit before you operate the machine.

Requirements—These personnel and items are necessary for this procedure:

- Two technicians
- An 8-ounce container of new brake fluid
- Alternative procedures to remove air and used brake fluid:
  - a suction pump (faster procedure) (see [Figure 20: Pumps Used to Remove Hydraulic Fluid Quickly, page 48](#) )
  - with pressure in the hydraulic cylinder and gravity (see [Figure 21: Typical Tools to Remove Air \(Bleed\) Brakes and Used Hydraulic Fluid, page 48](#) )



**TIP:** The Vacula suction pump can do the work more quickly than by gravity and pressure in the hydraulic cylinder. It is also cleaner because all of the hydraulic fluid goes into the container supplied. It helps you not spill the hydraulic fluid.

- If you use a suction pump as shown in [Figure 20, page 48](#), follow the manufacturer's instructions.
- If you use the tools as shown in [Figure 21, page 48](#), follow the instructions in [Section 2.2.4 : How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit , page 46](#).

Figure 20. Pumps Used to Remove Hydraulic Fluid Quickly





Figure 21. Typical Tools to Remove Air (Bleed) Brakes and Used Hydraulic Fluid



1. Use the tools in [Figure 21: Typical Tools to Remove Air \(Bleed\) Brakes and Used Hydraulic Fluid, page 48](#) to remove the used hydraulic fluid and clean the line. Do these steps:
  - a. Use a suction tool ([Figure 21, page 48, item 4](#)) to remove the used fluid from the reservoir. Clean the contamination.
  - b. Connect the tubing ([Figure 21, page 48, item 2](#)) and container ([Figure 21, page 48, item 1](#)) to the valve on the caliper ([Figure 18, page 41, item 7](#)).
  - c. Open the valve.
  - d. Add new fluid to flush out the lines.
  - e. Apply/release the brake (see [Section 2.2.6 : Operation of Brake Systems, page 52](#)) approximately 5 to 15 times. This will flush the used fluid out of the lines.
  - f. Close the valve.



**NOTE:** These steps will cause air to go into the line.

2. Add new hydraulic fluid and remove (bleed) air from the brake circuit.



**NOTE:** This procedure uses pressure in the hydraulic cylinder and the tools in [Figure 21: Typical Tools to Remove Air \(Bleed\) Brakes and Used Hydraulic Fluid, page 48](#).

- a. Fill the reservoir with new DOT 3 brake fluid. When you do the remaining steps, continue to add new fluid to the reservoir. Do not let the reservoir become more than half empty. You must make sure that the reservoir has fluid to prevent air flow into the system from the reservoir
- b. Apply electrical power to the machine. Release the brake.
- c. See the part of the machine reference manual that tells how to operate the outputs manually.
- d. Put a small quantity of new brake fluid (approximately inches (50 mm)) in the 12 ounce container ([Figure 21, page 48, item 1](#)).
- e. Do these steps for each bleed valve ([Figure 18, page 41, item 1](#)). Two technicians are necessary. This will move the fluid in one direction and push air out of the line:
  - Attach a clean tube to the valve. Put the other end in the container ([Figure 21, page 48, item 1](#)) below the fluid.
  - Make sure that the reservoir is full of fluid.
  - Apply the brake (See [Section 2.2.6 : Operation of Brake Systems, page 52](#)).
  - Open the bleed valve. ([Figure 19, page 45, item 12](#))
  - Look for air bubbles in the container when you push the air and fluid out through the tube.
  - Close the valve.
  - Release the brake.
  - Continue the steps above until no more air comes out of the line.


- f. Add fluid to the top of the reservoir. Replace the cap.
- g. Operate the brake many times. Make sure that it operates correctly.


## 2.2.5 How to Adjust the Connection between the Brake Cylinder and the Air Cylinder

BNWUUM03.T05 0000277686 D.2 A.7 A.4 3/17/20, 2:24 PM Released

If you removed the brake cylinder or the air cylinder, you must adjust this connection.

**Figure 22. The Connection between the Brake Cylinder and the Air Cylinder**



**Figure 23. The Adjustment between the Brake Rod and the Air Cylinder**

1. Adjust for maximum rod travel.
  - a. Operate the master switch to energize control power.
  - b. Make sure that the air pressure that releases the brake ([Figure 24: A Typical First and Second Brake on a Divided Cylinder Machine, page 53](#) , item 1) is 85 -100 PSI (5.95 - 07.0 kg/cm-cm).
  - c. Make sure that the nuts that lock the rods together ([Figure 22, page 50](#), item 5) are loose.
  - d. Release the brake (see [Section 2.2.6 : Operation of Brake Systems, page 52](#)). Let the air cylinder rod fully retract into the air cylinder as shown in [Figure 23, page 51](#), item A.
  - e. Turn the brake rod into the air cylinder rod until the brake rod comes out of the brake cylinder fully. See [Figure 23, page 51](#), item B.
  - f. Lock the brake rod ([Figure 22, page 50](#), item 2) to the air cylinder rod ([Figure 22, page 50](#), item 3) with two nuts ([Figure 22, page 50](#), item 5).
2. Make sure that the brake will continue to operate while the pads wear.
  - a. Release the brake. On the view slot, put a mark at the position of the lock nuts. ([Figure 23, page 51](#), item M1).
  - b. Apply the brake. See [Section 2.2.6 : Operation of Brake Systems, page 52](#).
  - c. Put a mark at the position of the lock nuts when the brake is applied. This can be at position M2a, M2b, or between M2a and M2b. When the pads wear, this position will move.
  - d. Make sure that the distance the rod moves when you apply the brake is 0.75 to 1.0 inches (19-25 mm). If the travel is more than this, the brake piston can hit the mechanical stop before the brake engages fully. This condition is shown in [Figure 23, page 51](#), item E (dimension TT).

## 2.2.6 Operation of Brake Systems

BNWUUM03.T06 0000277789 D.2 A.7 A.3 3/17/20, 11:57 AM Released

Look at the electrical schematics of your machine to find how your brake is controlled. Some machines release the brake when you close the door. Some machines have a control relay to release or apply the brake.

### 2.2.6.1 How to Apply the Brake for Machines with a "Break Release" Output

BNWUUM03.T07 0000279004 D.2 A.7 A.2 3/17/20, 11:57 AM Released

1. Turn the "brake release" control output off to de-energize the air valve to remove air pressure to the air cylinder ([Figure 18: A typical hydraulic brake system, page 41](#) , item 1).
2. With no air pressure, a spring in the air cylinder will apply force to the hydraulic cylinder ([Figure 18: A typical hydraulic brake system, page 41](#) , item 8). This will apply pressure to the brake pads ([Figure 19: The Caliper Components, page 45](#) , item 4) against the rotor disk ([Figure 18: A typical hydraulic brake system, page 41](#) , item 5). ([Figure 23: The Adjustment between the Brake Rod and the Air Cylinder, page 51](#) , item C,D)



**NOTE:** If electrical power or compressed air is missing, hydraulic pressure will apply the brake.

### 2.2.6.2 How to Release the Brake for Machines with a "Brake Release" Output

BNWUUM03.T08 0000279003 D.2 A.7 A.2 3/17/20, 11:57 AM Released

1. Turn the control output called "brake release" on to energize the air cylinder valve.
2. Air pressure compresses the spring and releases the brake. ([Figure 23: The Adjustment between the Brake Rod and the Air Cylinder, page 51](#) , item B)

### 2.2.6.3 How to Apply and then Release the Brake Quickly

BNWUUM03.T09 0000279002 D.2 A.7 A.2 3/17/20, 11:57 AM Released


There are two air tubes at ([Figure 18: A typical hydraulic brake system, page 41](#) , item 1). One supplies compressed air from an air valve. The other sends this compressed air to a pressure switch. If you remove one of the two tubes when compressed air is there, you will apply the brake.

1. Disconnect the air tubing ([Figure 18: A typical hydraulic brake system, page 41](#) , item 1).
2. Turn the "brake release" output on. The air valve will supply compressed air to one of the tubes. ([Figure 18: A typical hydraulic brake system, page 41](#) , item 1).
3. Quickly move one of the compressed air tubes ([Figure 18: A typical hydraulic brake system, page 41](#) , item 1) on and off the air cylinder.
4. After you complete this procedure, connect the air tubing.

### 2.2.6.4 How the Brake Operates on Divided Cylinder Machines

BNWUUM03.T10 0000279001 D.2 A.7 A.2 3/17/20, 11:57 AM Released

**Figure 24. A Typical First and Second Brake on a Divided Cylinder Machine**



- On divided cylinder machines, two pair of air tubes connect to different ends of the air cylinder.
- When the cylinder turns, air pressure at [Figure 24: A Typical First and Second Brake on a Divided Cylinder Machine, page 53](#) , item 1 compresses the spring and releases the brake.
- When you operate the stop control, air pressure at 1 is removed. Then the spring in the air cylinder applies the brake.
- If you open the door, the 2nd brake is applied. Then the air pressure at [Figure 24: A Typical First and Second Brake on a Divided Cylinder Machine, page 53](#) , item 2 and the spring apply the brake.

### 2.2.6.5 The Second Brake

BNWUUM03.T11 0000279000 D.2 A.7 A.2 3/17/20, 11:57 AM Released

If your machine has a second brake which uses air pressure and spring pressure, it will have a pressure regulator. Make sure that you adjust the air pressure of the second brake ([Figure 24: A Typical First and Second Brake on a Divided Cylinder Machine, page 53](#) , item 2) to 10 – 12 PSI (0.7-0.84 kg/cm-cm).



BPWG7I01 / 2020213


BPWG7I01.1 0000292161 D.2 A.3 5/19/20, 4:22 PM Released

**Drive Chart**

3 Sheets

72044SR2, SR3

**Figure 25. Drive Chart**



**Legend**


- A** . . . Clutch drum pulley
- B** . . . Autospot motor
- C** . . . Gear reducer
- D** . . . Wash motor
- E1** . . E1 motor
- E2** . . E2 motor
- F** . . . Drain motor
- G** . . . Jackshaft
- H** . . . Main shaft
- J** . . . Idler shaft

**Drive Chart**

72044SR2, SR3

3 Sheets

**Figure 26. Drive Chart - Rear View and Top View**



**Drive Chart**

3 Sheets

72044SR2, SR3

**Table 18. Parts List—Drive Chart**


| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |   |                      |
|---|------|-------------|---|----------------------|
| Used In   | Item | Part Number | Description/Nomenclature                | Comments             |
| Reference Assemblies  |      |             |   |                      |
|   | A    | D36 00360   | *DRIVECHART=7244SG2 60CYC               |                      |
| Components  |      |             |   |                      |
| all   | 1    | X3 06039    | CLUTCH DRUM+VPUL 72MM                   |                      |
| all   | 2    | X2 15106    | FLANGE=CLUTCH DRIVE 2.5                 |                      |
| all   | 3    | 56Q1GSDS    | 1+3/8" BUSH VPUL QD TYPE SDS            |                      |
| all   | 4    | 560685R2SE  | VPUL 2G3V6.85 (SDS) TYPE QD             |                      |
| all   | 5    | 56VR0900M2  | VBELT 3V900 EA=1BLT                     | USES 2 BELTS         |
| all   | 6    | 56Q1MSK     | 1+5/8" BUSH VPUL QD TYPE SK             |                      |
| all   | 7    | 560685R5SK  | VPUL 5G3V6.85 (SK) TYPE QD              |                      |
| all   | 8    | 56VR067S    | VBELT 3V670                             | USES 5 BELTS         |
| all   | 9    | 56Q1RSK     | 1+7/8" BUSH VPUL QD TYPE SK             |                      |
| all   | 10   | 561110R4SK  | VPUL 4G3V11.1(SK) TYPE QD               |                      |
| all   | 11   | 56VR112S    | VBELT 3V1120                            | USES 4 BELTS         |
| all   | 12   | 56Q1GSF     | 1+3/8" BUSH VPUL QD TYPE SF             |                      |
| all   | 13   | 02 19201D   | V-PUL 8G3V7.95 QD TYPE "SF"             |                      |
| all   | 14   | 15K226C     | SOKCAPSCR 5/8-11X3 BLK                  |                      |
| all   | 15   | 56Q3DR2S    | 3+3/16" SPLIT BUSH BROWNING #R2         |                      |
| all   | 16   | 54V400      | BUSHING=3-15/16=SPECIAL                 |                      |
| all   | 17   | 15E250      | STRSQMACHKEY 1X6 C1018                  |                      |
| all   | 18   | 03 06330    | VPUL BROWN 7C7.0 (R2)35#EA              |                      |
| all   | 19   | X3 06330A   | VPUL=7GR 7PDX14.5PD=72SG                |                      |
| all   | 20   | 56Q2HQ2S    | 2+7/16"SPLIT BUSH'N BROWN "Q2"          |                      |
| all   | 21   | 56070C7Q2   | VPUL 7C7.0 Q2=SPCL B#7C70Q              |                      |
| all   | 22   | 56VC190XBA  | SETOF 1-3RCX190+1-4RCX190VBAND          | SET OF 2 VBAND BELTS |
| all   | 23   | 56Q2TF      | 2+15/16" BUSH VPUL QD TYPE F            |                      |
| all   | 24   | 56130C7FA   | VPUL 7C13.0(F)TYPE QD=SPECIAL           |                      |
| all   | 26   | 56VC120XBA  | SETOF 1-3RCX120+1-4RCX120VBAND          | SET OF 2 VBAND BELTS |
| all   | 27   | 56Q1GSK     | 1+3/8" BUSH VPUL QD TYPE SK             |                      |
| all   | 28   | 560470R6SK  | VPUL 6G3V4.7 (SK) TYPE QD               |                      |
| all   | 29   | 56VR053X    | VBELT 3VX530                            | USES 6 BELTS         |
| all   | 30   | 02 175021   | KEY-3/4"SQX6+1/2"LONG-60WE              |                      |
| all   | 31   | 54S025A     | MILNOR, 10,17:1, AIR SEAL 30HP GEAR RED |                      |

Drive Base

72044SR2



Section A-A: Jackshaft, Air Clutch, Gear Reducer, Reducer Air Seal





Legend

- B . . . See detail B
- C . . . See detail C
- D . . . See detail D
- DM . . Drain motor
- E1 . . E1 motor
- E2 . . E2 motor
- H . . . Jackshaft
- J . . . Air clutch, see BPWG7103
- K . . . Gear reducer
- L . . . Reducer air seal, see BPWG7104
- M . . . Air to air clutch
- N . . . 11 instances
- WM . . Wash motor

**Drive Base**

5 Sheets


72044SR2



**Drive Base**

72044SR2

5 Sheets



**Legend**  
 R. . . 4 instances  
 S. . . Uses 4

**Drive Base**

5 Sheets

72044SR2

**Table 19. Parts List—Drive Base**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |              |
|---|------|-------------|--------------------------------|--------------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments     |
| Reference Assemblies  |      |             |                                |              |
|   | A    | SA 36 024   | *DRIVE BASE ASSY=72"SGD        | REFERENCE    |
|   | B    |             | FRONT MOTORS                   | E1 & E2      |
|   | C    |             | REAR MOTORS                    | WASH & DRAIN |
| Components  |      |             |                                |              |
| all   | 1    | W2 18717A   | *DRVBSE=60+72SP (50+60C)TMKN   |              |
| all   | 2    | X2 18634    | CLAMP=MACHINED DR HINGPIN      |              |
| B   | 3    | 02 19285    | MTRPLATE 184/215T BEND@PRINT   |              |
| C   | 3    | 05 20131A   | MTRPLATE 284/286T BEND@PRINT   |              |
| B   | 4    | 17R022A09A  | THRD ROD 1/2-13UNCX9"LG ZN PL  |              |
| C   | 4    | 17R022A14A  | THRD ROD 1/2-13UNCX14LG ZN PL  |              |
| B   | 5    | 02 19287    | MTRPLATE FR256T BEND@PRINT     |              |
| C   | 5    | 02 19286    | MTRPLATE 254/256T BEND@PRINT   |              |
| all   | 9    | 02 18733    | BRACE=SWAY 60"SGH              |              |
| all   | 10   | 02 18706    | REINFORCEMENT=HINGE PINCLAMP   |              |
| all   | 11   | 03 25626    | FORK=MTR MNT ADJ SCREW 52      |              |
| all   | 12   | 02 19380    | MOTOR MOUNT=SHIM 72 SGH        |              |
| all   | 13   | X3 06039    | CLUTCH DRUM+VPUL 72MM          |              |
| all   | 14   | X2 15106    | FLANGE=CLUTCH DRIVE 2.5        |              |
| all   | 15   | 54H150      | RUBBER AIRCLUTCH EATON 12ER350 |              |
| all   | 16   | 15E230      | STRMACHKEY 3/8SQX2+1/2 TOL.+0  |              |
| all   | 17   | 56AHW12     | W12 BEARING LOCKWASHER         |              |
| all   | 18   | 56AHN12     | N12 BEARING LOCKNUT            |              |
| all   | 19   | 53A060A     | NUT BRASS 5/16 COMP#61A-5      |              |
| all   | 20   | 53A060      | SLEEVE 5/16 COMP IMP#60-F      |              |
| all   | 21   | 53A040B     | BODY=EL90MALE5/16X.25#B69A-5B  |              |
| all   | 22   | 5SB0G0EDEO  | NPTHEXBUSH 3/8X1/4 GALCI 125#  |              |
| all   | 23   | 03 01234    | COVER=CENT-SW SHAFT PLATED     |              |
| all   | 24   | 15N154D     | RDMACSCR 10-24UNC2AX5 ZINC GR2 |              |
| all   | 25   | 03 06247    | BRACKET-REDUCER MTG=SGD        |              |
| all   | 26   | 02 19131    | BRACKET=FRONT REDUCER MOUNT    |              |
| all   | 27   | 5SCC0GNF    | NPT COUP 3/8 GALMAL 150#       |              |
| all   | 28   | 5N0GCLSG42  | NPT NIP 3/8XCLS TBE GALSTL S40 |              |
| all   | 29   | 5SP0GFFSSV  | NPT PLUG 3/8 SQSOLIDVENTBLKSTL |              |

**Drive Base**

72044SR2

**Table 19 Parts List—Drive Base (cont'd.)**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| all   | 30   | 5SL0GNFA    | NPTLNB 90DEG 3/8 GALMAL 150#   |          |
| all   | 31   | 5SP0GGFSS   | NPT PLUG 3/8 SQ SOLID GALSTL   |          |
| all   | 32   | 5N0G04KG42  | NPT NIP 3/8X4.5 TBEGALSTL SK40 |          |
| all   | 33   | 15K095      | HXCPSCR 3/8-16UNC2AX1 GR5 ZINC |          |
| all   | 34   | 15K110      | HEXCAPSCR 3/8-16UNC2AX1.5 GR5- |          |
| all   | 35   | 15U240      | FLATWASHER(USS STD) 3/8" ZNC P |          |
| all   | 36   | 15U255      | LOCKWASHER MEDIUM 3/8 ZINCPL   |          |
| all   | 37   | 15G205      | HXNUT 3/8-16UNC2B ZINC GR2     |          |
| all   | 38   | 15K147      | HXCAPSCR 1/2-13UNC2X1 GR5 ZINC |          |
| all   | 39   | 15K151      | HXCAPSCR 1/2-13UNC2AX1.25 GR5  |          |
| all   | 40   | 15K182      | HEXTAPSCR 1/2-13X2ZINC GR5 FUL |          |
| all   | 41   | 15U300      | LOKWASHER REGULAR 1/2 ZINC PLT |          |
| all   | 42   | 15G230      | HXNUT 1/2-13UNC2B SAE ZINC GR2 |          |
| all   | 43   | 02 19283    | NUT=1/2-13UNCX1+1/2SQ SPEC     |          |
| all   | 44   | 15K227      | HXCAPSCR 5/8-11UNC2AX4 GR5 ZIN |          |
| all   | 45   | 15U315      | LOKWASHER MEDIUM 5/8 ZINCPL    |          |
| all   | 46   | 15G236      | SQNUT 5/8-11UNC2B SAE ZINC GR2 |          |
| all   | 47   | 17R125A15K  | STUD=DRIVEBASEADS 1+1/4X15.5   |          |
| all   | 48   | 17W125      | 1+1/4"SPHERICAL WASHER SET     |          |
| all   | 49   | 15U425      | LOCKWASHER MEDIUM 1+1/4"ZINC P |          |
| all   | 50   | 15G261      | HVHXNUT 1+1/4-8UNC2B ZINC GR2H |          |
| all   | 51   | 5N0E02AG42  | NPT NIP 1/4X2 TBE GALSTL SK40  |          |
| all   | 52   | 96M055      | DELTROL QUICK EXHAUST VLV.1/4" |          |
| all   | 53   | 5N0ECLSBE2  | NPT NIP 1/4XCLS TBE BRASS 125# |          |
| all   | 54   | 27A005      | MUFFLER 3/8" BANTAM B38        |          |
| all   | 55   | 02 19383    | BEARHOUSE MT PLATE FRONT       |          |
| all   | 56   | 15K221      | HEXCAPSCR 5/8-11 UNC2X2GR5 ZIN |          |
| all   | 57   | 15U314      | FLATWASHER(USS STD) 5/8" ZNC P |          |
| all   | 58   | 15G238      | HXNUT 5/8-11UNC2B SAE ZINC GR2 |          |



BPWG7I05 / 2020232


BPWG7I05.1 0000294388 D.2 A.5 6/1/20, 2:09 PM Released

**Jackshaft**

3 Sheets

72044WR2, 72044SR2

**Figure 27. Cross Section Views**




# Jackshaft

72044WR2, 72044SR2

3 Sheets

Figure 28. Detail Views



**Jackshaft**

3 Sheets


72044WR2, 72044SR2

**Table 20. Parts List—Jackshaft**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| Reference Assemblies  |      |             |                                |          |
|   | A    | ABJ25004    | JKSHAFT-BRGHOUS-SPHRCL BNG     |          |
| Components  |      |             |                                |          |
| all   | 1    | X2 18711E   | JACKSHAFT SPHERICAL BRNG       |          |
| all   | 2    | 54A988      | SKF BRNG #22217EK/C3           |          |
| all   | 3    | 54A989      | 17 X 2.938 SNW ADAPTER ASSY    |          |
| all   | 4    | X2 19381D   | BRNG HOLDER=SPHRCL BRNG-REAR   |          |
| all   | 5    | X2 19381C   | BRNG HOLDER=SPHRCL BRNG-FRT    |          |
| all   | 6    | X2 15702A   | RETAINER-SPHRCL BRNG           |          |
| all   | 7    | 02 19384    | COVER=BRG HOUSE FT+REAR        |          |
| all   | 8    | X2 19378    | BRGHSG SUP=TIMKENS MACHINED    |          |
| all   | 9    | 15K193      | SOKCAPSCR 1/2-13X2.75GR8 HK    |          |
| all   | 10   | 15U180      | LOCKWASHER MEDIUM 1/4 ZINCPL   |          |
| all   | 11   | 15K030      | HEXCAPSCR 1/4-20UNC2X1/2 GR5 Z |          |
| all   | 12   | 15K041      | HXCAPSCR 1/4-20UNC2AX1 GR 5 ZI |          |
| all   | 14   | 02 19196    | RING=GREASE SLNGR JKSHFT BLK   |          |
| all   | 15   | 51A001      | ADAPTER 1/8 PT BRASS           |          |
| all   | 16   | 5SL0CBEC    | NPTELB 90DEG STRT 1/8 BRASS125 |          |
| all   | 17   | 20C007G     | THDLOCKSEAL LCT24231 RMUBL50CC |          |
| all   | 18   | 5N0C04AG42  | NPT NIP 1/8X4 TBE GALSTL SK40  |          |
| all   | 19   | 5SCC0CBE    | NPT COUP 1/8 BRASS 125# 103A-A |          |
| all   | 20   | 54M025      | HYDFIT 1/8"-90 ALEMITE 1613-B  |          |

**Air Clutch**

72044WR2, 72044SR2



**Legend**

A . . . 12 instances

**Table 21. Parts List—Air Clutch**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

| Used In              | Item | Part Number | Description/Nomenclature       | Comments |
|----------------------|------|-------------|--------------------------------|----------|
| Reference Assemblies |      |             |                                |          |
|                      | A    | A28 18000   | CLUTCH DRUM-AIR ASSY=60+72WE   |          |
| Components           |      |             |                                |          |
| all                  | 1    | 54H150      | RUBBER AIRCLUTCH EATON#12ER350 |          |
| all                  | 2    | X2 15106    | FLANGE=CLUTCH DRIVE 2.5        |          |
| all                  | 3    | 15K151      | HXCAPSCR 1/2-13UNC2AX1.25 GR5  |          |
| all                  | 4    | 15U300      | LOKWASHER REGULAR 1/2 ZINC PLT |          |
| all                  | 5    | 15E230      | STRMACHKEY 3/8SQX2+1/2 TOL.+0  |          |
| A                    | 6    | 53A023      | MALECON3/8X.25COMP ANCHR#68-64 |          |
| A                    | 7    | 5SB0G0EDEO  | NPTHEXBUSH 3/8X1/4 GALCI 125#  |          |
| A                    | 8    | 5SL0EBEA    | NPTELB 90DEG 1/4 BRASS 125#    |          |
| A                    | 9    | 5N0E01KBE2  | NPT NIP 1/4X1.5TBE BRASS STD.  |          |
| A                    | 10   | 53A043G     | EL90 3/8X1/4COMP.AND#69A-6B    |          |
| A                    | 11   | 90A021      | COPERTUBE 3/8"ODX.032X50' EA=1 |          |

Reducer Air Seal






Table 22. Parts List—Reducer Air Seal

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

| Used In              | Item | Part Number | Description/Nomenclature                | Comments                 |
|----------------------|------|-------------|---|--------------------------|
| Reference Assemblies |      |             |   |                          |
|                      | A    | 54S014HC    | MILNOR: 15.40:1 TAPERED OUTPUT          | 3621,3626,4226,4832,4836 |
|                      | B    | 54S012HC    | REDUCER 15.4 DORRIS #1115-25HC          | SHUTL36/40/48R+L         |
|                      | C    | 54S015      | REDUCER 19.6 SKK/DOR 3220-60C           | 4226DYE                  |
|                      | D    | 54S022A     | MILNOR, 19.59:1, AIR SEAL               | 4231,4244,5238           |
|                      | E    | 54S023B     | MILNOR, 10.17:1 AIR SEAL 7.5            | 6044WR2/WR3              |
|                      | F    | 54S025A     | MILNOR, 10,17:1, AIR SEAL 30HP GEAR RED | 6442,6446,7244,6440,6450 |
| Components           |      |             |   |                          |
| BF                   | 1    | 24S020      | MECHSHFT SEAL CRANE 3/4"TYPE#2          | (PART OF KIT ITEM 6)     |
| B-F                  | 2    | 02 15111    | GASKET AIRSEALHOUSING COVER             | (PART OF KIT ITEM 6)     |
| B-F                  | 3    | 15Q077      | SOKSETSCR 1/4-20X1/4 ZINC ALLE          | (PART OF KIT ITEM 6)     |
| B-F                  | 4    | 02 10380    | Z SHAFT COLLAR FOR AIR SEAL             | (PART OF KIT ITEM 6)     |
| A-C                  | 5    | 02 15108    | COVER=ROTARY AIRSEAL HOUSING            |                          |
| D-F                  | 5    | 02 15108A   | CVR,OUTPUT,ENDCAP MILNOR 23/25          |                          |
| all                  | 6    | K10 0002    | KIT=ROTARY AIR SEAL                     | ITEMS 1-4                |

Upper Brake Assembly

72044SR2/SR3



Legend

- A . . . Stop
- B . . . Shoe
- C . . . Do not lubricate. Make sure nyliners are in place.
- N1 . . Adjust anchor by sliding back and forward so that brake lining clears drum in open position and contacts drum in closed position.
- N2 . . When the Brake is off, the back of the shoe pushes against the Limit Bracket (Stop) to prevent the brake from rattling. Center the opening in the stop with the shoe so that the shoe pushes on the stop in the open position and doesn't drag on the drum.
- N3 . . Tighten these jam nuts enough to take out the excess clearance. Do Not Over Tighten, the Air Cylinder must move freely.

## Upper Brake Assembly

2 Sheets

72044SR2/SR3

Table 23. Parts List—Upper Brake Assembly

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                     |              |
|---|------|-------------|-------------------------------------|--------------|
| Used In   | Item | Part Number | Description/Nomenclature            | Comments     |
| Reference Assemblies  |      |             |                                     |              |
|   | A    | G40 00200C  | BRKE ASSY= DOUBLEACT/SAFETY 72      | 72044SR2/SR3 |
| Components  |      |             |                                     |              |
| all   | 1    | A40 01000A  | BRKE CYL=DOUBLE ACT/SAFETY          |              |
| all   | 2    | 17A040      | CLEVIS PIN 1/2"X1+3/8" DRILLED      |              |
| all   | 3    | 15H045      | STDCOTTERPIN 1/8X1 SS18-8           |              |
| A   | 4    | SA 28 131N  | 85131C*BRAKESHOE(NON-ASB)72SG+WETCH |              |
| all   | 5    | 02 18986    | 95521B ANCHOR=BRAKE END 1/60SGH     |              |
| all   | 6    | 15G230      | HXNUT 1/2-13UNC2B SAE ZINC GR2      |              |
| all   | 7    | 15U300      | LOKWASHER REGULAR 1/2 ZINC PLT      |              |
| all   | 8    | 15U490      | FLTWASH 1+1/2X17/32X1/4 ZINC        |              |
| all   | 9    | 15K173A     | HXCAPSCR 1/2-13UNC2AX1.75 GR5 PLATD |              |
| all   | 10   | 17A045      | CLEVIS PIN 3/4"X 3" DRILLED +ZNC    |              |
| all   | 11   | 54E223      | NYLNR12L12-FBUSH3/4X13/16X3/4       |              |
| all   | 12   | 15H051      | STDCOTTERPIN 1/8X1+1/2ZINCPL        |              |
| all   | 13   | 04 00331    | 95391C LIMIT BKT=BRAKEASSY=SAFETY   |              |
| all   | 14   | 02 18987    | 81047C ANCHOR=BRAKE END 1/60SGH     |              |
| all   | 15   | 15K105      | HXCAPSCR 3/8-16UNC2A1.25 GR5 PLATED |              |
| all   | 16   | 15U255      | LOCKWASHER MEDIUM 3/8 ZINCPL        |              |
| all   | 17   | 15U240      | FLATWASHER(USS STD) 3/8" ZNC PLT    |              |
| all   | 18   | 02 18984    | 81047A SHIM=BRAKE END 16GA          |              |
| all   | 19   | 02 18984A   | 85403B SHIM BRAKE END 10GA          | AS REQUIRED  |

## 2.3 Main Bearing and Seal Replacement for Divided Cylinder Machines


BNWVUM02.C01 0000278612 D.2 A.5 A.3 3/12/20, 11:54 AM Released

This section applies to the front and rear cylinder shaft bearings of all divided cylinder machines (Rapid Load, Staph Guard®, dye machines, etc.). It does not apply to jackshaft bearings, idler shaft bearings or bearings on open pocket machines.

The bearings covered by this section are double row, spherical roller, self aligning bearings; Koya, SKF, FMC, Torrington or equal. Referring to [Figure 29, page 70](#), the rear (clean side on Staph Guard® models) bearing is firmly held in the bearing housing (bearing and seal carrier) by the shaft seal holder, preventing axial movement. The front (soil side on Staph Guard® models) bearing is free to move axially in the bearing housing to accommodate thermal expansion of the shaft during operation and is thus the “floating” bearing. Both bearings are held in place on the tapered portion of the shaft by a bearing lock washer and lock nut.

The front and rear bearings are each protected from contamination from wash water by three spring loaded, lip type seals and a shaft seal leak off cavity (that carries off any water that leaks past the main water seals) as shown in [Figure 29, page 70](#).

**Figure 29. Cross Section View of Front and Rear Bearing Assemblies (Bearing Assembly for 60" and 72" WED Shown. Others similar.)**



Access to the bearings and seals for lubrication is provided by the various grease passages. Excess lubricant is excreted through the bearing and seal cavity leak offs as shown on [Figure 29, page 70](#). The bearings and seals must be lubricated regularly and the leak off cavities flushed out



periodically through the plugged cleanout connections, in strict accordance with the preventive maintenance procedures elsewhere.

If bearing replacement becomes necessary due to wear, it is essential that the bearings **and seals** are replaced. Seal replacement requires removal of the bearing housing and seal sleeve. (In rare instances where the seals are known to be in good condition, it is not necessary to remove the bearing housing, seals or seal sleeve when a bearing is replaced.) **A pulling fixture is required to remove the bearing housing. A set of guide rods, a seal sleeve setting fixture and a bearing setting fixture are required for reinstallation of the housing.** These tools are available for rental or purchase from the Milnor® factory and are pictured elsewhere in this section. Contact the factory two weeks in advance of repairs, when ordering these tools.

This maintenance is performed in the following order:

1. Remove old bearing(s). When removing both bearings, remove the front (soil side) bearing first.
2. Remove bearing housings, seal sleeves, and seals.
3. If both bearings were removed, install the bearing housing, seal sleeve, seals, and new bearing on the rear (clean side).
4. Install the bearing housing, seal sleeve, seals, and new bearing on the front (soil side).
5. Tighten bearing(s).


See the Main Bearing Assembly drawing for your machine for bearing component part numbers.

### 2.3.1 Removing the Bearing (Front or Rear)

BNWVUM02.T01 0000278621 D.2 A.5 A.3 3/12/20, 11:54 AM Released

1. Loosen, then remove the main drive belts and cylinder shaft pulley (if applicable) by lowering the drive base with the jacking bolts. Do not attempt to pry belts off with a pry bar or by rolling the sheave. Remove the bearing cover (or shaft seal holder) to expose the bearing.
2. Bend back the locking tang on the bearing lock washer then remove the lock nut and lock washer.
3. The center tapped hole in the shaft end is an oil passage through which oil may be forced between the tapered shaft and the bearing inner race. Install a pipe fitting into this tapped hole as shown in [Figure 30: Connection From Hydraulic Pump to Assist in Bearing Removal, page 72](#) . Using a “Porta Power” or similar hand operated hydraulic pump, force fluid into the passage. Pump hard to build up fluid pressure. This pressure will cause the inner race to expand slightly; just enough to free the tapered surfaces and allow the bearing to slip off easily. If the bearing is not readily removed, remove the front water level inspection plate and use a timber to pry up the cylinder to remove cylinder weight from the bearings. Once the bearing is removed, the cylinder drops only approximately 1/32" before the shaft comes to rest on the shaft support.
4. Slide the bearing off of the shaft and if it is to be reused, place it on a clean surface and cover with a clean, lint free cloth.

**Figure 30. Connection From Hydraulic Pump to Assist in Bearing Removal**




### 2.3.2 Removing the Bearing Housing (Bearing and Seal Carrier), Seal Sleeve, and Seals (Front or Rear)

BNWVUM02.T02 0000278618 D.2 A.5 A.3 3/12/20, 11:54 AM Released


These procedures require the use of a pulling fixture and guide rods available from the Milnor<sup>®</sup> factory. With the bearing cover (or shaft seal holder) and the bearing removed, proceed as follows:

1. Remove the three bearing housing cap bolts and the grease lines from the bearing housing front plate. Install guide rods in two of the bolt holes, as shown in [Figure 31, page 72](#).
2. Install the pulling fixture as shown in [Figure 32, page 72](#), by placing each of the four threaded rods through a hole in the steel plate with hexnuts to the outside of the plate then screwing each rod into the appropriate tapped hole in the bearing housing (same holes as used to mount the bearing cover or shaft seal holder).

**Figure 31. Two Bearing Housing Guide Rods in Position**



**Figure 32. Bearing Housing Pulling Fixture in Position**





**NOTE:** Step 2a or 2b below will cause the bearing housing to slide away from the shell. Shims were placed under one or more of the three bearing housing pads during factory assembly to align the housing and insure its being exactly parallel with the shaft. **When removing the bearing housing, be sure to keep these shims separate and identified so that they may be returned to their proper location, otherwise the bearing and seal will be out of line and may be damaged after a short operating period.** As a precaution in case the shims are lost during disassembly, you will find stamped next to the bearing housing the proper thickness of shims required (if any) under each adjacent bearing housing pad. The stamped number indicates the shim thickness in thousandths of an inch. For example, the number “38” indicates that 38/1000 (.038") shims would be required under this pad.

- a. Tighten all four hex nuts on the threaded rods such that the pulling fixture plate is pressed against the shaft end. With an impact wrench, tighten down on the center bolt until the housing slides out, or
- b. If no impact wrench is available, simply continue to tighten down on each of the four hex nuts behind the pulling fixture plate, alternately and progressively, until the housing slides out. It may be necessary to place a spacer (approx. two inches long) between the plate and the shaft to provide enough clearance between the plate and the bearing housing.
3. Once the bearing housing is free of the shell, carefully slide it off of the guide rods and place on a clean work surface.
4. The seal sleeve will almost always remain on the shaft when the housing is removed. Remove the seal sleeve **taking care not to damage or scar it** and place it on a clean work surface.

### 2.3.3 Precautions for Bearing Replacement

BNWVUM02.C02 0000278703 D.2 A.5 A.4 3/16/20, 8:35 AM Released

The most important ingredient in successful bearing and seal installation is **cleanliness**. The bearing housing must be free of all **foreign** matter. The grease and leak off passages must be blown clear and all **foreign** matter removed. You must have a clean work area. Keep your hands and tools free from grit and grime. Wash your hands before starting and as required during these procedures. **Foreign** matter is, without doubt, the most frequent cause of bearing failure, and one over which the manufacturer has no control.

Where cleaning is required, bearings, bearing housings and seal sleeves may be cleaned with the following solvents or cleaning agents (in strict accordance with the manufacturer's recommendations as such substances are generally toxic and/or explosive under certain conditions):

|             |                |                   |
|-------------|----------------|-------------------|
| Benzene     | Gasoline       | Naptha            |
| Chlorethane | Kerosene       | Tricholorethylene |
| Freons      | Mineral Spirts |                   |

Do not, however, expose any components to the above substances for more than 24 hours and only use at room temperature. Never use the following solvents or cleaning agents: alcohols, cresols, phenols, flouro propanols, or other similar chemicals or mixtures.



**NOTE:** Hammer blows, overheating, or improper use of force can damage precision parts.

## 2.3.4 Replacing the Bearing Housing, Seal Sleeve, and Seals (Front or Rear)

BNWVUM02.T03 0000278713 D.2 A.5 A.3 3/12/20, 11:54 AM Released

1. With the seal sleeve removed, press all old seals out of the bearing housing. Remove the large o-ring from the outside of the housing. Thoroughly clean the bearing housing and flush out all grease passages to make certain they are unblocked. Remove the o-rings from the inside of the seal sleeve and clean the seal sleeve.
2. While the bearing housing is disassembled, charge all grease passages with grease. This will assure that there are no blockages.
3. Replace the o-rings in the seal sleeve and the large o-ring on the outside of the bearing housing. Replace with new o-rings if the old ones are worn.
4. Press new seals into the bearing housing. You may gently work the seals in with a mallet and metal drift as shown in [Figure 33, page 74](#).




**CAUTION:** Each seal must be of the proper material and face the proper direction. The type of material and direction the seal faces may differ from one seal to another within the same bearing housing and also from one type of machine to another. It is essential to consult the Main Bearing Assembly drawing for your machine for the proper part number and direction to face each seal.

5. Slip the seal sleeve into the bearing housing as shown in [Figure 34, page 74](#), using care not to damage or fold under any of the seal lips. Be sure to insert the sleeve in the proper direction (see Bearing Assembly drawing).

**Figure 33. Installing Seals in Bearing Housing**



**Figure 34. Installing Seal Sleeve in Bearing Housing**






**NOTE:** If both housings are being installed, install the rear housing first.

6. With two of the three temporary guide rods in position on the shell, place the bearing housing onto the guide rods and install the seal sleeve setting fixture on to the bearing housing as shown in [Figure 35, page 75](#). The seal sleeve setting fixture prevents the seal sleeve from being pushed out of the housing as the housing is inserted into the shell. Note that the seal sleeve setting fixture and the bearing setting fixture are very similar, but the seal sleeve setting fixture has a longer hub.
7. With a clean, lint free cloth, apply a coating of light machine oil to the outside of the housing, to assist in installation. Push the housing into the shell as shown in [Figure 36, page 75](#). Once the housing is far enough into the shell to support itself, place any shims back into position between the housing and the shell. Remove, then replace guide rods if required to place shims under bearing housing pads.

**Figure 35. Installing the Bearing Housing Setting Fixture onto Housing (42" machine shown)**




**Figure 36. Pushing the Bearing Housing into the Shell (60" Rapid-load machine shown)**



8. Install the third guide rod, spacers if required, and hex nuts, using these to seat the housing fully, as shown in [Figure 37, page 76](#). Remove the seal sleeve setting fixture.

**Figure 37. Tightening the Bearing Housing into the Shell (42" machine shown)**



9. Remove the guide rods and install the bearing housing cap bolts. See “Bolt Torque Requirements” elsewhere, for proper torques.
10. With the grease gun, pump grease into the inner portion of the bearing cavity, such that when the bearing is installed, the space between the bearing and the seals will be approximately 1/3 full of grease.
11. Proceed to [Section 2.3.5 : Measuring Unmounted Clearance and Setting Bearing \(Front or Rear\)](#), page 76, even if both the front and rear bearings are being replaced. Once the rear bearing is installed, the bearing housing replacement procedures may then be repeated for the front (soil side) bearing housing.

### **2.3.5 Measuring Unmounted Clearance and Setting Bearing (Front or Rear)**

BNWVUM02.T04 0000278712 D.2 A.5 A.3 3/12/20, 11:54 AM Released

The bearings used on Milnor® washer and dye extractors are the very best anti-friction devices available for these applications. However, the anti-frictional characteristics of the bearings will be reduced if they are not properly installed. It is of critical importance when installing these tapered roller bearings, to accomplish the following (A step by step procedure follows this synopsis):

1. Accurately measure the unmounted internal clearance of the bearing (gap between the rollers and outer race before the bearing is installed). This is an essential quality control measure.
2. Calculate the final internal clearance by subtracting the specified clearance reduction (amount that the internal clearance must be reduced when the bearing is tightened onto the tapered shaft) from the unmounted clearance.
3. Tighten the bearing onto the shaft until the final internal clearance as calculated is achieved and verified by measurement.

These measurements are taken in thousandths of an inch. Although this requires precise work, attention to detail and a good set of feeler gauges, it is the only way to insure that the bearing will be tightened onto the shaft to precisely the right tension. If you have any questions on performing the measurements or adjustments described below, your local bearing supplier or the Milnor® factory can assist you. Although these procedures require precision over and above that normally required for laundry room maintenance, they are standard in bearing installation and absolutely essential:



**NOTE:** Step 4 requires a good set of feeler gauges including .001" through .010" in thousandths of an inch increments. Contact your local bearing supplier.

4. When you are ready to proceed (and not before), remove the new bearing from its box or protective wrapping. Do not attempt to clean the bearing or wash out the preservative coating. On a clean work surface, stand the bearing on edge and insert a .003 feeler gauge into the bearing as shown in [Figure 38, page 77](#). The gauge should be inserted just inside the outer race between two rollers and worked through to the opposite row of rollers. Rotate the inner race of the opposite row so that the end of the feeler gauge is caught between a roller and the outer race.

**Figure 38. Measuring Bearing Unmounted Clearance (bridge for 42" machine shown)**



5. Try to pull the gauge straight out. If it comes out, increase the size of the gauge by .001". If it does not come out, decrease the gauge by .001". The thickest feeler gauge that will come out is the unmounted internal clearance of the bearing.
6. Compare the measured clearance with the "Unmounted Clearance" in [Table 24: Table of Bearing Clearances, page 78](#). If the measured clearance is not within the range shown, do not use the bearing. Contact your bearing supplier for an exchange.



**NOTE:** The clearances listed in the chart are industry standards and therefore apply to all brands of bearings supplied by Milnor®. If other sources of bearings are used, refer to the manufacturer's instructions for proper clearances.



**NOTE:** To locate your bearing on the chart, match the first five characters of the manufacturer’s part number (**not the Milnor® part number**) with those in the chart. For example, for a manufacturer’s part number 22217LBK, find under “Manufacturer Part Number” the line “22217 . . .”

**Table 24. Table of Bearing Clearances**

| Manufacturer Part Number | Unmounted Clearance |         | Clearance Reduction |         |
|--------------------------|---------------------|---------|---------------------|---------|
|                          | Minimum             | Maximum | Minimum             | Maximum |
| 22330...                 | .0071               | .0091   | .002                | .003    |
| 22213...                 | .0030               | .0039   | .001                | .002    |
| 22216...                 | .0028               | .0037   | .001                | .002    |
| 22217...                 | .0044               | .0057   | .0015               | .0025   |
| 22312...                 | .0030               | .0039   | .001                | .002    |
| 22316...                 | .0037               | .0049   | .001                | .002    |
| 22320...                 | .0044               | .0057   | .0015               | .0025   |
| 22328...                 | .0063               | .0081   | .002                | .003    |
| 23220...                 | .0044               | .0057   | .0015               | .0025   |

7. Calculate and record the final internal clearance by deducting the “Clearance Reduction” for your bearing (see [Table 24, page 78](#)) from the measured clearance. For example, if you measured .004 and the clearance reduction is .001 to .002, then the final internal clearance should be between .002 and .003.
8. Hand pack the bearing with grease by rotating the inner race and rollers, forcing grease between all rollers.



**NOTE:** The bearing will be set into position in Step 9. If both front and rear bearings are being installed, the rear (clean side on Staph Guard® models) bearing should be set in position first because it is the fixed bearing.

9. Set the bearing into the housing (with the taper facing the proper direction) and seat the bearing using the bearing setting fixture. This fixture is installed in similar fashion to the seal sleeve setting fixture. If you have just set the rear bearing and the front bearing housing is yet to be installed, leave the bearing setting fixture in place for now.
10. If you have just set the rear bearing and the front bearing housing is yet to be installed, repeat all steps in bearing housing installation, measuring unmounted clearance and setting bearing, for the front bearing and housing. The bearing setting fixture should not be removed from the rear housing until it is needed to seat the front bearing. This will prevent rear bearing components from being pushed out of position by the shaft as the front housing components are seated. Remove the bearing setting fixture from the front housing once the bearing is seated.

### 2.3.6 Tightening Bearing(s) (Front and/or Rear)

BNWVUM02.T05 0000278718 D.2 A.5 A.3 3/12/20, 11:54 AM Released

1. Once both bearings are seated, or if only one bearing was replaced, install the bearing lock washer(s) and lock nut(s). Use a hammer and a metal drift as shown in [Figure 39, page 79](#), to tighten the lock nut. **It is imperative to only tap lightly and to assure that metal chips from the drift or lock nut do not fall off and contaminate the bearing.** If both bearings are



being tightened, work between the front and rear bearings and turn the basket by hand periodically, while tightening the lock nut(s).

2. After tightening the bearing(s) onto the tapered shaft, check the internal clearance as pictured in [Figure 40, page 79](#), by working a feeler gauge between the outer race and a roller of the outer row then between the outer race and a roller of the inner row.



**NOTE:** Sometimes, when setting the bearings, all the load is taken by only one row of rollers (although the load would quickly equalize on both rows after the machine has run for only a few minutes). If all the load is taken by one row, you will get an erroneous clearance reading. It is therefore, necessary to use the feeler gauge to measure the **clearance of both rows of rollers**. With the bearing in place on the machine it is admittedly rather difficult to get a feeler gauge back past the first row of rollers to measure the second **but it must be done**.

3. If one row of rollers is tight but the other has measurable clearance, tap lightly on the end of the shaft nearest the tight row of rollers to cause the shaft to shift axially and equalize the roller loading. Adjust the bearing tightness to achieve the internal clearance previously calculated.
4. When the proper internal clearance has been attained, lock the nut by bending over the matching tang on the lock washer, making sure that all unused tangs are bent as near the nut as possible so that they will not rub against the bearing roller cage.



**NOTE:** Check each unused tab individually to insure this.

**Figure 39. Tightening the Bearing Lock nut (42" machine shown)**



**Figure 40. Measuring the Mounted Internal Clearance of the Bearing (42" machine shown)**



5. With the grease gun, fill the space between the bearing and the front of the housing 1/3 full of grease.
6. Install the bearing cover plate or shaft seal holder, as appropriate. When installing the shaft seal holder, take care not to damage the seal as it is gently pushed over the shaft. Cover the keyway on the end of the shaft with tape to prevent the sharp corners of the keyway from cutting the seal lip. Also, make sure that the seal lip does not turn over as it passes over rough areas.

BPWG7B02 / 2020242

BPWG7B02.1 0000294963 D.2 A.4 6/8/20, 11:41 AM Released

# Shaft and Bearing Components

4 Sheets

72044WR2, 72044WR3, 72044SR2, 72044SR3

Figure 41. Shaft and Bearing Components





Figure 42. Front Bearing (Models: 72044WR2, 72044WR3)



# Shaft and Bearing Components

4 Sheets

72044WR2, 72044WR3, 72044SR2, 72044SR3

Figure 43. Front Bearing (Models: 72044SR2, 72044SR3)





Figure 44. Rear Bearing (Models: 72044WR2, 72044WR3, 72044SR2, 72044SR3)



# Shaft and Bearing Components

4 Sheets

72044WR2, 72044WR3, 72044SR2, 72044SR3

**Table 25. Parts List—Shaft and Bearing Components**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |   |                   |
|---|------|-------------|---|-------------------|
| Used In   | Item | Part Number | Description/Nomenclature                        | Comments          |
| Reference Assemblies  |      |             |   |                   |
|   | A    | AD 36 022   | BEARASY,MAIN FRONT 72WEU                        | 72044WR2,72044WR3 |
|   | B    | G36 05400   | BEARASY MAIN REAR 7244WE2+3                     | 72044WR2,72044WR3 |
|   | C    | AD 36 040   | BEARASY,MAIN (LOD+CLN) 72SGU                    | 72044SR2,72044SR3 |
| Components  |      |             |   |                   |
| A   | 1    | X3 06047    | SUPPORT=FRNTSHFT=72": C2-18843                  |                   |
| BC  | 2    | X3 06003    | SHAFT SUPPORT= 72"WE: C2-18592                  |                   |
| A   | 3    | X3 06005    | HOUSING=FRNT BRG+SIL:C2-18842                   |                   |
| C   | 3    | X2 175005   | BRGHOUSE=FRNT=SG: C2-18590                      |                   |
| B   | 4    | X3 06369    | HOUSING=REAR=BRG :C2-18590                      |                   |
| C   | 4    | X2 175007   | BRGHOUSE=REAR=WEH:C2-18590                      |                   |
| A   | 5    | 02 18618A   | COVER=BEARING 60 WED                            |                   |
| B   | 6    | X3 06370    | HOLDER=REAR SEAL                                |                   |
| C   | 6    | X2 175053   | HOLDER=SEAL=60SG SS W/AUTOSP                    |                   |
| all   | 7    | X3 06165    | SLEEVE=SHAFT SEAL=2/72WEDU                      |                   |
| all   | 8    | 02 18219    | LOCKWASH=MAIN BEARHOUSE ZINC                    |                   |
| A   | 9    | 02 18928    | DRIPSHIELD=60" WE + ZINC                        |                   |
| AC  | 10   | 56S22316T   | SPHEROLBRG KOYO#22316RKW33C3FY<br>(3.1496"BORE) |                   |
| B   | 10   | 56S23220T   | SPHEROLBRG NTN#23220BL1KD1C3                    |                   |
| AC  | 11   | 56AHN16     | AN16 BEARING LOCKNUT                            |                   |
| B   | 11   | 56AHN20     | AN20 BEARING LOCKNUT                            |                   |
| AC  | 12   | 56AHW16     | W16 BEARING LOCKWASHER                          |                   |
| B   | 12   | 56AHW20     | W20 BEARING LOCKWASHER                          |                   |
| all   | 13   | 24S114      | SEAL 4.5X5.5X.50 JM# 9170 LUP                   |                   |
| A   | 15   | 60C161      | ORING 6"IDX1/4CS BUNA-70 #437                   |                   |
| BC  | 16   | 60C172      | ORING 8"IDX1/4CS BUNA70 #445                    |                   |
| B   | 18   | 24S112      | SEAL 3.75X4.75X.500 CS/BUNA                     |                   |
| C   | 18   | 24S111      | SEAL 3X4.00X.437#21158-2175                     |                   |
| B   | 19   | 60C166A     | ORING 6+3/4IDX1/8"CS BUNA-N 70                  |                   |
| C   | 19   | 60C160J     | ORING 6+1/4ID1/8CS BUNA70 #259                  |                   |
| all   | 20   | 5SCC0CBE    | NPT COUP 1/8 BRASS 125# 103A-A                  |                   |
| all   | 21   | 54M029      | RELIEFFIT 1/8STR ALEMITE 47200                  |                   |
| all   | 22   | 5N0C03AG42  | NPT NIP 1/8X3 TBE GALSTL SK40                   |                   |

## Shaft and Bearing Components

4 Sheets

72044WR2, 72044WR3, 72044SR2, 72044SR3

Table 25 Parts List—Shaft and Bearing Components (cont'd.)

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                  |          |
|---|------|-------------|----------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature         | Comments |
| BC  | 23   | 5SCC0EBE    | NPT COUP 1/4 BRASS 150#PSI W/HEX |          |
| BC  | 24   | 5N0E02KG42  | NPT NIP 1/4X2.5 TBEGALSTL SK40   |          |
| all   | 25   | 5SB0E0CBEO  | NPTHEXBUSH 1/4X1/8 BRASS 125#    |          |
| all   | 26   | 5N0C01KG42  | NPT NIP 1/8X1.5 TBE GALSTL S40   |          |
| B   | 27   | 5SL0CBEA    | NPTELB 90DEG 1/8 BRASS 125#      |          |
| C   | 27   | 5SL0ENFK    | NPTELB 45DEG 1/4 GALMAL 150#     |          |
| all   | 28   | 15B243      | HEXCAPSCR 1-8X2+1/2 GR5 ZINC     |          |
| all   | 29   | 15U400      | LOCKWASHER MEDIUM 1" ZINCPL      |          |
| all   | 30   | 15K145      | HXCAPSCR 1/2-13UNC2AX3/4 GR5 P   |          |
| all   | 31   | 15U300      | LOKWASHER REGULAR 1/2 ZINC PLT   |          |
| all   | 32   | 15B236      | HEXCAPSCR 1-8UNC2AX3 SAEGR5 ZN   |          |
| all   | 33   | 15K236      | SOKCAPSCR 1-8X2.75 BLK           |          |
| all   | 34   | 15K170      | HXCAPSCR 1/2-20UNFA X 1.5 GR 5   |          |
| all   | 34   | 15K180      | HXCAPSCR 1/2-13UNCAX2 GR5 ZINC   |          |
| all   | 36   | 02 18768D   | GASKET=SHAFT SUPT DA3            |          |
| all   | 37   | 02 18105    | BEARING CAP GASKET               |          |
| all   | 38   | 54M015      | GREASEFIT 60X36/60X44 1610BL     |          |
| all   | 40   | 53A039B     | BODY=EL90MALE5/16X1/8 #B69A-5A   |          |
| all   | 41   | 53A508      | SLEEVE DELRIN 5/16"OD#60PT-5     |          |
| all   | 42   | 53A509      | TUBE INSERT 5/16"OD X .53"LG.    |          |
| all   | 43   | 53A019B     | BODYMALECON5/16X1/8COM#B68A-5A   |          |
| all   | 44   | 5N0E01KBE2  | NPT NIP 1/4X1.5TBE BRASS STD.    |          |
| all   | 45   | 51P008B     | PLUG SQSLD 1/4"BLK LVENT STEEL   |          |
| all   | 46   | 53A060A     | NUT BRASS 5/16 COMP#61A-5        |          |


BPWG7106 / 2020232

BPWG7106.1 0000294434 D.2 A.4 6/1/20, 2:13 PM Released

# Autospot Drive Motor

2 Sheets

72044WR2, 72044SR2



# Autospot Drive Motor

2 Sheets

72044WR2, 72044SR2


**Table 26. Parts List—Autospot Drive Motor**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| Reference Assemblies  |      |             |                                |          |
|   | A    | G15 13400   | MOTOR DRIVE ASSY=AUTOSPOT      | 7244SR2  |
|   | B    | G28 15600   | MOTOR DRIVE ASSY=AUTOSPOT      | 7244WR2  |
| Components  |      |             |                                |          |
| all   | 1    | 54N015      | SPROCKET BROWN#35A96-6"BORE    |          |
| all   | 2    | 54N008      | SPRKT BROWN#35-13X7/8" BORE    |          |
| all   | 3    | 54H164A     | CLUTCH 12VDC MA-PM02B          |          |
| all   | 4    | 15E006      | KEY #6 WOODRUFF 5/32X5/8 SAE10 |          |
| all   | 5    | 15Q068      | SOKSETSCR CUP10-24X1/4ZINCALLE |          |
| all   | 7    | 54G010B43P  | ROLLCHAIN+CONNLINK 3/8"=AUTO   |          |
| A   | 8    | 02 15865    | BASE=AUTOSPOT MOTOR BND@ PRT   |          |
| B   | 8    | 02 175036   | BASE=AUTSPMTMR60+72WE BND@PT   |          |
| all   | 9    | 15K105      | HXCAPSCR 3/8-16UNC2A1.25 GR5 P |          |
| all   | 10   | 15U255      | LOCKWASHER MEDIUM 3/8 ZINCPL   |          |
| all   | 11   | 02 175027   | TAPSTRIP=AUTOSPOT MOTORMOUNT   |          |
| all   | 12   | 15K211      | HXCAPSCR 5/8-11UNC2AX1 GR5 ZIN |          |
| all   | 13   | 15U315      | LOKWASHER MEDIUM 5/8 ZINCPL    |          |
| all   | 14   | 15K180      | HXCAPSCR 1/2-13UNCAX2 GR5 ZINC |          |
| all   | 15   | 15U300      | LOKWASHER REGULAR 1/2 ZINC PLT |          |
| all   | 16   | 15G230      | HXNUT 1/2-13UNC2B SAE ZINC GR2 |          |
| all   | 17   | 03 01275    | COVER=AUTO CLUTCHWIRES         |          |
| all   | 18A  | 12M036L     | 1/2" 90-DEG SHORT ELLS         |          |
| all   | 18B  | 12M035      | 3/8" SCREW-IN CONNECTOR        |          |
| all   | 19   | 15K041      | HXCAPSCR 1/4-20UNC2AX1 GR 5 ZI |          |
| A   | 20   | 12C0375FN   | 3/8" FLX NON-METAL CONDUIT     |          |
| A   | 21   | 12M040      | 3/8" X 90-DEG SEALTITE CONN.   |          |
| A   | 23   | 12H050      | HANDYBOX 4X2+1/8X2+1/8         |          |
| A   | 24   | 12H095      | HANDY BOX COVER 4+2+1/8        |          |
| A   | 25   | 15P185      | TRDCUT-F HXHD 1/4-20UNC2AX3/4  |          |
| A   | 29   | 15U150      | LOCKWASHER MEDIUM #10 ZINCPL   |          |
| A   | 30   | 15K018      | SKCPSCR 10-24 UNC 3X3/8 BLK    |          |
| all   | 31   | 5SCC0GNF    | NPT COUP 3/8 GALMAL 150#       |          |
| all   | 32   | 5N0G02AG42  | NPT NIP 3/8X2 TBE GALSTL SK40  |          |

4 Inch Idler Shaft Bearing

72044SR2

Figure 45. Cross section views





## 4 Inch Idler Shaft Bearing

2 Sheets

72044SR2

Table 27. Parts List—4 Inch Idler Shaft Bearing

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                      |          |
|---|------|-------------|--------------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature             | Comments |
| Reference Assemblies  |      |             |                                      |          |
|   | A    | ABI36002    | 95041# BEARASSY=IDLERSHAFT NOBRAKE   |          |
| Components  |      |             |                                      |          |
| all   | 1    | 02 19023    | 94353A DRIVE BASE ADJ. SCREW 13.5LG  |          |
| all   | 2    | 15G250      | HXNUT 1-8UNC2B SAE ZNC GR2           |          |
| all   | 3    | 15U400      | LOCKWASHER MEDIUM 1" ZINCPL          |          |
| all   | 4    | 15K225      | 05Z HEXCAPSCR 5/8-11X2+1/2           |          |
| all   | 5    | 15G238      | HXNUT 5/8-11UNC2B SAE ZINC GR2       |          |
| all   | 6    | 15U315      | LOKWASHER MEDIUM 5/8 ZINCPL          |          |
| all   | 7    | 15U180      | LOCKWASHER MEDIUM 1/4 ZINCPL         |          |
| all   | 8    | 15K030      | HEXCAPSCR 1/4-20UNC2X1/2 GR5 ZINC    |          |
| all   | 9    | 15P010      | 12Z PHILPAN TRDCUTSCR TYP10-24X1/2SS |          |
| all   | 10   | 15U314      | FLATWASHER(USS STD) 5/8" ZNC PLT     |          |
| all   | 11   | 15U450      | FLATWASH.1345X3.25X1+11/16 ZINCPLTD  |          |
| all   | 12   | 15G268      | HXFINJAMNUT 1+1/2-12UNF2B ZINC GR2   |          |
| all   | 13   | 03 06391A   | 94266B ROD=1.5UNFX10.5LG=TAKE-UP     |          |
| all   | 14   | 15K235A     | 03Z HEXCAPSCR 3/4-10X2.5 GR 8        |          |
| all   | 15   | 15U340      | LOCKWASH MEDIUM 3/4 ZINCPL           |          |
| all   | 16   | 15U320      | FLATWASHER(USS STD) 3/4" UNPLT       |          |
| all   | 17   | 56S22220T   | 04Z SPHEROLBRG NTN#22220BL1KD/C3     |          |
| all   | 18   | 56AHS20     | SNW20 BRG ADAPT 3.5" CYL BORE        |          |
| all   | 19   | 56S22220S   | 04Z SPHEROLBRG NTN#22220BL1D1C3      |          |
| all   | 20   | W2 18747E   | 92257C*TAKE-UP WLMT=4"IDLER SHAFTCS  |          |
| all   | 21   | 03 06444A   | 79337C CAP=BEARING IDLERSHAFT C.S.   |          |
| all   | 22   | X3 06154A   | 92236# IDLER SHAFT 4"DIA 60+72SGU    |          |
| all   | 23   | X2 18697A   | 79277C BEARHOUSE IDLER SHAFT FLOAT   |          |
| all   | 24   | X2 18696A   | 94283C BEARHOUSE IDLER SHAFT LOCKED  |          |
| all   | 25   | W3 06388D   | 91247D *TAKE-UP WLMT SOIL SIDE 4"SHA |          |
| all   | 26   | 03 06444    | 79507C CAP=BEARING 4"IDLERSHAFT      |          |
| all   | 27   | 03 06445    | 94251B WEDGE=SHEAVE+SHAFT=60+72SGU   |          |
| all   | 28   | 53A005B     | BODYMALCON1/4X1/8COMP #B68A-4A       |          |
| all   | 29   | 53A059A     | NUT 1/4"BR.HOLYOKE AND #61A-4        |          |
| all   | 30   | 53A501      | TUBEINSERT .170"OD                   |          |
| all   | 31   | 53A500      | 1/4" SLEEVE DELRIN                   |          |

## 4 Inch Idler Shaft Bearing

2 Sheets

72044SR2

**Table 27 Parts List—4 Inch Idler Shaft Bearing (cont'd.)**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| all   | 32   | 54M020      | GREASEFIT 30DEG 1611-B ALEMITE |          |
| all   | 33   | 5SB0E0CBEO  | NPTHEXBUSH 1/4X1/8 BRASS 125#  |          |
| all   | 34   | 53A007B     | BODYFEMCON.25X.25COMP#B66A-4B  |          |
| all   | 35   | 5N0C01KG42  | NPT NIP 1/8X1.5 TBE GALSTL S40 |          |
| all   | 36   | 53A005F     | BODYFEMCON.25X1/8COMP#B66A-4A  |          |



BPWG6I08 / 2021314A

BPWG6I08.1 0000289364 D.2 B.2 7/28/21, 12:00 PM Released

Lower Disc Brake Installation

5 Sheets

6044SR2, 6044SR3, 7244SR2






**Legend**  
 B . . . See BPWVUP01  
 C . . . 4 instances  
 D . . . See BPWG6B02

# Lower Disc Brake Installation

5 Sheets


6044SR2, 6044SR3, 7244SR2



**Legend**

**A** . . . See detail A


**E** . . . Adapter includes bearing locknut & washer



# Lower Disc Brake Installation

5 Sheets

6044SR2, 6044SR3, 7244SR2



# Lower Disc Brake Installation

6044SR2, 6044SR3, 7244SR2

**Table 28. Parts List—Lower Disc Brake Installation**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |             |
|---|------|-------------|--------------------------------|-------------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments    |
| Reference Assemblies  |      |             |                                |             |
|   | A    | GBR28001    | INST=DISC BRAKE=60SG           | 6044SR2/SR3 |
|   | B    | GBR36001    | INST=DISC BRAKE=72SG           | 7244SR2     |
| Components  |      |             |                                |             |
| all   | 1    | ABR28002A   | ASSY=DISC BRAKE SPLIT BRNG     |             |
| all   | 2    | ABR28003    | DISC ASSY +BALANCE=60+725G     |             |
| all   | 3    | 54KC7961    | CALIPER HYD FIXMT 12/20 ROTOR  |             |
| all   | 4    | 03 65203    | DISC BRAKE PAD DAMPENER 1/8T   |             |
| all   | 5    | 15C098      | HXSOKSTRPBLT 3/4X5+1/2X5/8-11  |             |
| all   | 6    | 01 09294    | RETAIN RING-FLANGE(STEEL)+\$4S |             |
| all   | 7    | 56AHS22     | SNW22 BRG ADAPTER 4" CYL BORE  |             |
| all   | 8    | 15E260      | KEY-DISC BRAKE                 |             |
| all   | 9    | W2 19569    | *WELD TORQUE ARM 60+72SG       |             |
| A   | 10   | 02 19570    | BRKT=TORQUE ARM MOUNT          |             |
| B   | 10   | 03 06531    | BRACKET=TORQUE ARM MT 72SG     |             |
| all   | 11   | X4 22046C   | 7/8" DIA. SPACER=COBUCK        |             |
| all   | 12   | 15C095      | HXSOKSTRPBLT 3/4X1+3/4X5/8-11  |             |
| all   | 13   | 15G238N     | HXLOCKNUT NYL 5/8-11UNC STL/   |             |
| all   | 14   | 54AA00PBB   | BUSH BALL 3/4 RBC-B12L         |             |
| A   | 15   | 02 19573    | CHANNEL=TORQUE ARM MT          |             |
| B   | 15   | 03 06530    | CHANNEL=TORQUE ARM MT 72SG     |             |
| all   | 16   | 17B132      | INDUSTRIAL RETAIN.RING 4000-12 |             |
| all   | 17   | 02 19572A   | RT BRKT=DISCBRAKE HOLDER FRNT  |             |
| all   | 18   | 02 19572    | LT BRKT=DISCBRAKE HOLDER FRNT  |             |
| all   | 19   | 15K054      | HXCAPSCR 5/16-18X3/4 GR5 XYLAN |             |
| all   | 20   | 15U185      | FLATWASHER(USS STD) 1/4" ZNC P |             |
| all   | 21   | 15U210      | LOKWASHER MEDIUM 5/16 ZINCPL   |             |
| all   | 22   | 54KC7961B0  | O-RING 08-11070 BRAKE 2-660    |             |
| all   | 23   | 54KC7961H2  | BRAKEHOSE #W2511 1/8X32" OAL   |             |
| all   | 24   | 52LY0CR001  | HEXPIP NIP 1/8"XCLOSE#5404-2-2 |             |
| all   | 25   | 52JY0CR001  | ELBOW 1/8"FEM.#5504-02-02      |             |
| all   | 26   | 5N0C03AS82  | NPT NIP 1/8X3 TBE 304SS SK80   |             |
| all   | 27   | 52AY0ER003  | STR.1/4"MJICX1/8"MP#2404-4-2   |             |
| all   | 28   | 54KMC1125U  | MASTER CYL TILTON 74-1125U     |             |

## Lower Disc Brake Installation

5 Sheets

6044SR2, 6044SR3, 7244SR2

**Table 28 Parts List—Lower Disc Brake Installation (cont'd.)**


| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                   |                     |
|---|------|-------------|-----------------------------------|---------------------|
| Used In   | Item | Part Number | Description/Nomenclature          | Comments            |
| all   | 29   | W3 65238    | *WLMT=MASTER BRAKE CYL BRKT       |                     |
| all   | 30   | AAC65002    | 2006292 AIRCYL BRAKE SINGLE MOTOR |                     |
| all   | 31   | 02 19576    | SPLASH SHIELD=DISC BRAKE          |                     |
| all   | 32   | 15K154A     | HEXCAPSCR 1/2-13X1.5 G8 ZN        |                     |
| all   | 33   | 15G230      | HXNUT 1/2-13UNC2B SAE ZINC GR2    |                     |
| all   | 34   | 15U280      | FL+WASHER(USS STD)1/2 ZNC PL+D    |                     |
| all   | 35   | 15U300      | LOKWASHER REGULAR 1/2 ZINC PLT    |                     |
| all   | 36   | 15K223A     | HEXCAPSCR 5/8-11X2 GR8 ZIN        |                     |
| all   | 37   | 15U315      | LOKWASHER MEDIUM 5/8 ZINCPL       |                     |
| all   | 38   | 54KC7961BG  | BRAKE HOSE=1/8"X18"OAL # 50612    |                     |
| all   | 39   | 54KC7961BH  | BRAKE HOSE #W2261 1/8X18"OAL      |                     |
| all   | 40   | 54KC7961BP  | BRAKEFLUID/PISTON KIT #98-1198    | Caliper repair part |
| all   | 41   | 54KC7961B0  | O-RING 08-11070 BRAKE 2-660       | Caliper repair part |
| all   | 42   | 54KC7961BS  | BLEEDERSCREW#10-07721 #2-660      | Caliper repair part |
| all   | 43   | 54KC7961RK  | BRAKE PADS W/SENSOR #98-13982     | Caliper repair part |
| all   | 44   | 54KC7961CT  | CROSSOVERTUBEKIT HAY#B98-11700    | Caliper repair part |

**Lower Disc Brake Split Bearing Parts and Assembly**

5 Sheets

6044SR2, 72044SR2/SR3

**Figure 46. Bearing Components**



**Table 29. Parts List—Lower Disc Brake Split Bearing Parts and Assembly**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

| Used In    | Item | Part Number | Description/Nomenclature       | Comments |
|------------|------|-------------|--------------------------------|----------|
|            | A    | ABR28002A   | ASSY=DISK BRAKE SPLIT BRNG     |          |
| Components |      |             |                                |          |
| all        | 1    | X2 19577    | SPLIT BUSHNG=DISK BRAKE BRNG   |          |
| all        | 2    | X2 19578    | FRONT FLANGE=DISK BRAKE BRNG   |          |
| all        | 3    | X2 19579    | REAR FLANGE=DISK BRAKE BRNG    |          |
| all        | 4    | 02 10426B   | WASH=SEAL RETAIN+LOCK+SPLIT    |          |
| all        | 5    | 15K142      | HXCAPSCR 3/8-16X6 GR8ZC        |          |
| all        | 6    | 15G205      | HXNUT 3/8-16UNC2B ZINC GR2     |          |
| all        | 7    | 24S126      | SEAL 4X5X.5 JM#R-0400-10175RUP |          |
| all        | 8    | 54M029      | RELIEFFIT 1/8STR ALEMITE 47200 |          |
| all        | 9    | 53A031B     | BODY-EL90MALE.25X1/8 #269C-42B |          |
| all        | 10   | 15G218      | HXLOKNUT NYL 3/8-16 STL/ZNC    |          |
| all        | 11   | X2 19580    | SPACER=DISC BRAKE BRNG         |          |



BPWG6B02 / 2020174

BPWG6B02.1 0000288467 D.2 A.9 4/22/20, 4:56 PM Released

## Assembly Procedure


5 Sheets

6044SR2, 72044SR2/SR3


Use "Antiseize" lubricant on all threads.

Refer to the illustrations next to each step. Item numbers shown refer to the parts list.

1. Slide the front and rear flanges (Items 2 & 3) onto the shaft. Bore chamfers (large arrows) must face inward. Assemble spacers (Item 11) and ensure bolts are loose. (Only for new installation and complete replacement.)



2. Apply a thin bead of high temperature RTV silicone to the bronze bushing (Item 1) seams. Large arrows show surfaces on which to apply silicon.




## Assembly Procedure


5 Sheets

6044SR2, 72044SR2/SR3


- Put the two halves of the bronze bushing around the shaft. Ensure alignment by matching alignment marks (large arrow).



- Push the front and rear flanges (Item 2 & 3) onto the bronze bushing (Item 1). Use only a hard rubber mallet. Ensure spacers are loose.
- Rotate the bushing so the seams are approximately 90 degrees to the flange openings.



- Insert the seals (Item 7) in two locations (large arrows). Use only hard rubber or plastic mallet.




## Assembly Procedure


5 Sheets

6044SR2, 72044SR2/SR3

7. Install the seal retainers (Item 4) so they overlap the seams. Ensure the six bolts (Items 5 & 6) are loose.



8. Refer to the illustration below. Tighten the spacers (Item 11) until they no longer rotate. Constantly check assembly rotation around the shaft. Use only hand wrenches.




## Assembly Procedure

5 Sheets


6044SR2, 72044SR2/SR3

9. Refer to the illustration above. Ensure that the edges of the retainers (Item 4) meet but do not overlap. Tighten the bolts (Item 5) in an alternate pattern. Constantly check assembly rotation. Use only hand wrenches. If binding occurs, loosen the bolts and repeat.

10. With all bolts tightened rotate the assembly. Bend the star tabs (large arrow) on the retainers. The assembly should continue to rotate freely.



11. Assemble fittings (Item 8) and tubing for grease supply line. Refer to document BPWG6I08 for the lower disk brake shown in this illustration.



# 3 Frame & Suspension

BNWVUM01 / 2020106

BNWVUM01 0000277899 B.2 2/5/21, 9:25 AM Released

## 3.1 Suspension Adjustments for Divided Cylinder Machines

BNWVUM01.C01 0000277938 D.2 B.2 2/5/21, 9:25 AM Released

The suspension system on Milnor® Hydro-cushion™ machines is adjusted and thoroughly tested at the factory. It should not require subsequent adjustment unless the machine is distorted during shipment or installation or unless some component of the system, such as a Hydro-cushion™ cylinder is replaced.

There are two primary objectives when adjusting the suspension system on any Hydro-cushion™ machine model:

1. To position the shell in the proper location within the frame (hanging dimensions) to maximize freedom of movement of the shell and to insure proper draining, and
2. To adjust the length of up and down travel at each of the push-down locations (push down travel) so that the shell will not be distorted (racked) when pushed down.

All Milnor® Hydro-cushion™ machines contain the following suspension system components:

1. Hydro-cushion™ cylinder—which suspend the shell and cylinder within the frame and provide vibration damping during extraction.
2. Pneumatic push down devices (air bags)—which when inflated, force the shell downward where it is held against rigid pads during loading, unloading, washing, and draining.
3. Metal or rubber pads—some rigidly fixed to the shell and some rigidly fixed to the frame, which come in contact when the shell is pushed down.

The actual configuration of these components varies from model to model.

### 3.1.1 How Shell Adjustments are Made

BNWVUM01.T01 0000278202 D.2 B.2 A.2 3/3/20, 4:33 PM Released

Regardless of machine model, repositioning of the shell is always accomplished by adjusting the nuts at the top of the upper Hydro-cushion™ shafts. To move the shell up or down at the location of any Hydro-cushion™, see [Figure 47: Hydro-cushion™ Upper Shaft and Adjusting Nuts, page 100](#) and proceed as follows:




**CAUTION:** These procedures should be accomplished with power to the machine locked off.

1. Straighten the tongues on the keyed lock washer using pliers, screw driver, etc.
2. Loosen the lock nut (upper hex nut) and move it all the way up to the top of the shaft, but do not remove it.

3. Use the adjusting nut (lower hex nut) to “crank” the shaft up or down as required.
4. Once final adjustment is made, while holding the adjusting nut to prevent it from turning, re-tighten the lock nut against the adjusting nut (with the lock washer between).
5. Rebend the tongues on the lockwasher as before, to prevent movement of the nuts.

**Figure 47. Hydro-cushion™ Upper Shaft and Adjusting Nuts**



### 3.1.2 Shell Hanging Dimensions and Adjustment Procedures

BNWVUM01.T02 0000278201 D.2 B.2 2/5/21, 9:25 AM Released


To adjust the shell of a divided cylinder machine, proceed as follows:

1. Locate the shell hanging dimension for your machine in [Table 30: Hanging Dimensions, page 101](#) and adjust your machine accordingly. Take measurements on the left and right sides of the shell, to assure that the shell is horizontal, left to right.
2. The shell and cylinder should be level front to back. Check this with a bubble level, as shown in [Figure 48: Shell Hanging for Divided Cylinder Machines \(Left side view of 60044WE shown\), page 101](#) .
3. If further adjustment is required in order to level the cylinder, make small adjustments at all four corners. For example, if the cylinder slopes down to the front, try raising the two front corners by 1/16" (2mm) and lowering the two rear corners by 1/16" (2mm). Always split the difference.



**NOTE:** Only slight deviations from the dimensions shown should be used to level the shell. If large deviations are required, this may indicate that the frame is out of level. If so, this condition must be corrected before attempting to level the shell.

**Figure 48. Shell Hanging for Divided Cylinder Machines (Left side view of 60044WE shown)**



**Table 30. Hanging Dimensions**

| <b>Machine Model</b> | <b>Dimension A</b> |
|----------------------|--------------------|
| 42031WE              | 4 1/8" (105)       |
| 42031SG              | 4 1/8" (105)       |
| 44044WE              | 4 1/8" (105)       |
| 42044SG              | 4 1/8" (105)       |
| 60031WE              | 3 5/8" (92)        |
| 60031SG              | 3 5/8" (92)        |
| 60044WE              | 3 5/8" (92)        |
| 60044SG              | 3 5/8" (92)        |
| 72044SG              | 3 3/4" (95)        |
| 72044WE              | 3 3/4" (95)        |

### 3.1.3 Push-Down Travel Dimensions and Adjustment Procedures

BNWVUM01.C02 0000278454 D.2 B.2 A.2 3/5/20, 1:08 PM Released



**CAUTION:** Some of the following procedures require power to the machine. Take the necessary precautions to assure that no one operates the machine controls while personnel are adjusting the push-down components.

#### 3.1.3.1 42" Divided Cylinder Machines

BNWVUM01.T03 0000278453 D.2 B.2 A.3 3/6/20, 9:06 AM Released

The push-down stops on these machines consist of brackets attached to the shell and rubber rest pads, mounted atop the base pads (see [Figure 49: Push-down Travel Adjustment: 42" Div-cyls \(42" Staph Guard®\), page 103](#) ) which make contact when the shell pushes down. The rubber rest pads sit in metal pans and are raised or lowered by adding metal shims to or removing the shims from inside the pans. Extra shims and adhesive for securing the shims were supplied with your machine.


There is no specific push-down travel dimension for these machines; however, length of travel must be adjusted as follows:

1. With the **Master switch** set to **off**, and the shell hanging free, measure the gap between each bracket and base pad.
2. Add or remove shims from the appropriate pads as required to make all four gaps equal and to insure that no rest pad protrudes completely from its metal pan.

Test for equal length of travel at all four locations as follows:

3. With four sheet metal shims of **equal** thickness, set one shim **on top of** each rubber rest pad, such that at least a one inch length of the shim overhangs the outside edge of the pad.
4. Set the **Master switch** to **manual**, causing the shell to push-down.



**Figure 49. Push-down Travel Adjustment: 42" Div-cyls (42" Staph Guard®)**

5. With the shell pushed down, attempt to pull each test shim out from between the bracket and rubber pad. The test shims should all be tight. If any shim(s) are not pinched tightly between the bracket and pad, take note of which one(s) are not.

Make final adjustments as follows:

6. Set the **Master switch** to **off**, remove the test shims and make the necessary changes to the shims below the rubber pads as indicated by the above test.
7. Repeat Steps 3 through 6 as required, until this test is successful.
8. Once the adjustments are completed, secure all shims and rubber rest pads with the adhesive provided.

### 3.1.3.2 60" Divided Cylinder Machines


BNWVUM01.T04 0000278485 D.2 B.2 5/15/20, 10:18 AM Released

These machines have push-down stops on the four corners of the frame which appear as shown in [Figure 50: Ring Weldments, page 104](#) . When pushed down, the ring weldments (which move with the shell) must seat firmly onto the plugs which are mounted atop the base pads. The push-down travel dimension must assure that 1) the ring weldments and plugs are far enough apart when the shell is not pushed down, so as not to interfere with the free movement of the shell, and 2) that all four stops are in solid contact when the shell is pushed down. To accomplish this, proceed as follows:

1. With the **Master switch** set to **off** and the shell hanging free, remove the bolts securing the ring weldments to the mounting brackets. Set each ring weldment on top of its respective plug, removing any shims which may have been used and placing them next to the ring weldment.

2. Measure the gap between the top of the ring weldment and the bottom of the mounting bracket, at each location.

**Figure 50. Ring Weldments**



3. Stack shims on top of the ring weldment as required to make each gap **exactly 2 inches** as shown in the left side of [Figure 50: Ring Weldments, page 104](#) . If the gap at any location is less than 2 inches without shims, the shell must then be raised in the frame, using the procedures previously described.
4. Once the proper arrangement of shims is made, remount the ring weldment and shims to the mounting bracket (see the right side of [Figure 50: Ring Weldments, page 104](#) ). Any extra shims may be stacked on the top side of the mounting bracket plate to which the ring weldment is attached.


This page intentionally blank

# Hold Down Adjustment

6044SR2/SR3, 6044WR2/WR3, 72044SR2/SR3, 72044WR2/WR3



**NOTE:** For instruction: push down travel dimensions and adjustment procedures, see BNWVUM01



# Hold Down Adjustment

2 Sheets

6044SR2/SR3, 6044WR2/WR3, 72044SR2/SR3, 72044WR2/WR3

**Table 31. Parts List—Hold Down Adjustment**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| none  |      |             |                                |          |
| Components  |      |             |                                |          |
| all   | 2    | 03 06216A   | SHIM=HOLDOWN 1/4"THICK         |          |
| all   | 3    | 03 06216B   | SHIM=HOLDOWN 10GA THICK        |          |
| all   | 4    | 03 06216C   | SHIM=HOLDOWN 16GA THICK        |          |
| all   | 5    | W3 06406    | *RING=HOLD DOWN CENT-STAMPED   |          |
| all   | 6    | 15G238      | HXNUT 5/8-11UNC2B SAE ZINC GR2 |          |
| all   | 7    | 15U315      | LOKWASHER MEDIUM 5/8 ZINCPL    |          |
| all   | 8    | 15D125      | HXTAPSCR 5/8-11X4-FLTHRD GR5   |          |
| all   | 9    | 15K300      | HXCAPSCR 1-8UNC2A X4.5 SAE GR5 |          |


Push Down Components

72044WR2, SR2



**NOTE:** The 72044SR2 model is shown. The 72044WR2 repair parts are identical.

Figure 51. Push Down installation and pneumatic fittings




# Push Down Components

3 Sheets

72044WR2, SR2

Figure 52. Push Down installation and pneumatic fittings



### Legend

C . . . Typical

**Push Down Components**

3 Sheets

72044WR2, SR2

**Table 32. Parts List—Push Down Components**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                 |          |
|---|------|-------------|---------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature        | Comments |
| Reference Assemblies  |      |             |                                 |          |
|   | A    | AD 36 037   | PUSH DOWN MT ASSY 72SGH         | 72044SR2 |
|   | B    | AD 36 036   | PUSHDOWN MOUNTING ASSY=72WED    | 72044WR2 |
| Components  |      |             |                                 |          |
| all   | 1    | 60B120      | AIRMT S-20 2CONV F#W013586910   |          |
| all   | 2    | 03 06193    | UP PUSH BRKT 72W+S BEND@PRNT    |          |
| all   | 3    | 03 06193A   | ADJ.PLATE=20C AIRCUSHION        |          |
| all   | 4    | 69C050A     | POLYETHYLENE BAG 9X6X13X.005    |          |
| all   | 5    | 27A005      | MUFFLER 3/8" BANTAM B38         |          |
| all   | 6    | 96M055      | DELTROL QUICK EXHAUST VLV.1/4"  |          |
| all   | 7    | 5N0ECLSBE2  | NPT NIP 1/4XCLS TBE BRASS 125#  |          |
| all   | 8    | 96D026      | 1/4"GLOBEVAL BRZ125 STEAM       |          |
| all   | 9    | 51V015      | TEE 1/4 FGDBRASS 101T7-444      |          |
| all   | 10   | 51E507      | HOSESTEM BRASS 1/4MPX1/2HOSEID  |          |
| all   | 11   | 5N0E02KG42  | NPT NIP 1/4X2.5 TBEGALSTL SK40  |          |
| all   | 12   | 5SL0ENFA    | NPTEL B 90DEG 1/4 GALMAL 150#   |          |
| all   | 13   | 60E085A210  | HOSE- *AIR-1/2ID PE X210"LG     |          |
| all   | 14   | 27A090      | HOSECLAMP 13/16-1.5"CADSC#HS16  |          |
| all   | 15   | 15K191      | HXCAPSCR 1/2-13UNC2AX2.5 GR5 Z  |          |
| all   | 16   | 15G230      | HXNUT 1/2-13UNC2B SAE ZINC GR2  |          |
| all   | 17   | 15U280      | FL+WASHER(USS STD)1/2 ZNC PL+D  |          |
| all   | 18   | 15U300      | LOKWASHER REGULAR 1/2 ZINC PLT  |          |
| all   | 19   | 15U490      | FLTWASH 1+1/2X17/32X1/4 ZINC    |          |
| all   | 20   | 15K095      | HXCPCSCR 3/8-16UNC2AX1 GR5 ZINC |          |
| all   | 21   | 15U240      | FLATWASHER(USS STD) 3/8" ZNC P  |          |
| all   | 22   | 15U255      | LOCKWASHER MEDIUM 3/8 ZINCPL    |          |
| all   | 23   | 15K105      | HXCAPSCR 3/8-16UNC2A1.25 GR5 P  |          |




BPWVUJ01 / 2020032

BPWVUJ01.1 0000267484 D.2 A.5 1/13/20, 4:53 PM Released

Suspension Cylinder Assemblies

3 Sheets

42031,42044,52038,60044,72044



## Suspension Cylinder Assemblies

3 Sheets

42031,42044,52038,60044,72044

**Table 33. Parts List—Suspension Cylinder Assemblies**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.        |      |             |                                |                                   |
|--|------|-------------|--------------------------------|-----------------------------------|
| Used In  | Item | Part Number | Description/Nomenclature       | Comments                          |
| Reference Assemblies   |      |             |                                |                                   |
|  | B    | SA 16 039   | *HYDROCUSHION CYL ASSY-"B"     | CYLINDER ASSY B                   |
|  | C    | SA 16 038   | *HYDROCUSHION CYL ASSY-"C"     | CYLINDER ASSY C                   |
|  | D    | SA 28 091   | *HYDROCUSHION CYL ASSY-"D"     | CYLINDER ASSY D                   |
|  | F    | SA 36 021   | *HYDROCUSHION CYL ASSY-"F"     | CYLINDER ASSY F                   |
|  | G    | SA 36 023   | *HYDROCUSHION CYL ASSY-"G"     | CYLINDER ASSY G                   |
|  | H    | SA 36 047   | *HYDROCUSHION CYL ASSY-"H"     | CYLINDER ASSY H                   |
|  | K    | SA 29 031K  | *HYDROCUSHION CYL ASSY-"K"     | CYLINDER ASSY K                   |
| (To identify which cylinder is supplied with your machine, see BPVVUJ02 which should be located in the manual next to this document. Once you know which cylinder assembly you have, "B-K" listed above, identify your parts by referencing the "Used In" coding.) |      |             |                                |                                   |
| Components   |      |             |                                |                                   |
| ABCDK  | 1    | 02 18244    | BOLT=HYDCYL 27+7/8LG+KEYWAY    |                                   |
| K  | 1    | 02 18244A   | BOLT=HYDCYL 28+7/8LG+KEYWAY    |                                   |
| FGH  | 1    | 03 06201    | BOLT=HYDCYL 41+7/8LG+KEYWAY    |                                   |
| all  | 2    | 02 18840A   | UPCAP=HYDROCYL 42+52+60        |                                   |
| all  | 4    | 5SP0KGFSS   | NPT PLUG 1/2 SOSOLID GALSTL    |                                   |
| BC   | 5    | X2 15356    | PISTON=HYDROCYL 6"- 6 NOTCH    |                                   |
| DFGHK  | 5    | X2 18228    | PISTON=HYDROCYL 6"- 3 NOTCH    |                                   |
| all  | 6    | 5SP0GHFKM   | NPT PLUG 3/8"-HEXCSMAGNETIC ZN |                                   |
| FG   | 7A   | 03 06139    | SPRING=IN HYDRO CYL 331LB/IN   | FULL SPRING (PURPLE)              |
| G  | 7B   | 03 06139A   | SPRING=IN HYDRO CYL            | PLUS 1/2 SPRING "G" ONLY (PURPLE) |
| H  | 7C   | 03 06338    | SPRING INNER-GOLD 14"LONG      | GOLD                              |
| B  | 8    | 02 16068    | MAIN SPRING 212LB/IN RED       | RED                               |
| C  | 8    | 02 16125    | MAIN SPRING 300LB/IN BLACK     | BLACK                             |
| D  | 8    | 02 19039    | MAIN SPRING 480LB/IN GREEN     | GREEN                             |
| FG   | 8    | 03 06138    | SPRING=OUT HYDROCYL 667LB/IN   | ORANGE                            |
| G  | 8    | 03 06138A   | SPRING=OUT HYDRO CYL           | ORANGE                            |
| H  | 8    | 03 06337    | SPRING-OUTER-GOLD 14.5"LONG    | GOLD                              |
| K  | 8    | 03 09016    | MAIN SPRING 1035LB/IN BLUE     | BLUE                              |
| ABCDFG-K   | 9    | 02 18619    | BUSHING RETAINER + CAD         |                                   |
| H  | 9    | 03 06358    | BUSHING RETAINER.CAD           |                                   |
| all  | 10   | 15B237      | HXCAPSCR 1-8UNC2AX5.5 SAEGR5 Z |                                   |

## Suspension Cylinder Assemblies

3 Sheets


42031,42044,52038,60044,72044

**Table 33 Parts List—Suspension Cylinder Assemblies (cont'd.)**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                 |          |
|---|------|-------------|---------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature        | Comments |
| all   | 11   | 15G255A     | SQ NUT 1-8UNC2B SAE ZINC GR2    |          |
| all   | 12   | 15U400      | LOCKWASHER MEDIUM 1" ZINCPL     |          |
| all   | 13   | 60C159A     | ORING 5.475ID 1/4CS BN70 #433   |          |
| all   | 14   | 24S040      | SEAL URETHNE 1-7/16 2.25 13/32  |          |
| GH  | 15   | M2 18690    | LOWER CAP=HYDROCYL              |          |
| all   | 16   | 02 18839A   | MACHBUSH HYDRCYL CAP #433-OR    |          |
| BC  | 17   | SA 15 084   | *HYDCUSH CYL WLDMT (18"X/12")   |          |
| DI  | 17   | SA 28 090   | *HYDCUSH CYL WLDMT (18"/23")    |          |
| FGH   | 17   | W3 06203    | *HYDCUSH CYL WLDMT (35"/12")    |          |
| K   | 17   | W2 18233    | *HYDCUSH CYL WLDMT (20"X22")    |          |
| all   | 18   | 02 175034   | SHIELD-BALLBUSH-4/HYDRO MACH    |          |
| BDFGH   | 19   | 02 02230    | 6 WATER BARRIER (NEOPRENE)      |          |
| all   | 30   | 15G268      | HXFJNUT 1+1/2-12UNF2B ZINC      |          |
| all   | 31   | 02 18571A   | PISTON ROD WASHER-.25"TK        |          |
| all   | 32   | X3 06252    | RETAINER-BALBUSH=4/72WEDU       |          |
| all   | 33   | 54M025      | HYDFIT 1/8"-90 ALEMITE 1613-B   |          |
| all   | 34   | 27B240      | SPCRROLL.5ID.813L.062T STLZNC   |          |
| all   | 35   | 02 18534    | HOLDPLATE= BALLBUSH ZNC/CAD     |          |
| all   | 36   | 15G230      | HXNUT 1/2-13UNC2B SAE ZINC GR2  |          |
| F   | 37   | Y3 06200    | SPACER=HYDRO-CUSHION CYL-MACH   |          |
| all   | 38   | 15K203      | HXTAPSCR TFL 1/2-13X5 GR5 ZINC  |          |
| all   | 39   | 54A705      | BALBRUSH 1.5 SKF#GEZ108ESAVE467 |          |
| all   | 40   | 15N037      | HXCAPSCR 1/2-13UNC2AX6.5 GR5 Z  |          |
| all   | 41   | 02 18256    | LOKWASH-TONGUE 8/WEH ZINC       |          |
| all   | 42   | 15K202      | HEXCAPSCR 1/2-13UNC2AX5 GR5 ZIN |          |
| all   | 43   | 15U300      | LOKWASHER REGULAR 1/2 ZINC PLT  |          |
| all   | 44   | 15G231      | HXFJNUT 1/2-13UNC2B ZINC G      |          |
| all   | 45   | 02 18534    | HOLDPLATE= BALLBRUSH ZNC/CAD    |          |
| all   | 46A  | 02 18795A   | WASH-TIMING=HYDRO CYL 45DEG     | USE ONE  |
| all   | 46B  | 02 18795B   | WASH-TIMING=HYDRO CYL 75DEG     | USE ONE  |
| all   | 47   | 15K191      | HXCAPSCR 1/2-13UNC2AX2.5 GR5 Z  |          |
| FGH   | 48   | AVH52001    | ASSY=OILFIL SPOUT 72HYD CYL     |          |

# Suspension Cylinder Locations

2 Sheets



### Legend

- C1 . . Cylinder #1
- C2 . . Cylinder #2
- C3 . . Cylinder #3
- C4 . . Cylinder #4
- E . . . Front or soil side
- J . . . A letter is stamped on the end of the upper bolt to designate the cylinder assembly.

## Suspension Cylinder Locations

2 Sheets



**NOTE:** See BPWVUJ01. For repair parts: hydrocushion cylinder assembly “B” through hydrocushion cylinder assembly “K”

| Machine Models: |                        |                |                             |                    |                              |                    |                                     |                    |                       |
|-----------------|------------------------|----------------|-----------------------------|--------------------|------------------------------|--------------------|-------------------------------------|--------------------|-----------------------|
| Position        | 42031 CP2,NP2, WP2,WP3 | 42031 SP2, SP3 | 42044 CP2, NP2,WP2, WP3,D7P | 42044 SP2/3; SR2/3 | 42044 WP2 SM, WP3 SM WR2,WR3 | 52038 WTL,WTN, WP1 | 60044 WP2/3 SM SP2/3 SM WR2/3 SR2/3 | 72044 WP2,WP3, DA1 | 72044 SP2,SP3 SR2/SR3 |
| Cylinder #1     | B                      | B              | C                           | C                  | C                            | D                  | K                                   | H                  | G                     |
| Cylinder #2     | B                      | C              | B                           | C                  | C                            | D                  | K                                   | H                  | G                     |
| Cylinder #3     | B                      | C              | B                           | C                  | C                            | D                  | K                                   | F                  | G                     |
| Cylinder #4     | B                      | C              | C                           | C                  | C                            | D                  | K                                   | F                  | G                     |


# 4 Shell, Cylinder & Door

This page intentionally blank

Shell Doors

72044WR3, 72044SR2

Figure 53. Exploded Views



**Adjust the Pressure Plate**

- 1 . . . With the inner tubes deflated, tighten the tension nut (item 30), until two threads extend beyond the nut.
- 2 . . . Check the spring with air pressure applied to the inner tubes. Verify that the spring is not over compressed. If the spring height is only 3/4", it will be necessary to loosen the tension nut.



**NOTE:** The door spring should be slightly compressed. If the spring is compressed too much the air bags will not be able to inflate and properly seal the door.

**Legend**

- A-A** . . . Detail view A-A
- B** . . . 24 instances
- C** . . . Liner
- D** . . . Door gasket
- E** . . . Tabs: Fold gasket tabs over the edge of the door and anchor with holding strips (item 33) and screws on the final assembly.
- F** . . . Fill plate
- G** . . . Apply glue (4) to both surfaces
- H** . . . Pressure plate




# Shell Doors

4 Sheets

72044WR3, 72044SR2

**Figure 54. Detail View**



**Table 34. Parts List—Shell Doors**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |   |
|---|------|-------------|--------------------------------|---|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments                                |
| Reference Assemblies  |      |             |                                |   |
|   | A    | SA 36 019   | *SHELL DOOR ASY 72WE3+SG SOIL  | 7244WR3                                 |
|   | B    | SA 36 020   | *SHELL DOOR ASY 72SG CLEAN     | 7244SR2 SOIL SIDE<br>7244SR2 CLEAN SIDE |
| Components  |      |             |                                |   |
| A   | 1    | W3 06126    | * SHELLDOOR 72SG2+3 SOILSIDE   |   |
| B   | 1    | W3 06127    | * SHELLDOOR 72SG2+3 CLEANSID   |   |
| A   | 2    | W3 06304B   | WLDMT=PRESSPLT DR 72SG SOIL    |   |
| B   | 2    | W3 06303B   | WLDMT=PRESSPLT DR 72SG CLEAN   |   |
| all   | 3    | 60A006P     | PORON STRIP .25X1 1/4# W E=FT  |   |
| all   | 4    | 20C044      | RUB/GASKET ADH 3M#EC1300 PINTS |   |
| all   | 5    | X3 06130C   | FILL-PLATE=SHELLDOOR           |   |
| all   | 6    | 03 06130    | GASKET=SHELL DOOR 2/72SG       |   |
| all   | 7    | 03 06130A   | LINER=SHELLDOOR RT 72SGD SS    |   |
| all   | 8    | 15K039A     | BUTSOKCPSCR 1/4-20X7/8 SS 18-8 |   |
| all   | 9    | 15G164      | HX THIN LOCKNUT NYL 1/4-20 SS  |   |
| all   | 10   | 03 06302    | BAR=GASKET CLAMPING            |   |
| all   | 11   | 15N174      | HXCAPSCR 1/4-20UNC X5/8SS18-8  |   |
| all   | 12   | 15U181      | LOCKWASHER MEDIUM 1/4 SS18-8   |   |
| all   | 13   | 03 06225G   | DOORTUBE-72SGA-OURTUBE         |   |

**Shell Doors**

72044WR3, 72044SR2

**Table 34 Parts List—Shell Doors (cont'd.)**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| all   | 14   | 02 18981G   | DOOR TUBE-60SGH-PRES. TUBE E   |          |
| all   | 15   | 02 18181    | FITTING-BRASS FOR INNER TUBE   |          |
| all   | 16   | 60E004TE    | 1/4"OD X.170"ID NYL(BLK)TUBING |          |
| all   | 17   | 53A047H     | MALCON 5/16X1/8POLY PH#68P-5-2 |          |
| all   | 18   | 51V010      | TEE PIPE 1/8 BRASS FORGING TYP |          |
| all   | 19   | 53A031XB    | BODY-EL90MALE.25X25 #269C-4-4B |          |
| all   | 20   | 53A500      | SLEEVE DELRIN 1/4"OD#60PT-4    |          |
| all   | 21   | 53A501      | TUBE INSERT .163"OD #63PT-4-40 |          |
| all   | 22   | 53A059A     | NUT 1/4"BR.HOLYOKE AND #61A-4  |          |
| all   | 23   | 12P016      | CABLE CLMP-BLACK UL APPROVED   |          |
| all   | 24   | SA 15 028   | * DOOR LATCH ASSY-DIVCYLS      |          |
| all   | 25   | 02 15633S   | ADJPLATE=DOORLATCH SS          |          |
| all   | 26   | 15U255      | LOCKWASHER MEDIUM 3/8 ZINCPL   |          |
| all   | 27   | 15K085      | HEXCAPSCR 3/8-16UNC2AX3/4 GR5  |          |
| all   | 28   | 01 09028    | SPRING=BRAKE.88OD2.5FL95#/"    |          |
| all   | 29   | 15U280      | FL+WASHER(USS STD)1/2 ZNC PL+D |          |
| all   | 30   | 15G234      | LOKNUT 1/2-13NC CAD FLXLOC#21F |          |
| all   | 31   | 01 10020    | NPLT SMALL "MILNOR" LOGO       |          |
| all   | 32   | 15P010      | TRDCUT PHILPANHDSCR 10-24X1/2S |          |
| all   | 33   | 02 175231   | PLATE=SHELL DOOR GASKET        |          |
| all   | 34   | 03 06137    | HINGE PIN 72 SG2,SG3,WE2&WE3   |          |
| all   | 35   | 03 06136    | WASHER,BRG BACKUP 72SG         |          |
| all   | 36   | 54A974975   | TIM #L68111/L68149-1.3775"BORE |          |
| all   | 37   | X3 06146    | BEARING ADAPTER 60&72 SG DR.   |          |
| all   | 38   | 54M021      | GRSFIT 1/8PIPE X 1/4STR 1607-B |          |
| all   | 39   | 54JH15500A  | HINGE COL SPLIT 5.50 FL TOP    |          |
| all   | 40   | 15K045E     | SKCPSCR 1/4-20X2 BLK           |          |
| all   | 41   | 15Q091      | SOKSETSCR CUP1/4-20X5/8BLK     |          |
| all   | 42   | 03 06132    | BUSHING,HINGE PIN 60&72 SG     |          |
| all   | 43   | 15U314      | FLATWASHER(USS STD) 5/8" ZNC P |          |
| all   | 44   | 15U521      | SPRINGWSHR.630ID 1.250D.051T   |          |
| all   | 45   | 15K214E     | HXCAPSCR 5/8-11UNC2AX1.5 GR5 Z |          |

BPWG4D02 / 2020034

BPWG4D02.1 0000267678 D.2 A.2 1/15/20, 9:51 AM Released

Door Latch

1 Sheet




Table 35. Parts List—Door Latch

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.


| Used In              | Item | Part Number | Description/Nomenclature | Comments |
|----------------------|------|-------------|--------------------------|----------|
| Reference Assemblies |      |             |                          |          |
|                      | A    | SA 15 028   | Assembly, Door latch     |          |
| Components           |      |             |                          |          |
| all                  | 1    | 02 15105    | RETAINER RING            |          |
| all                  | 2    | 02 15297    | STRIKER                  |          |
| all                  | 3    | 02 15298    | CYLINDER                 |          |
| all                  | 4    | 02 15836    | SPRING                   |          |
| all                  | 5    | 15H090      | PIN                      |          |
| all                  | 6    | 60C122      | O-RING, 1"X1/8           |          |
| all                  | 7    | 60C128      | O-RING, 1+3/8X1/8        |          |

# Cylinder Assembly and Cylinder Door Installation

5 Sheets

6044SR2, 7244SR2

Figure 55. Cylinder Assembly and Cylinder Door Installation




# Cylinder Assembly and Cylinder Door Installation

5 Sheets

6044SR2, 7244SR2

Figure 56. Cylinder Doors Installed



Large Door

Small Door

Legend


G. . . See detail A & B

# Cylinder Assembly and Cylinder Door Installation

5 Sheets

6044SR2, 7244SR2


Figure 57. Detail Views



# Cylinder Assembly and Cylinder Door Installation

5 Sheets

6044SR2, 7244SR2



**Table 36. Parts List—Cylinder Assembly and Cylinder Door Installation**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                               |          |
|---|------|-------------|-------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature      | Comments |
|   | A    | REFERENCE   |                               | 6044SR2  |
|   | B    | REFERENCE   |                               | 7244SR2  |
| Components  |      |             |                               |          |
| A   | 1    | ACA19SG2A   | * CYL ASSY=6044SG2 WELD/SHAFT |          |
| B   | 1    | ACA36SG2A   | * CYL ASSY=7244SG2 WELD/SHAFT |          |
| A   | 3    | SA 28 110   | CYLDOOR LOLT 60WE2+ MIN-REIF  |          |
| B   | 3    | SA 36 003   | CYLDOOR LOLT 72WE2+ MAX-REIF  |          |
| A   | 4    | SA 28 111   | CYLDOOR UPLT 60WE2+ MIN-REIF  |          |
| B   | 4    | SA 36 004   | CYLDOOR UPLT 72WE2+ MAX-REIF  |          |
| A   | 5    | SA 28 112   | CYLDOOR LORT 60WE2+ MIN-REIF  |          |
| B   | 5    | SA 36 001   | CYLDOOR LORT 72WE2+ MAX-REIF  |          |
| all   | 6    | SA 28 116   | CYLDOR ASY,SMALL =60+72SG2    |          |
| A   | 7    | X3 06166    | KEEPER=CYL DOOR LATCH(MONEL)  |          |
| B   | 7    | X2 15201    | KEEPER=CYLDOOR LATCH(MONEL)   |          |
| all   | 8    | 02 19183    | COVER-DOORLATCH KEEP-OURMATL  |          |
| all   | 9    | 03 06174    | KEEPER=DOORLATCH REINFORCE    |          |
| all   | 10   | 02 18977A   | SHIM=CYL DRLATCH KEEPER-11GA  |          |
| all   | 10   | 02 18977B   | SHIM=CYL DRLATCH KEEPER-14GA  |          |
| all   | 10   | 02 18977C   | SHIM=CYL DRLATCH KEEPER-18GA  |          |
| all   | 11   | X3 06166    | KEEPER=CYL DOOR LATCH(MONEL)  |          |
| all   | 12   | 03 06167    | COVER-LARGE CYLDOOR KEEPER    |          |
| all   | 13   | 15A015      | CARRSCR 3/8-16X1+1/4 18-8 SS  |          |
| all   | 14   | 15G206      | HEXNUT 3/8-16 UNC2 SS 18-8    |          |

## Cylinder Assembly and Cylinder Door Installation

5 Sheets

6044SR2, 7244SR2

Table 36 Parts List—Cylinder Assembly and Cylinder Door Installation (cont'd.)

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |                       |
|---|------|-------------|--------------------------------|-----------------------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments              |
| all   | 15   | 15U260      | LOCKWASHER MEDIUM 3/8 SS18-8   |                       |
| all   | 16   | 15K086      | HXCAPSCR 3/8-16NCX3/4 SS18-8   |                       |
| all   | 17   | 15K106E     | BUTSOKCAPSCR 3/8-16NCX1+1/2 SS |                       |
| all   | 18   | 03 06156    | SPRING=LARGE CYLDOOR LATCH     |                       |
| all   | 19   | X3 06152    | PLATE = LARGE DOORLATCH        |                       |
| all   | 20   | 03 06151    | LATCHBODY-LARGE=CYLDOOR        |                       |
| all   | 21   | X3 06150    | PLUNGER=LARGE CYLDOOR(CAST)    |                       |
| all   | 22   | 03 06172    | SHIM=DOOR LATCH-18GA           |                       |
| all   | 23   | 03 06173A   | SHIM=DOOR LATCH-11GA           |                       |
| all   | 24   | 02 18869    | SPACER-LATCH PULL BND@PRNT     |                       |
| all   | 25   | 15K042      | BUTSOKCAPSCR 1/4-20NCX1 SS18-8 |                       |
| all   | 26   | 15U181      | LOCKWASHER MEDIUM 1/4 SS18-8   |                       |
| all   | 27   | 15G170      | HEXNUT 1/4-20UNC2 SS18-8       |                       |
| all   | 28   | 15K042K     | BUTSOKCAPSCR 1/4-20UNCX1+1/4 S |                       |
| all   | 29   | 02 15040    | PLUNGER=CYLDOOR LATCH(CAST)    |                       |
| all   | 30   | 02 15041    | BODY=CYLDOOR LATCH             |                       |
| all   | 31   | 02 15077    | PLATE = SMALL DOORLATCH        |                       |
| all   | 32   | 02 15093    | SPRING=DOOR LATCH 9.4#/INCH    |                       |
| all   | 33   | 15N173      | FLATMACSCR 1/4-20NCX5/8SS18-8  |                       |
| all   | 34   | 15N158      | HEXCAPSCR 1/4-20NCX1/2SS18-8   |                       |
| all   | 35   | 02 18990    | PLATE=STOP + COVER 2/60+72WD   |                       |
| all   | 36   | 02 18864    | PIN=LG CYL DOOR HINGE          | LARGE PIN             |
| all   | 37   | W2 18855    | WLMT=HINGE LRG CYL DR MULT     | USED WITH ITEMS 3 & 5 |
| all   | 37   | W2 18866    | WLMT=HINGE LRG CYL DR 2/60WE   | USED WITH ITEM 4      |
| all   | 38   | 02 18865    | PIN=SM CYL DOOR HINGE          | SMALL PIN             |
| all   | 39   | 02 18858    | HALFHINGE=60"WED CYLDOR SMAL   |                       |
| all   | 40   | 02 18989    | PLATE-LATCH MTG2/WED+2/SGD     |                       |



BPWG7D02 / 2020253


BPWG7D02.1 0000295477 D.2 A.7 6/16/20, 11:17 AM Released

**Cylinder Doors 3 pocket**

5 Sheets

7244WR3, 7244SR3

**Figure 58. Section Views**




### Cylinder Doors 3 pocket

5 Sheets

7244WR3, 7244SR3

Figure 59. Cylinder Doors



**Legend**


G . . . Large doors

**Cylinder Doors 3 pocket**

5 Sheets

7244WR3, 7244SR3

**Figure 60. Additional Views**



**Legend**

- F** . . . Shims
- H** . . . Uses 3
- J** . . . 2 instances
- K** . . . 6 instances

**Cylinder Doors 3 pocket**

5 Sheets

7244WR3, 7244SR3

**Table 37. Parts List—Cylinder Doors 3 pocket**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| Reference Assemblies  |      |             |                                |          |
|   | A    | ACA36SG3A   | * CYL ASSY=7244SG3 WELD/SHAFT  |          |
| Components  |      |             |                                |          |
| all   | 1    | Y3 06162    | MAINSHAFT 7244SG2+3            |          |
| all   | 2    | SA 36 003   | CYLDOOR LOLT 72WE2+ MAX-REIF   |          |
| all   | 3    | SA 36 001   | CYLDOOR LORT 72WE2+ MAX-REIF   |          |
| all   | 4    | SA 36 004   | CYLDOOR UPLT 72WE2+ MAX-REIF   |          |
| all   | 5    | SA 28 116   | * CYLDOR ASY,SMALL =60+72SG2   |          |
| all   | 6    | X2 15201    | KEEPER=CYLDOOR LATCH(MONEL)    |          |
| all   | 7    | 02 19183    | COVER-DOORLATCH KEEP-OURMATL   |          |
| all   | 8    | 03 06174    | KEEPER=DOORLATCH REINFORCE     |          |
| all   | 9    | 02 18962    | STOP=CYLDOOR=42WEHU            |          |
| all   | 10   | 02 18977A   | SHIM=CYL DRLATCH KEEPER-11GA   |          |
| all   | 11   | 02 18977B   | SHIM=CYL DRLATCH KEEPER-14GA   |          |
| all   | 12   | 02 18977C   | SHIM=CYL DRLATCH KEEPER-18GA   |          |
| all   | 13   | 15K106E     | BUTSOKCAPSCR 3/8-16NCX1+1/2 SS |          |
| all   | 14   | 15U260      | LOCKWASHER MEDIUM 3/8 SS18-8   |          |
| all   | 15   | 15G206      | HEXNUT 3/8-16 UNC2 SS 18-8     |          |
| all   | 16   | 15A015      | CARRSCR 3/8-16X1+1/4 18-8 SS   |          |
| all   | 17   | 15K086      | HXCAPSCR 3/8-16NCX3/4 SS18-8   |          |
| all   | 18   | X3 06166    | KEEPER=CYL DOOR LATCH(MONEL)   |          |
| all   | 19   | 03 06167    | COVER-LARGE CYLDOOR KEEPER     |          |
| all   | 20   | 15K084S     | HXCAPSCR 3/8-16NCX5/8 SS18-8   |          |
| all   | 21   | 02 18818    | CYL DOOR SM 60+72 WEDU         |          |
| all   | 22   | 02 18854    | PLATE=SM CYLDOOR REINFORCING   |          |
| all   | 23   | 02 18991    | PULL=DOORLATCH 2/WED+4/SGD     |          |
| all   | 24   | 02 18865    | PIN=SM CYL DOOR HINGE          |          |
| all   | 25   | W2 18858    | WLMT=HINGE SM CYL DR 2/60WED   |          |
| all   | 26   | 02 15040    | PLUNGER=CYLDOOR LATCH(CAST)    |          |
| all   | 27   | 02 15093    | SPRING=DOOR LATCH 9.4#/INCH    |          |
| all   | 28   | 02 18990    | PLATE=STOP + COVER 2/60+72WD   |          |
| all   | 29   | 02 18989    | PLATE-LATCH MTG2/WED+2/SGD     |          |
| all   | 30   | 02 15077    | PLATE = SMALL DOORLATCH        |          |
| all   | 31   | 02 15041    | BODY=CYLDOOR LATCH             |          |

**Cylinder Doors 3 pocket**

5 Sheets

7244WR3, 7244SR3

**Table 37 Parts List—Cylinder Doors 3 pocket (cont'd.)**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| all   | 32   | 15N158      | HEXCAPSCR 1/4-20NCX1/2SS18-8   |          |
| all   | 33   | 15U181      | LOCKWASHER MEDIUM 1/4 SS18-8   |          |
| all   | 34   | 15G170      | HEXNUT 1/4-20UNC2 SS18-8       |          |
| all   | 35   | 15N173      | FLATMACSCR 1/4-20NCX5/8SS18-8  |          |
| all   | 36   | 03 06035    | PIN=CYL DOOR HINGE 72WED       |          |
| all   | 37   | W3 06031    | WLMT=HINGE HALF 72WED CYL DR   |          |
| all   | 38   | 02 18869    | SPACER-LATCH PULL BND@PRNT     |          |
| all   | 39   | 03 06156    | SPRING=LARGE CYLDOOR LATCH     |          |
| all   | 40   | X3 06152    | PLATE = LARGE DOORLATCH        |          |
| all   | 41   | 03 06151    | LATCHBODY-LARGE=CYLDOOR        |          |
| all   | 42   | X3 06150    | PLUNGER=LARGE CYLDOOR(CAST)    |          |
| all   | 43   | 15K042K     | BUTSOKCAPSCR 1/4-20UNCX1+1/4 S |          |
| all   | 44   | 15K042      | BUTSOKCAPSCR 1/4-20NCX1 SS18-8 |          |
| all   | 47   | 03 06173A   | SHIM=DOOR LATCH-11GA           |          |
| all   | 48   | 03 06172    | SHIM=DOOR LATCH-18GA           |          |
| all   | 49   | 03 06317    | STOP=CYLINDER DOOR LATCH       |          |

# 5 Staph Guard®

This page intentionally blank


BPWG6P01 / 2020192

BPWG6P01.1 0000290411 D.2 A.4 5/4/20, 11:33 AM Released

# Staph Barrier Cleanside

2 Sheets

6044SR2, 72044SR2





## Staph Barrier Cleanside

2 Sheets

6044SR2, 72044SR2

Table 38. Parts List—Staph Barrier Cleanside


| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                               |          |
|---|------|-------------|-------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature      | Comments |
| Reference Assemblies  |      |             |                               |          |
|   | A    | GBF60001    | STAPH BARRIER CS 60SG         | 6044SR2  |
|   | B    | GBF72001    | STAPH BARRIER CS 72SG         | 6044SR2  |
| Components  |      |             |                               |          |
| all   | 1    | 02 18781T   | EXTRUSION SHELL CS LF 72SG    |          |
| all   | 2    | 02 18781V   | EXTRUSION SHELL CS RT 72SG    |          |
| all   | 3    | 02 18781W   | EXTRUSION FRAME CS LF 72SG    |          |
| all   | 4    | 02 18781X   | EXTRUSION FRAME CS RT 72SG    |          |
| all   | 5    | 03 06105    | BOOT ASSEMBLY=72SGH OUR MATL  |          |
| all   | 6    | 02 175032   | CLAMP BOOT 60142 +60SG        |          |
| all   | 7    | 15P175      | TRDCUT-F HXHD 1/4-20UNC2AX1/2 |          |
| B   | 8    | 02 21677    | CLAMP=BOOT SHLFRT SEAM 3630S  |          |

# Staphairtol

3 Sheets

60044SR2, 72044SR2

Figure 61. Exploded View




# Staphairtrol

3 Sheets

60044SR2, 72044SR2

**Figure 62. Installed View**



**Legend**

- A** . . . Exhaust, soil side
- B** . . . Intake, clean side

**Table 39. Parts List—Staphairtrol**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

| Used In              | Item | Part Number | Description/Nomenclature       | Comments |
|----------------------|------|-------------|--------------------------------|----------|
| Reference Assemblies |      |             |                                |          |
|                      | A    | SA 28 126   | * STAPHAIRTROL 6" #60+72SGU    |          |
| Components           |      |             |                                |          |
| all                  | 1    | W2 18975    | * WLMT,AIRTROL BODY =60+72SGU  |          |
| all                  | 2    | W2 18973    | * WLMT,AIRTROL EXHAUST =60+72  |          |
| all                  | 3    | W2 18974    | * WLMT,AIRTROL INTAKE=60+72SG  |          |
| all                  | 4    | 02 15714    | AIR TROL FLAPPER               |          |
| all                  | 5    | 02 18930    | PLATE-AIRTROL FLAPPER          |          |
| all                  | 6    | 02 175025   | PLATE-BACKUP=AIRTROL FLAPPER   |          |
| all                  | 7    | 15P010      | TRDCUT PHILPANHDSCR 10-24X1/2S |          |
| all                  | 8    | 15G071      | MACHSCRLOKNUT 6-32 NM SER ZINC |          |
| all                  | 9    | 15U131L     | FLATWASH #10L (US STD) BRASS   |          |
| all                  | 10   | 15N050      | RDMACSCR 6-32UNC2X1/2 SS18-8   |          |

**Staphairtrol**

60044SR2, 72044SR2

**Table 39 Parts List—Staphairtrol (cont'd.)**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| all   | 11   | 15N141      | RDMACSCR 10-24NCX3/4 SLOTTED S |          |
| all   | 12   | 15G130      | HEXMACHSCRNUT 10-24UNC2 SS18-8 |          |
| all   | 13   | 60E320A18A  | HOSE *6"ID FLEXAUST PE X 18"   |          |
| all   | 14   | 27A083      | HOSECLAMP 5+1/8-7"CADSCR#HS104 |          |
| all   | 15   | 60E320A30A  | HOSE *6"ID FLEXAUST PE X 30"   |          |
| all   | 16   | 03 06199A   | BRT=AIRTROL+VENT MT. BD@PRT.   |          |
| all   | 17   | W2 18496    | * WLMT,AIRTROL INSCREEN=60+72  |          |
| all   | 18   | 15K039      | HXCAPSCR 1/4-20UNC2AX3/4 GR5 Z |          |
| all   | 19   | 15U185      | FLATWASHER(USS STD) 1/4" ZNC P |          |
| all   | 20   | 15G165      | HXNUT 1/4-20UNC2BSAE ZC GR2    |          |
| all   | 21   | 15K153      | HXCAPSCR 1/2 -13 X 1 +1/4 SS   |          |
| all   | 22   | 15U310      | LOKWASHER REGULAR 1/2 SS18-8   |          |
| all   | 23   | 15G225      | HEXNUT 1/2-13UNC2 SS18-8       |          |


# 6 Control & Sensing

# Air Operated Autospot and Sensing Unit

4 Sheets

72044SR2

Figure 63. Sensing Unit Installation and Drive Components




## Air Operated Autospot and Sensing Unit

4 Sheets

72044SR2

Figure 64. Sensing Unit: Switch Assembly and Cam



## Air Operated Autospot and Sensing Unit

4 Sheets

72044SR2

Table 40. Parts List—Air Operated Autospot and Sensing Unit

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |   |              |
|---|------|-------------|---|--------------|
| Used In   | Item | Part Number | Description/Nomenclature                | Comments     |
| Reference Assemblies  |      |             |   |              |
|   | A    | G36 06700   | AIROP AUTOSPOT ASSEMBLY-72SG2           | REFERENCE    |
|   | B    | E36 00300   | * SENSE UNIT AUTOSPOT 72SG2             | INSTALLATION |
|   | C    | E15 03000   | \$ BASIC 2-SWITCH AUTOSPOT ASY          | SWITCH       |
|   | D    | E15 03100   | \$CAM AS42WE2+SG2+DY2+60-72SG2          | CAM          |
| Components  |      |             |   |              |
| A   | 1    | 54X020      | SYNCHRONUS GEARBELT SPRKT               |              |
| A   | 2    | 56Q0MHS     | .627" BUSH VPUL TYPE H,D,OR QT"SPECIAL" |              |
| A   | 3    | 12H050      | HANDYBOX 4X2+1/8X2+1/8                  |              |
| A   | 4    | 12H095      | HANDY BOX COVER 4+2+1/8                 |              |
| A   | 5    | 54C100      | GEARBLT SYNC-COG DAYCO#420L050          |              |
| A   | 6    | 02 10191    | PULLEY-TIMING-DRIVER                    |              |
| A   | 7    | 15E007      | KEY #7 WOODRUFF 3/4X1/8 SAE103          |              |
| B   | 8    | 03 06415    | LONG SUPPORT=72SG AIROP AS              |              |
| B   | 9    | 03 06414    | SHORT SUPPORT=72SG AIROP AS             |              |
| B   | 10   | 03 06412    | STIFFENER=AIROP AUTOSPOT-SG             |              |
| B   | 11   | 03 06413    | MTG PLATE=72SG AIROP ASS                |              |
| B   | 12   | 03 01344    | COVER=AIROP AUTOSPOT                    |              |
| B   | 13   | 03 01329    | SHAFT=AIROPAUTOSPOT OUR MATL            |              |
| B   | 14   | 02 10508    | BEARING HOUSING- PLATED- ZINC           |              |
| B   | 15   | 03 IF2X3    | INSUL.AUTOSPOT/CENTRIFUGL.SW            |              |
| B   | 16   | 02 02463    | SPRING-CHART HOLDING                    |              |
| B   | 17   | 15P175      | TRDCUT-F HXHD 1/4-20UNC2AX1/2           |              |
| B   | 18   | 02 10507    | BEARING HOUSING- CUP- PLATED            |              |
| B   | 19   | 15N140      | RDMACSCR 10-24UNC2AX3/4 ZINC G          |              |
| B   | 20   | 15G125      | HXMACHSCRNUT 10-24UNC2B ZINC G          |              |
| all   | 21   | 15U150      | LOCKWASHER MEDIUM #10 ZINCPL            |              |
| all   | 22   | 15N125      | RDMACSCR 10-24UNC2AX1/2 ZC GR2          |              |
| all   | 23   | 15G219NTE   | HXTHINLOKNUT 3/8-24NF NYL STL/          |              |
| B   | 24   | 15U238      | LOKWAS INTOOTH 3/8" (US STD) 4          |              |
| B   | 25   | 03 01328    | HOUSING=AIROP AUTOSPOT                  |              |
| B   | 26   | 15K095      | HXCPSCR 3/8-16UNC2AX1 GR5 ZINC          |              |
| B   | 27   | 15G205      | HXNUT 3/8-16UNC2B ZINC GR2              |              |
| B   | 28   | 15U255      | LOCKWASHER MEDIUM 3/8 ZINCPL            |              |



## Air Operated Autospot and Sensing Unit

4 Sheets


72044SR2

Table 40 Parts List—Air Operated Autospot and Sensing Unit (cont'd.)

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                   |          |
|---|------|-------------|-----------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature          | Comments |
| C   | 30   | 03 01343    | SCREW-ADJ=AIROP AUTOSPOT          |          |
| C   | 31   | 15G177      | HXNUT 1/4-28UNF2B SAE ZINC GR2    |          |
| C   | 32   | 03 01336    | BKT-AIRCYL=AIRAUTOSPOT            |          |
| C   | 33   | 27C205      | AIRCYL 3/4"BORE X 1"STROKE        |          |
| C   | 34   | 53A031B     | BODY-EL90MALE.25X1/8 #269C-42B    |          |
| C   | 35   | 03 01357    | PIVOT-SPRING=AIROP AUTOSPOT       |          |
| C   | 36   | 17B006      | EXTRETRING IND#1000-25-ST-ZD Z    |          |
| C   | 37   | 03 01333    | PIVOT=AIRCYL=AIROP AUTOSPOT       |          |
| C   | 38   | 03 01332    | SUPPORT=AIROP AUTOSPOT            |          |
| C   | 39   | 15K020      | SKCPSCR 10-24 UNC 3AX3/4 ALLOY    |          |
| C   | 40   | 15U131L     | FLATWASH #10L (US STD) BRASS      |          |
| C   | 41   | 15N019      | RDMACSCR 4-40UNC2AX5/8 ZINC GR    |          |
| C   | 42   | 15U040      | LOCKWASHER MEDIUM #4 ZINCPL       |          |
| C   | 43   | 03 01335    | INSULATOR=AIROP AUTOSPOT+\$8S     |          |
| C   | 44   | 09R014A     | MINI-SW SPDT STAKON #V-15G-1C26-K |          |
| C   | 45   | 09R015      | ACTUATOR MICRO SWITCH #JV-5       |          |
| C   | 45   | 03 01356    | SHAFT-PIVOT=AIROP AUTOSPOT        |          |
| C   | 47   | 15G195      | HXNUT 5/16-24UNF2B SAE ZINC GR    |          |
| C   | 48   | 15U210      | LOKWASHER MEDIUM 5/16 ZINCPL      |          |
| C   | 49   | 54E005      | FLGMTBRG 3/8X1/2X1/2 B#FB68-4     |          |
| C   | 50   | 54E007      | PLNBRG 3/8X1/2X3/4 B#6-8-6        |          |
| C   | 51   | 03 01355    | SPRING=EXT=AIROP AUTOSPOT         |          |
| C   | 52   | 15N154B     | FILMACSCR 10-24UNC2AX2 ZINC GR    |          |
| C   | 53   | 27B207      | SPCRROLL.202ID.688L.027T STLZC    |          |
| C   | 54   | 12P1AHSB    | SNAPBUSH .437"MH X .312" T=1/8    |          |
| C   | 55   | 03 01330    | ARM=SWLEVER=AIROP AUTOSPOT        |          |
| C   | 56   | 15G131      | HXLIGHTLOKNUT 10-32 ESNA22NM02    |          |
| C   | 57   | 15G124C     | HXMACHSCRNUT 10-32UNF BRASS       |          |
| C   | 58   | 15Q070C     | SOKSETSCR CUP 10-32X1.25 18-8S    |          |
| C   | 59   | 03 01334    | BKT=SW=AIROP AUTOSPOT             |          |
| C   | 60   | 27B206      | SPCRROLL.202ID.625L.027T STLZC    |          |
| D   | 61   | 15N152      | RDMACSCR 10-24UNC2AX1.25 ZINC     |          |
| D   | 62   | 03 01340    | CAM=AIROP AUTOSPOT                |          |
| D   | 63   | 03 01339    | SPACER=CAM=AIROP AUTOSPOT         |          |

**Excursion Switch**

6044SR2, 6044SR3, 7244SR2



**Legend**

A . . . Jackshaft

**Table 41. Parts List—Excursion Switch**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

| Used In              | Item | Part Number | Description/Nomenclature      | Comments     |
|----------------------|------|-------------|-------------------------------|--------------|
| Reference Assemblies |      |             |                               |              |
|                      | A    | E03 33100B  | EXCURSION SWITCH ASSY 60SGH   | 6044SR2, SR3 |
|                      | B    | E15 04000   | * EXCURSION SWITCH ASSY=SGU   | 7244SR2      |
| Components           |      |             |                               |              |
| A                    | 1    | 09R008A     | MICSW SPDT BZE6-2RN183        |              |
| B                    | 1    | 09R008ASTD  | * 09R008A+MOUNTING HDWRE+INST |              |
| all                  | 2    | 02 10391    | COVER STRIP=MICRO SW #6-8     |              |
| all                  | 3    | 02 15783A   | *PLATE=EXCURSION SW MTG       |              |
| all                  | 4    | 02 15980B   | BRACKET=EXCURSION SW MT 72T   |              |


BPWVUZ01 / 2020043

BPWVUZ01.1 0000267913 D.2 A.3 1/21/20, 10:27 AM Released

### Air Chamber Level Switch

1 Sheet

42044WR2,WR3,SR2,SR3; 6044WR2,WR3,SR2, SR3; 72044WR2, WR3, SR2, SR3



**Legend**

- A . . . To transducer
- B . . . Transducer

**Table 42. Parts List—Air Chamber Level Switch**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

| Used In              | Item | Part Number | Description/Nomenclature             | Comments |
|----------------------|------|-------------|--------------------------------------|----------|
| Reference Assemblies |      |             |                                      |          |
|                      | A    | AD 15 090A  | AIRCHAMBER PRESWITCH INSTALL         |          |
| Components           |      |             |                                      |          |
| all                  | 1    | 5SB0E0CBEO  | NPTHEXBUSH 1/4X1/8 BRASS 125#        |          |
| all                  | 2    | 53A047H     | MALCON 5/16X1/8POLY PH#68P-5-2       |          |
| all                  | 3    | 5SR1A0ENF   | NPT RED 1X1/4 GALMAL 150#            |          |
| all                  | 4    | 5N1A07AG42  | NPT NIP 1X7 TBE GALSTL SK40          |          |
| all                  | 5    | 5S0KNFA1A   | NPT TEE 1/2X1/2X1" GALMAL 150#       |          |
| all                  | 6    | 5N0KCLSG42  | NPT NIP 1/2XCLS TBE GALSTLSK40       |          |
| all                  | 7    | 5SL0PNFC0K  | NPT 90D STREET 3/4X1/2 GAL150#       |          |
| all                  | 8    | 96DB0PNA    | HOSEBIBB 3/4" MALEINLT 45DEG. ACETAL |          |
| all                  | 9    | 60E005      | TUBING BLK.POLY.5/160DX3/16ID        |          |
| all                  | 10   | 51V010A     | TEE 1/8"BRSEXTR BLOCTYP#2203P2       |          |
| all                  | 11   | 51E502A     | HOSESTEM BRASS 1/8MPT X3/16          |          |

**Air Chamber Level Switch**

1 Sheet

42044WR2,WR3,SR2,SR3; 6044WR2,WR3,SR2, SR3; 72044WR2, WR3, SR2, SR3

**Table 42 Parts List—Air Chamber Level Switch (cont'd.)**


| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                  |          |
|---|------|-------------|----------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature         | Comments |
| all   | 12   | 5SP0CBEHS   | NPT PLUG 1/8 HXCTRSNK BRASS      |          |
| all   | 13   | 60E004NA    | TUBING CLEAR PVC 3/16"IDX5/16"OD |          |
| all   | 14   | 08BNLTT     | LEVEL TRANSDUCER BD->TEST        |          |

This page intentionally blank

# Air Chamber Level Switch with Overflow Pressure Switch

2 Sheets

72044WR2,WR3,SR3 72046M5K, 48040M7K



### Legend

- A . . . Vent
- B . . . Transducer
- C . . . Manual adjustment
- D . . . Overflow pressure switch
- E . . . If only one air chamber, the air line must tee off to both switches.
- F . . . Air chamber (typical)
- G . . . Dual drain with two air chambers

## Air Chamber Level Switch with Overflow Pressure Switch

2 Sheets


72044WR2,WR3,SR3 72046M5K, 48040M7K

Table 43. Parts List—Air Chamber Level Switch with Overflow Pressure Switch

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |  |           |
|---|------|-------------|--|-----------|
| Used In   | Item | Part Number | Description/Nomenclature                   | Comments  |
| Reference Assemblies  |      |             |  |           |
|   | A    | ALS68002    | 72WP/SP PRESURE LEVEL SWITCH ASSY OVERFLOW | REFERENCE |
|   | B    | ALS48001    | 4840M7K LEVEL SWITCH ASSY                  |           |
| Components  |      |             |  |           |
| all   | 1    | 5N0KCLSG42  | NPT NIP 1/2XCLS TBE GALSTLSK40             |           |
| all   | 2    | 5S0KNFA1A   | NPT TEE 1/2X1/2X1" GALMAL 150#             |           |
| all   | 3    | 5SL0PNFC0K  | NPT 90D STREET 3/4X1/2 GAL150#             |           |
| all   | 4    | 96DB0PNA    | HOSEBIBB 3/4" MALEINLT 45DEG. ACETAL       |           |
| all   | 5    | 5N1A07AG42  | NPT NIP 1X7 TBE GALSTL SK40                |           |
| all   | 6    | 5SR1A0ENF   | NPT RED 1X1/4 GALMAL 150#                  |           |
| all   | 7    | 5SB0E0CBEO  | NPTHEXBUSH 1/4X1/8 BRASS 125#              |           |
| all   | 8    | 53A047H     | MALCON 5/16X1/8POLY PH#68P-5-2             |           |
| all   | 9    | 60E005      | TUBING BLK.POLY.5/160DX3/16ID              |           |
| all   | 10   | 53A019B     | BODYMALECON5/16X1/8COM#B68A-5A             |           |
| all   | 11   | 53A032      | ELB90MAL5/16X1/8POLY #169P-5-2             |           |
| all   | 12   | 51V010A     | TEE 1/8"BRSEXTR BLOCTYP#2203P2             |           |
| all   | 13   | 5N0CCLSB42  | NPT NIP 1/8XCLS TBE BRASS STD              |           |
| all   | 14   | 5SP0CBEHS   | NPT PLUG 1/8 HXCTRSNK BRASS                |           |
| all   | 15   | 51E502A     | HOSESTEM BRASS 1/8MPT X3/16                |           |
| all   | 16   | 27A043      | HOSECLAMP 5/16"DIA.SPRING#A-5S             |           |
| all   | 17   | 60E004NA    | TUBING CLEAR PVC 3/16"IDX5/16"OD           |           |
| all   | 18   | 09N069      | PRESS SW 4"WC INVENSYS 738-719             |           |
| all   | 19   | 27A047A     | HOSE CLAMP 5/16" NOMINIAL MIN .256"        |           |
| all   | 20   | 08BNLTT     | LEVEL TRANSDUCER BD->TEST                  |           |
| all   | 21   | 5N0E11ABE2  | NPT NIP 1/4X11 TBE BRASS STD               |           |

**Temperature Probe**

6044WR2,WR3,SR2 72044WR2,WR3,SR3



**Table 44. Parts List—Temperature Probe**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                              |          |
|---|------|-------------|------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature     | Comments |
| Components  |      |             |                              |          |
| all   | 1    | 30R0043PB   | TEMPERATURE PROBE ASSY=BRASS |          |




BPWG7Z02 / 2020234

BPWG7Z02.1 0000294740 D.2 A.4 6/3/20, 9:00 AM Released

# Centrifugal Switch Assembly

1 Sheet

72044SR2, 72044SR3



**Table 45. Parts List—Centrifugal Switch Assembly**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| Reference Assemblies  |      |             |                                |          |
|   | A    | G03 04500A  | CENTSWITCH=MOTOR MT NO-PLATE   |          |
| Components  |      |             |                                |          |
| all   | 1    | 09X100      | CARBONBRUSH -187 STMARY GR B86 |          |
| all   | 2    | ESC0001     | * CENT SWITCH BRUSHHOLDER ASSY |          |
| all   | 3    | 15G071      | MACHSCRLOKNUT 6-32 NM SER ZINC |          |
| all   | 4    | 03 IF2X3    | INSUL.AUTOSPOT/CENTRIFUGL.SW   |          |
| all   | 5    | 60E005E     | TUBNG,VNYL.3/8IDX.025"W#HT105C |          |
| all   | 6    | 12P015C     | CABLECLAMP 5/16-1/2            |          |
| all   | 7    | 15G070      | HXMACHSCRNUT 6-32UNC2B ZINC GR |          |
| all   | 8    | 15N045      | RDMACSCR 6-32UNC2AX3/8 ZINC GR |          |
| all   | 9    | 15U100      | LOCKWASHER MEDIUM #6 ZINCPL    |          |
| all   | 10   | 15P010      | TRDCUT PHILPANHDSCR 10-24X1/2S |          |
| all   | 11   | SAE03 012B  | *SLIPRING+CENT SW.ASSY(LORES)  |          |
| all   | 12   | 15U342      | FLTWASH .255/.260IDX.750DX.125 |          |
| all   | 13   | 15K036      | SKSELL0KCP SCR 1/4-20X5/8      |          |
| all   | 14   | 02 15582    | COVER=CENTSW-CADSTL            |          |
| all   | 15   | 03 01147    | HOUSING CENTSW                 |          |

**Centrifugal Switch Assembly**

1 Sheet

72044SR2, 72044SR3

**Table 45 Parts List—Centrifugal Switch Assembly (cont'd.)**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| all   | 16   | 15N119      | PHILPANMACSCR 10-32X1/2 NKL    |          |
| all   | 17   | 15U135      | FLATWASH#10 .4370DX.203IDX.04T |          |
| all   | 18   | 15U150      | LOCKWASHER MEDIUM #10 ZINCPL   |          |

## 6.1 Vibration Safety Switch Adjustments

BNWUUM01.C01 0000250243 D.2 C.2 A.3 1/2/20, 2:19 PM Released

### 6.1.1 What the Vibration Safety Switch Does

BNWUUM01.C02 0000250242 D.2 C.2 A.3 1/2/20, 2:19 PM Released

The **vibration safety switch** in [Figure 65: Vibration Switch, page 154](#) is an important safety feature. If properly adjusted, the switch will momentarily actuate as a result of repeated machine movement caused by an out-of-balance condition. [Table 46, page 153](#) below illustrates the effect of the **vibration safety switch** actuation.

**Table 46. Effect of Tripping Vibration Safety Switch**

| Machine Model  | Function of Vibration Safety Switch                                      |
|--|--|
| 30015, 30020, and 30022  | Disables high speed extract  |
| All microprocessor-controlled washer-extractors not listed above, and all dye machines | De-energizes three-wire relay, effectively terminating machine operation |

### 6.1.2 Adjustments

BNWUUM01.C03 0000250240 D.2 C.2 B.2 11/7/19, 10:43 AM Released

When the machine leaves Milnor®, the actuator arm is tie-wrapped to prevent damage (except on 30015, 30020, and 30022 models). **This tie wrap must be removed after the machine is set into position but before the machine is operated.**


Adjustment of this switch from the factory setting is not recommended; however, it should be checked for proper functioning and adjusted if its proper setting is lost.

As shown in [Figure 65: Vibration Switch, page 154](#), the unit consists of a **sensitive micro-switch** with an extended actuating arm supporting an eccentric weight. The weight may be adjusted by moving it up and down on the arm and by rotating it on the arm. In addition, the **micro-switch** itself may be tilted from side to side.

**The sensitivity of the switch increases as the eccentric weight is raised on the actuating arm and decreases as the weight is lowered.**

The unit should be adjusted so that the actuating arm will always reset by itself, this being accomplished by rotating either the switch or the weight to give just enough bias to cause the switch to reset. Check the adjustment by moving the arm to the left then slowly releasing it. Make sure the micro-switch clicks when the arm is **slowly** released, thus indicating that it has reset. In the released position, the arm should rest **lightly** but definitely against the stop on the **micro-switch** case that prevents any further arm movement to the left.

**Figure 65. Vibration Switch**



For machines with rigid mounted shells, where the machine is bolted to a very substantial foundation, very little machine movement will occur for a given degree of out-of-balance. Under such conditions it may be better to adjust the switch to be very sensitive. With less substantial foundations (e.g., ones where the sub-soil is mushy or springy or otherwise not as desirable), considerably greater machine movement will occur for a given degree of out-of-balance, in which case a less sensitive **vibration switch** setting may be indicated.

BPWOAZ03 / 2019375

BPWOAZ03.1 0000252209 D.2 B.3 1/2/20, 2:25 PM Released

## Vibration Safety Switch

1 Sheet




Table 47. Parts List—Vibration Safety Switch

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| Reference Assemblies  |      |             |                                |          |
|   | A    | SAE03 151   | * ASSY-VIBRATION SWT=LG CONTR  |          |
| Components  |      |             |                                |          |
| all   | 1    | 02 02038    | PLATE INSULATING SMALL 9NOV51  |          |
| all   | 2    | 15P008      | TRDCUT PANHD 6-32X1 NIKSTL +WA |          |
| all   | 3    | 02 15119    | BRACKET=VIBSW CAD              |          |
| all   | 4    | 09R020      | SWITCH NC VIBR#WZ-2RW84429-P52 |          |
| all   | 5    | 03 01059    | VIBSWITCH CLAMP CADSTL         |          |
| all   | 6    | 03 01058    | VIBSWITCH WEIGHT-CADSTL        |          |
| all   | 7    | 15P101      | TRDCUT-F PANHD 8-32X3/8 NIKSTL |          |

# 7 Chemical Supply Devices


BPWG7C01 / 2020244

BPWG7C01.1 0000295532 D.2 A.3 6/10/20, 3:40 PM Released

# Peristaltic Supply Manifold

1 Sheet

72044WR2, 72044SR2



**Table 48. Parts List—Peristaltic Supply Manifold**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                 |                   |
|---|------|-------------|---------------------------------|-------------------|
| Used In   | Item | Part Number | Description/Nomenclature        | Comments          |
| Reference Assemblies  |      |             |                                 |                   |
|   | A    | GWL52005C   | INST=PERIS CONN 72SP/WP         | 72044WR2,72044SR2 |
| Components  |      |             |                                 |                   |
| all   | 1    | 03 25267E   | PERISTALTIC MOUNTING BRACKET    |                   |
| all   | 2    | 96TDC2AA37  | 1/2"N/C2WY120V50/60C VLV(DRYVC) |                   |
| all   | 3    | W8 01254    | *ASSY=PERIST CONNECT 20 HOLES   |                   |
| all   | 4    | 5SL2AP8K    | NPT EL45DEG 2"PVC SH80 FPTXFPT  |                   |
| all   | 5    | 5SCC2AP8    | NPT COUP 2" PVC SK80            |                   |
| all   | 6    | 60E255A70A  | HOSE=2"ID X 70"LG(NO DWG)       |                   |
| all   | 7    | 27A072      | T-BOLT HOSECLAMP2.16-2.47CADSC  |                   |



BPWG7C02 / 2020245

BPWG7C02.1 0000295570 D.2 B.2 6/16/20, 10:06 AM Released

# Soap Chute

2 Sheets

72044SR2



### Legend

- A . . . See detail A
- B . . . 4 instances
- C . . . 10 instances
- D . . . 6 instances
- E . . . Shell weldment

**Table 49. Parts List—Soap Chute**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

| Used In              | Item | Part Number | Description/Nomenclature     | Comments |
|----------------------|------|-------------|------------------------------|----------|
| Reference Assemblies |      |             |                              |          |
|                      | A    | G29 05500B  | INST=SOAP CHUTE 60/72SG      |          |
| Components           |      |             |                              |          |
| all                  | 1    | W2 18884    | WLMT=SOAP CHUTE              |          |
| all                  | 2    | 02 18887    | SOAP CHUTE GASKET            |          |
| all                  | 3    | 02 15982    | GUARD=42WE SOAP CHUTE        |          |
| all                  | 4    | SA 15 102   | *LID ASSY=SOAPCHUTE-GASKETED |          |
| all                  | 5    | 02 18640    | HOOK=SOAPCHUTE LATCH         |          |
| all                  | 6    | 02 15817    | LID=SOAP CHUTE (BEND@PRINT)  |          |
| all                  | 7    | 27A009B     | CATCH SPECIAL 2-HOLE BASE    |          |



**Soap Chute**

2 Sheets

72044SR2

**Table 49 Parts List—Soap Chute (cont'd.)**


| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| all   | 8    | 02 15838    | GASKET-SPONGRUBBER=SOAPCHUTE   |          |
| all   | 9    | 02 15839    | GASKET-SHEETRUBBER=SOAPCHUTE   |          |
| all   | 10   | 02 02706    | HINGE=SOAP CHUTE               |          |
| all   | 11   | 02 15835    | 02 18481 SOAP CHUTE HINGE      |          |
| all   | 12   | 15N130      | RDMACSCR 10-24UNC2A X 1/2 SS18 |          |
| all   | 13   | 24G018N     | ROLLED WASH.194ID NYLTITE 10W  |          |
| all   | 14   | 15G121      | HXCAPNUT 10-24UNC2 #3266BR NKL |          |
| all   | 15   | 15K096      | HEXCAPSCR 3/8-16UNC2X1SS18-8   |          |
| all   | 16   | 15U245      | FLTWASH 3/8 STD COMM 18-8 SS   |          |
| all   | 17   | 15U260      | LOCKWASHER MEDIUM 3/8 SS18-8   |          |
| all   | 18   | 15G206B     | HEXNUT 3/8-16UNC2 BRASS        |          |
| all   | 19   | 15N141      | RDMACSCR 10-24NCX3/4 SLOTTED S |          |

# Five Compartment Supply

5 Sheets

72044SP2, 72044SR2, 7244WP2, 7244WR2

Figure 66. Installed view



### Legend


- B . . . Hand actuated flush switch
- C . . . Shown disconnected

# Five Compartment Supply

5 Sheets

72044SP2, 72044SR2, 7244WP2, 7244WR2

Figure 67. Supply box components



### Five Compartment Supply

5 Sheets

72044SP2, 72044SR2, 7244WP2, 7244WR2

Figure 68. Water inlet and manifold piping



**Five Compartment Supply**

5 Sheets

72044SP2, 72044SR2, 7244WP2, 7244WR2

**Table 50. Parts List—Five Compartment Supply**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |              |
|---|------|-------------|--------------------------------|--------------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments     |
| Reference Assemblies  |      |             |                                |              |
|   | A    | AD 36 032A  | * SUPPLY INJECTOR ASSY         | 7244SP2, SR2 |
|   | B    | AD 36 031A  | 7244WP2/3 ADD FLUSH SUPPLY IN  | 7244WP2, WR2 |
|   | C    | SA 36 037   | *INLET-WATER SUP INJ 72WEV     | ALL          |
|   | D    | A36 04900D  | ASSY=5FLUSH SUP-7244SG         | 7244SP2, SR2 |
|   | E    | A36 04900B  | * ASSY,5FLUSH SUPINJ=72DIVCYL  | 7244WP2, Wr2 |
|   | F    | SA 36 017A  | * PIPING ASSY=7244 SUPINJ      | ALL          |
| Components  |      |             |                                |              |
| all   | 1    | 09R012STDG  | * 09R012 +MOUNTING HDWRE+INST  |              |
| all   | 2    | 02 15096    | BRACKET=DRINTLOKSW-CAD         |              |
| all   | 3    | 03 06263    | SUPPLY INJ PIPE MNT            |              |
| A   | 4    | 60E301A19A  | HOSE= *2.5"ID PE X19"          |              |
| B   | 4    | 60E301A24A  | HOSE= *2.5"ID PE X 24"         |              |
| A   | 5    | W2 15831A   | *TRAP-WELDED=SUPINJ INLET SG   |              |
| B   | 5    | W3 06292    | *ELBOW=SUPPINJ INLET=7244      |              |
| A   | 6    | 60E301A27A  | HOSE= *2.5"ID PE X27"          |              |
| B   | 6    | 60E301A33A  | HOSE= *2.5"ID PE X33"          |              |
| all   | 7    | 27A075      | T-BOLT HOSECLAMP 2.78-3.09"    |              |
| all   | 8    | 03 06382    | COVER=SUPPLY VALVE FRONT SG2   |              |
| all   | 9    | 03 06360    | COVER=SUPPLY VALVE TOP         |              |
| all   | 10   | 03 06286A   | END=SUPPLY VALVE COVER         |              |
| all   | 11   | 03 06286B   | END=SUPPLY VALVE COVER-FRONT   |              |
| all   | 12   | 03 06253    | SUPPORT=SUPPLY INJ PIPING      |              |
| D   | 13   | 03 06323A   | SUPPLY MNT FRONT=7244SG        |              |
| E   | 13   | 03 06323    | MTANGLE, FRONT=FLUSHSUP 72WEU  |              |
| DI  | 14   | 03 06324A   | SUPPLY MNT REAR=7244 SG        |              |
| E   | 14   | 03 06324    | MTG=SUP INJ REAR WES BND@PRT   |              |
| all   | 15   | 03 06373    | BAFFLE=SUPPLY TANK             |              |
| all   | 16   | 02 15773    | PINCHVALVE TUBE-HYPALON        |              |
| all   | 17   | 27A074      | HOSECLAMP 2+1/16-3"CADSC#62040 |              |
| all   | 18   | W3 06254    | *MANIFOLD=72"SUP.INJ.W/OBRACK  |              |
| all   | 19   | W3 06325    | * BUCKET=SUPPLY TANK=72WEDU    |              |
| all   | 20   | 15K096      | HEXCAPSCR 3/8-16UNC2X1SS18-8   |              |
| all   | 21   | 24G030N     | ROLLED WASH.379ID NYLTITE 37W  |              |

**Five Compartment Supply**

5 Sheets

72044SP2, 72044SR2, 7244WP2, 7244WR2

**Table 50 Parts List—Five Compartment Supply (cont'd.)**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                     |          |
|---|------|-------------|-------------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature            | Comments |
| all   | 22   | 15G206      | HEXNUT 3/8-16 UNC2 SS 18-8          |          |
| all   | 23   | 15U260      | LOCKWASHER MEDIUM 3/8 SS18-8        |          |
| all   | 24   | 15U245      | FLTWASH 3/8 STD COMM 18-8 SS        |          |
| all   | 25   | 20C040      | SUPERFLEX SILICONE ADH 85GR         |          |
| all   | 26   | 15N174      | HXCAPSCR 1/4-20UNC X5/8SS18-8       |          |
| all   | 27   | 24G020N     | ROLLED WASH.252ID NYLTITE 25W       |          |
| all   | 28   | 15U181      | LOCKWASHER MEDIUM 1/4 SS18-8        |          |
| all   | 29   | 15G170      | HEXNUT 1/4-20UNC2 SS18-8            |          |
| all   | 30   | 60E086C16K  | * HOSE ASSY=3/4"X 16+1/2"LG         |          |
| all   | 31   | 5SL0PBEA    | NPTLNB 90DEG 3/4 BRASS 125#         |          |
| all   | 32   | 5N0P02AB42  | NPT NIPPLE 3/4X2 TBE BRASS STD      |          |
| all   | 33   | 5S0PBEA     | NPT TEE 3/4" BRASS 125#             |          |
| all   | 34   | 5SL0PBEA0K  | NPTLNB 90DEG 3/4X1/2 BRASS150#      |          |
| all   | 35   | 5N0KCLSBE2  | NPT NIP 1/2XCLS TBE BRASS STD       |          |
| all   | 36   | 96TDC2AA37  | 1/2"N/C2WY120V50/60C VLV(DRYVC)     |          |
| all   | 37   | 27A004      | NOZZLE SPRACO                       |          |
| all   | 38   | 5S0PBEA0K   | NPT TEE 3/4X3/4X1/2 BRASS 125#      |          |
| all   | 39   | 5N0P05KBE2  | NPT NIP 3/4X5.5 TBE BRASS STD       |          |
| all   | 40   | 5SL0KBEA    | NPTLNB 90DEG 1/2 BRASS 125#         |          |
| all   | 41   | 5N0K04ABE2  | NPT NIP 1/2X4 TBE BRASS STD         |          |
| all   | 42   | 5S0KBEA     | NPT TEE 1/2" BRASS 125#             |          |
| all   | 43   | 96D047      | 1/2" SWING CHECK VALVE=SMITH COOPER |          |
| all   | 44   | 5N0P06ABE2  | NPT NIP 3/4X6 TBE BRASS STD         |          |
| all   | 45   | 5N0K02KB42  | NPT NIP 1/2X2.5 TBE BRASS STD       |          |
| all   | 46   | 5SU0KBE     | NPT UNION 1/2" BRASS 125#           |          |
| all   | 47   | 51X017      | UNIONSTRADT 1/2"#1404-8-8           |          |
| all   | 48   | 60E085C26K  | HOSE ASSY=1/2"X26 1/2LG+ENDS        |          |
| all   | 49   | 03 06261    | BOTTOM=SUPVAL COVER BND@PRT         |          |
| all   | 50   | 96J031D     | 3/4"PRESSREG SET 28# FEMXUN=WATTS   |          |
| all   | 51   | 5N0P20AG42  | NPT NIP 3/4X20 TBE GALSTL SK40      |          |
| all   | 52   | 5S0PNFB     | NPT SIDEOUT TEE 3/4" GARMAL         |          |
| all   | 53   | 5SB0P0KNFO  | NPTHEXBUSH 3/4X1/2 GARMAL 150#      |          |
| all   | 54   | 96M001      | 1/2X3/8" RELIEF VALVE SET31#        |          |
| all   | 55   | 5SB0G0EDEO  | NPTHEXBUSH 3/8X1/4 GALCI 125#       |          |

**Five Compartment Supply**

5 Sheets

72044SP2, 72044SR2, 7244WP2, 7244WR2

**Table 50 Parts List—Five Compartment Supply (cont'd.)**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| all   | 56   | 53A008B     | BODYMALECON.25X.25COMP#B68A-4B |          |
| all   | 57   | 5SB0P0CNFA  | NPTHEXBUSH 3/4X1/8GALV150#CORD |          |
| all   | 58   | 30N100      | PRESSGAUGE 1/8"BACKCN.0-30PSI  |          |
| all   | 59   | 51X019      | UNIONSTRADT 3/4"#0107-12-12    |          |

# 8 Water & Steam




**Water Inlets**

72044SR2


**Figure 69. Hot, Cold, and Third Water Inlets**

**72044SR2 Water Piping before 9/2014**



( T=9,8,4,3,7,1)

**Water valves used since 9/2014 (60044SR2 shown)**



**Legend**


- C** . . . Cold water inlet
- H** . . . Hot water inlet
- T** . . . Third water inlet (location shown dashed)
- N1** . . The 72044SR2 photos shows watts water valves not used since 2014. See the parts list for the current valve part number.
- N2** . . This 60044SR2 photo shows the current valve style.

# Water Inlets

72044SR2

3 Sheets

Figure 70. Piping to Drain Sump



## Water Inlets

3 Sheets



72044SR2

Table 51. Parts List—Water Inlets

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                 |           |
|---|------|-------------|---------------------------------|-----------|
| Used In   | Item | Part Number | Description/Nomenclature        | Comments  |
| Reference Assemblies  |      |             |                                 |           |
|   | A    | GVW36001    | H2O INLTS=MTG HDWE NO SB72SG    | REFERENCE |
|   | B    | AVW36003    | *H2O INLT=COLD ONLY , 72SG      |           |
|   | C    | AVW36004    | *H2O INLT=+HOT VALVE, 72SG      |           |
|   | D    | AVW36005    | *H2O INLT=+1 FRESH VALVE 72SG   |           |
|   | E    | AVW36002    | *H2O INLT=INLT PIPING,72SG      |           |
| Components  |      |             |                                 |           |
| all   | 1    | 5SL2ANFA    | NPT ELBOW 90DEG 2" GALMAL 150#  |           |
| all   | 2    | 5N2ACLSG42  | NPT NIP 2XCLS TBE GALSTL SK40   |           |
| all   | 3    | 96D088BCSR  | 2.00WAT BVAL+ACT/BR/NC/ST/RH    |           |
| all   | 4    | 5N2A18AG42  | NPT NIP 2X18 TBE GALSTL SK40    |           |
| all   | 5    | 5SL2ANFB    | NPT ELB 90D SIDEOUT 2"GALML150# |           |
| all   | 6    | 51P060      | PLUG PIPE SQ 2"GALCORED CI 125  |           |
| all   | 7    | 5N2A03AG42  | NPT NIPPLE 2X3 TBE GALSTL SK40  |           |
| all   | 8    | 5S2ANFA     | NPT TEE 2" GALMAL 150#          |           |
| all   | 9    | 5N2A04AG42  | NPT NIP 2X4 TBE GALSTL SK40     |           |
| all   | 10   | 5N2A04KG42  | NPT NIP 2X4.5 TBE GALSTL SK40   |           |
| all   | 11   | 5SB3A2ADEO  | NPTHEXBUSH 3X2 GALCI 125#       |           |
| all   | 12   | 5SL3ANFA    | NPT ELBOW 90DEG 3" GALMAL 150#  |           |
| all   | 13   | 5N3A03AG41  | NPT NIP 3X4 TOE GALSTL          |           |
| all   | 14   | 60E303C     | HOSE 3"ID#7216ETRANS/EQUALIZER  |           |
| all   | 15   | 27A075A     | T-BOLT HOSECLAMP 3.03-3.34"     |           |
| all   | 16   | 27A032M     | UBOLT 2"PIPE 3/8-16 ZNC3.5" LG  |           |
| all   | 17   | 15P200      | TRDCUT-F HXWASHD 3/8-16X3/4NIK  |           |
| all   | 18   | 15U245      | FLTWASH 3/8 STD COMM 18-8 SS    |           |
| all   | 19   | 15U260      | LOCKWASHER MEDIUM 3/8 SS18-8    |           |
| all   | 20   | 15G206      | HEXNUT 3/8-16 UNC2 SS 18-8      |           |

**Steam Components**

72044SR2




**Legend**

- A . . . See Detail A
- B . . . Steam
- C . . . Mixing water
- D . . . Water
- E . . . Sparger

# Steam Components

3 Sheets

72044SR2



F . . . Uses 3

**Legend**

## Steam Components

72044SR2

Table 52. Parts List—Steam Components

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                 |           |
|---|------|-------------|---------------------------------|-----------|
| Used In   | Item | Part Number | Description/Nomenclature        | Comments  |
| Reference Assemblies  |      |             |                                 |           |
|   | A    | GVS36001    | INSTAL=1.25STEAM 72SGU          | REFERENCE |
|   | B    | AVS04001A   | 1.25 BURKERT STEAM=72 SG2+3     |           |
|   | C    | SA 36 027   | *STEAM INLET FLANGE ASSY=72SG   |           |
|   | D    | ASS52001D   | *72TILT/DYE/DAN ST.SPAR 3/40R   |           |
| Components  |      |             |                                 |           |
| all   | 1    | 51T060      | Y-STRAINER 1+1/4" CAST IRON     |           |
| all   | 2    | 5SP0PHFSS   | NPT PLUG 3/4 SQ SOLID STL/ZINC  |           |
| all   | 3    | 5N1E05AG42  | NPT NIP 1.25X5 TBE GALSTL SK40  |           |
| all   | 4    | 96D0011E    | 1.25"NPTBRZ N/C STEAMVALANGBD   |           |
| all   | 5    | 96H018      | ANGLE NEEDLE VLV 1/4" T X 1/8MP |           |
| all   | 6    | 5SB0E0CBEO  | NPTHEXBUSH 1/4X1/8 BRASS 125#   |           |
| all   | 7    | 5N1E03AF42  | NPT NIP 1.25X3 TBE BLKSTL SK40  |           |
| all   | 8    | 5SL1EMFA    | NPT ELB 90DEG 1.25 BLKMAL 150#  |           |
| all   | 9    | 5N1ECLSF42  | NPT NIP 1.25XCLS TBE BLKSTLS40  |           |
| all   | 10   | 5SU1EMH     | NPT UNION 1.25" BLKMAL 150#     |           |
| all   | 11   | 60E096C35A  | STEAMH*OSE=1.25"X35"+2ENDS=(NO  |           |
| all   | 12   | 5SL1ENFK    | NPT ELB 45DEG 1.25 GALMAL 150#  |           |
| all   | 13   | 03 06081    | GASKET=STEAM FLANGE 1/60+72     |           |
| all   | 14   | W3 06080    | * TUBE-STEAM INLET              |           |
| all   | 15   | 5SL1ENFA    | NPT ELB 90DEG 1.25 GALMAL 150#  |           |
| all   | 16   | 5N1ECLSG42  | NPT NIP 1.25XCLS TBE GALSTLS40  |           |
| all   | 17   | 5SU1ENF     | NPT UNION 1.25" GALMAL 150#     |           |
| all   | 18   | 5SL1ESFA    | NPT ELB 90DEG 1.25 304SS 150#   |           |
| all   | 19   | 5N1E07AG42  | NPT NIP 1.25X7 TBE GALSTL SK40  |           |
| all   | 20   | 5SCC1ENF    | NPT COUP 1.25 GALMAL 150#       |           |
| all   | 21   | W3 64566B   | *WLM=STM SPARGER .75 ORF-12"L   |           |
| all   | 22   | 02 14647E   | GASKET=DRNTRGH TO RECIRC BOX    |           |
| all   | 23   | W5 20042    | * STEAM+WATER IN=7244 TILTS     |           |
| all   | 24   | 03 06287    | COVER=STEAM PIPING 72SG         |           |
| all   | 25   | 03 06381    | COVER=BOOT+STEAM PIPE=72"SG     |           |
| all   | 26   | 03 06288    | PLATE=STEAM PIPE COVER 72SG     |           |
| all   | 27   | 60E306A11K  | HOSE= *3.5"ID PE X11.5"         |           |
| all   | 28   | 27A084      | HOSECLAMP 3+9/16-4.5CADSC#HS64  |           |

**Steam Components**

3 Sheets

72044SR2


**Table 52 Parts List—Steam Components (cont'd.)**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                            |          |
|---|------|-------------|----------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature   | Comments |
| all   | 29   | 60E306A29A  | HOSE= *3.5"ID PE X29"      |          |
| all   | 30   | 60E306A24A  | HOSE *3.5"ID GATES PE X24" |          |

# Stainless Dump Valve

3 Sheets

42044WR2/WR3/SR2/SR3; 60044WR2/WR3/SR2/SR3; 72044WR2/WR3/SR2/SR3





## 8"X10" Stainless Dump Valve

3 Sheets

42044WR2/WR3/SR2/SR3; 60044WR2/WR3/SR2/SR3; 72044WR2/WR3/SR2/SR3

Table 53. Parts List—8"X10" Stainless Dump Valve

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |  |
|---|------|-------------|--------------------------------|--|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments   |
| Reference Assemblies  |      |             |                                |  |
|   | A    | SA 28 124   | *8"SGL.DUMPVALVE 4244+52+60    | 42044WR2/WR3 42044SR2/SR3;<br>60044WR2/WR3; 60044SR2/SR3 |
|   | B    | SA 36 015   | 10"SGL.DUMP VALVE 72WE+SG+WT   | 72044WR2/WR3; 72044SR2/SR3                               |
|   | C    | SA 28 158   | * BONNET+AIRCYL=8"SS DUMPVALV  | 8" DUMP VALVE  |
|   | D    | SA 36 044   | * BONNET+AIRCYL=10"SS DUMPVAL  | 10" DUMP VALVE   |
| Components  |      |             |                                |  |
| CD  | 1    | 02 02101    | CYLHEAD W/TAPPED HOLE          |  |
| CD  | 2    | 15U210      | LOKWASHER MEDIUM 5/16 ZINCPL   |  |
| CD  | 3    | 60C132      | ORING 2"IDX3/16CS BUNA70 #329  |  |
| CD  | 4    | 02 02068    | AIRCYL-STAINLESS=DUMP VALVE    |  |
| CD  | 5    | 02 10585D   | TIE BOLT=5/16-18X7.875 PLTD    |  |
| CD  | 6    | 03 01313    | STOP=AIR CYL W/2+11/16STROKE   |  |
| CD  | 7    | 15G220      | LTHX THIN LOKNUT 3/8-24 SSNTE  |  |
| CD  | 8    | 02 02194    | PISTON CUP=DUMPVALVE 2+3/8"    |  |
| CD  | 9    | 02 02085    | UP WASHER=2"OD=PISTON CUP      |  |
| CD  | 10   | 60C106      | ORING 5/16ID 1/16CSBUNA70#011  |  |
| CD  | 11   | 02 02185    | WASHER=PISTON CUP COMP LIMIT   |  |
| all   | 12   | 02 02105B   | 2.38"ACYL BRASS PISTONCUP WSHR |  |
| CD  | 13   | 03 06429    | SPRING=2.11ODX6.5FL 64#/"      |  |
| CD  | 14   | 60C132      | ORING 2"IDX/316CS BUNA70 #329  |  |
| CD  | 15   | 24G020N     | ROLLED WASH.252ID NYLTITE 25W  |  |
| CD  | 16   | X2 02743    | BONNET=2"DUMP VALVE            |  |
| CD  | 17   | 02 18931F   | GASKET=DUMPVALVE-1/60+72WEHU   |  |
| CD  | 18   | 02 16021I   | DUMPVAL STEM-4"+8"316SS        |  |
| CD  | 19   | 15G168      | SQNUT 1/4-20UNC2 SS18-8        |  |
| all   | 20   | 15K086      | HXCAPSCR 3/8-16NCX3/4 SS18-8   |  |
| CD  | 21   | 15K041S     | HEXCAPSCR 1/4-20UNC2AX1 SS18-8 |  |
| CD  | 23   | 02 16021E   | WASHER 3/8IDX1.250D DUMPVAL    |  |
| A   | 24   | 02 18068    | 9 SEAT-RESILIENT=8"DUMPVALVE   |  |
| B   | 24   | 03 06084    | SEAT-RESILIENT=10"DUMPVALVE    |  |
| A   | 25   | 5SP0KGFSS   | NPT PLUG 1/2 SOSOLID GALSTL    |  |
| CD  | 26   | 60C106      | ORING 5/16ID 1/6CS BUNA70#011  |  |
| AC  | 27   | 02 18796    | DISC-8" DUMP VALVE S/S         |  |

**8"X10" Stainless Dump Valve**

3 Sheets

42044WR2/WR3/SR2/SR3; 60044WR2/WR3/SR2/SR3; 72044WR2/WR3/SR2/SR3

**Table 53 Parts List—8"X10" Stainless Dump Valve (cont'd.)**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                               |                |
|---|------|-------------|-------------------------------|----------------|
| Used In   | Item | Part Number | Description/Nomenclature      | Comments       |
| BD  | 27   | 03 06083    | DISC-10"DUMP VALVE S/S        |                |
| all   | 28   | 15U245      | FLTWASH 3/8 STD COMM 18-8 SS  |                |
| A   | 29   | 02 18104    | GASKET=8"DUMP VALVE BONNET    |                |
| B   | 29   | 03 06086G   | GASKET=10" DUMP VALVE BONNET  |                |
| A   | 30   | 02 18931E   | BONNET=8"DUMP VALVE           | 8" DUMP VALVE  |
| B   | 30   | 03 06086F   | BONNET=10"DUMP VALVE          | 10" DUMP VALVE |
| CD  | 32   | 02 16021C   | BUMPER=DUMP VALVE BONNET      |                |
| CD  | 33   | 02 16021D   | DUMP VALVE BUMPER RETAINER    |                |
| A   | 34   | W2 18931    | * BODY=8"DUMPVALV=4244,60,52  | 8" DUMP VALVE  |
| B   | 34   | W3 06086    | *BODY=10"DUMP VALVE 72WE,SG,T | 10" DUMP VALVE |
| A   | 35   | 02 18107    | GASKET=8"FLANGED DUMP VALVE   | 8" DUMP VALVE  |
| B   | 35   | 03 06085D   | GASKET=10"FLANGEDUMP72D 8050  | 10" DUMP VALVE |

BPWG7W02 / 2020256



BPWG7W02.1 0000295820 D.2 B.2 4/15/21, 11:42 AM Released

### Drain Valve Body with Two Valves

3 Sheets

72044WR2, 72044SR2

Figure 71. Reserve Air Pressure Tank and Dual Drain Valve



#### Legend


A. . . See BPWVUZ01

# Drain Valve Body with Two Valves

3 Sheets

72044WR2, 72044SR2

Figure 72. Cross Section of one valve of the Dual Drain Valves



## Drain Valve Body with Two Valves

3 Sheets

72044WR2, 72044SR2

Table 54. Parts List—Drain Valve Body with Two Valves

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |  |          |
|---|------|-------------|--|----------|
| Used In   | Item | Part Number | Description/Nomenclature                   | Comments |
| Reference Assemblies  |      |             |  |          |
|   | A    | SA 36 015A  | DUAL 10"DUMPVAL 7244WE2+WE3                |          |
|   | B    | SA 36 044   | * BONNET+AIRCYL=10"SS DUMPVAL              |          |
| Components  |      |             |  |          |
| all   | 1    | 02 02101    | CYLHEAD W/TAPPED HOLE                      |          |
| all   | 2    | 15U210      | LOKWASHER MEDIUM 5/16 ZINCPL               |          |
| all   | 3    | 60C132      | ORING 2"IDX3/16CS BUNA70 #329              |          |
| all   | 4    | 02 02068    | AIRCYL-STAINLESS=DUMP VALVE                |          |
| all   | 5    | 02 10585D   | TIE BOLT=5/16-18X7.875 PLTD                |          |
| all   | 6    | 03 01313    | STOP=AIR CYL W/2+11/16STROKE               |          |
| all   | 7    | 15G220      | NUTLOK THINHX 3/8-24 SS/NYL                |          |
| all   | 8    | 02 02194    | PISTON CUP=DUMPVALVE 2+3/8"                |          |
| all   | 9    | 02 02085    | UP WASHER=2"OD=PISTON CUP                  |          |
| all   | 10   | 60C106      | ORING 5/16ID 1/16CSBUNA70#011              |          |
| all   | 11   | 02 02185    | WASHER=PISTON CUP COMP LIMIT               |          |
| all   | 12   | 02 02105B   | 2.38"ACYL BRASS PISTONCUP WSHR             |          |
| all   | 13   | 03 06429    | SPRING=2.11ODX6.5FL 64#/"                  |          |
| all   | 15   | 24G020N     | ROLLED WASH.252ID NYLTITE 25W              |          |
| all   | 16   | X2 02743    | BONNET=2"DUMP VALVE                        |          |
| all   | 17   | 02 18931F   | GASKET=DUMPVALVE-1/60+72WEHU               |          |
| all   | 18   | 02 16021I   | DUMPVAL STEM-4"+8"316SS                    |          |
| all   | 19   | 15G168      | SQNUT 1/4-20UNC2 SS18-8                    |          |
| all   | 20   | 15K086      | HXCAPSCR 3/8-16NCX3/4 SS18-8               |          |
| all   | 21   | 15K041S     | HEXCAPSCR 1/4-20UNC2AX1 SS18-8             |          |
| all   | 23   | 02 16021E   | WASHER 3/8IDX1.250D DUMPVAL                |          |
| all   | 24   | 03 06084    | SEAT-RESILIENT=10"DUMPVALVE                |          |
| all   | 25   | 5SP0KGFSS   | NPT PLUG 1/2 SQSOLID GALSTL                |          |
| all   | 27   | 02 18796    | DISC-8" DUMP VALVE S/S                     |          |
| all   | 28   | 20C018C     | NEOPRENE HIGH PERFORMANCE CONTACT ADHESIVE |          |
| all   | 29   | 03 06086G   | GASKET=10" DUMP VALVE BONNET               |          |
| all   | 30   | 03 06086F   | BONNET=10"DUMP VALVE                       |          |
| all   | 32   | 02 16021C   | BUMPER=DUMP VALVE BONNET                   |          |
| all   | 33   | 02 16021D   | DUMP VALVE BUMPER RETAINER                 |          |

**Drain Valve Body with Two Valves**

3 Sheets

72044WR2, 72044SR2

**Table 54 Parts List—Drain Valve Body with Two Valves (cont'd.)**

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| all   | 34   | W3 06086A   | *BODY=10"DUAL DUMP 72WE ONLY   |          |
| all   | 36   | 24G030N     | ROLLED WASH.379ID NYLTITE 37W  |          |
| all   | 37   | 15U200      | FLATWASHER(USS STD) 5/16"ZNC P |          |
| all   | 40   | W3 25307D   | *TANK=AIR PRESSURE RESERVE     |          |
| all   | 41   | 30N102      | PRESSGAUGE 1/4BOTCON.0-150PSI  |          |
| all   | 42   | 96H018      | ANGLE NEEDLE VLV 1/4"X 1/8MPE  |          |
| all   | 43   | 96D047AAK   | CHECK VALVE 1/4"DELT#CMMQ20B   |          |

# 9 Pneumatic

BNWUUM02 / 2020084

BNWUUM02 0000277470 A.3 2/19/20, 8:47 AM Released

## 9.1 Servicing Air Cylinders

BNWUUM02.T01 0000277469 D.2 A.3 A.2 2/18/20, 3:01 PM Released

This is the general procedure for rebuilding an air cylinder using a Milnor® furnished repair kit, once the air cylinder has been removed from the machine. See the specific air cylinder and major assembly parts drawing(s) for component identification and removal/replacement information.

Maintenance procedures require:

- Two threaded rods and nuts, twice the length of the tie bolts.
- The appropriate repair kit.



**CAUTION: EXPLOSION HAZARD** — Spring tension can cause air cylinder to burst apart with great force during disassembly. You can be struck by air cylinder parts.




- ▶ Follow maintenance instructions carefully.
- ▶ Wear eye protection.



**NOTE:** Use a new locknut when re-assembling air cylinder (see the appropriate parts drawing).


1. Replace two diagonally opposite tie bolts with threaded rods and nuts as shown in [Figure 73: Using Threaded Rods, page 182](#).
2. Tighten nuts on the threaded rods until they contact the air cylinder.
3. Remove the other two tie bolts and the nuts, washers, clips, and actuators from the external end of piston stem.

**Figure 73. Using Threaded Rods**



- Loosen nuts on threaded rods evenly, permitting cylinder heads to separate. Use only a few turns on one nut before moving to the other one. Continue until springs have no tension.

**Figure 74. Ensuring Correct Piston Cup Shape**



- Note the position and orientation of the piston cup(s), washers, and springs. Replace the worn parts, then reassemble them in reverse order. Tighten the locknut until it is just barely possible to turn the piston cup and washer assembly on the stem. The correct piston cup shape is shown on the left side of the above figure. **Do not** overtighten the locknut, as this causes the



piston cup to deform to the shape shown on the right side of the figure and may cause the piston to bind in the cylinder.

# Brake Air Cylinder


2 Sheets



**CAUTION:** Circled items are under high spring tension — Air cylinder can burst apart with great force.



- ▶ Follow maintenance instructions BNWUUM02 carefully.



## General Service &amp; Safety-Related Components

2 Sheets

Table 55. Parts List—Brake Air Cylinder

| Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations. |      |             |                                |          |
|---|------|-------------|--------------------------------|----------|
| Used In   | Item | Part Number | Description/Nomenclature       | Comments |
| Reference Assemblies  |      |             |                                |          |
|   | A    | AAC65002    | AIRCYL BRAKE SINGLE MOTOR      |          |
| Components  |      |             |                                |          |
| all   | 1    | 02 18650B   | STEM=2WAY AIRCYL BRAKE 7.88L   |          |
| all   | 2    | W2 18646    | *CYLINDER-AIR=DOUBLEACT BRAKE  |          |
| all   | 3    | 53A031XB    | BODY-EL90MALE.25X25 #269C-4-4B |          |
| all   | 4    | 60C132      | ORING 2"IDX3/16CS BUNA70 #329  |          |
| all   | 5    | 27B250      | SPCRROLL.5ID1.5L.062T STLZNC   |          |
| all   | 6    | 27B34010SS  | SPACERROLL .51ID.625L.062T SS  |          |
| all   | 7    | 02 02194    | PISTON CUP=DUMPVALVE 2+3/8"    |          |
| all   | 8    | 02 18651    | WASHER=2 WAY BRAKE CYL         |          |
| all   | 9    | 15G220      | NUTLOK THINHX 3/8-24 SS/NYL    |          |
| all   | 10   | 60C106      | ORING 5/16ID 1/16CSBUNA70#011  |          |
| all   | 11   | 02 02105B   | 2.38"ACYL BRASS PISTONCUP WSHR |          |
| all   | 12   | 02 02085    | UP WASHER=2"OD=PISTON CUP      |          |
| all   | 13   | 06 20702E   | FLOW NOT ACTUATOR CYL HEAD     |          |
| all   | 14   | 02 02101    | CYLHEAD W/TAPPED HOLE          |          |
| all   | 15   | 02 17024    | SPRING-SS=DUMP 1.5OD4FL40#"    |          |
| all   | 16   | W6 20702F   | *FLOW NOT VLV=AIR-CYL ROD WLD  |          |
| all   | 17   | 60C110      | ORING 1/2IDX3/32CS BUNA70 #112 |          |
| all   | 18   | 02 02185    | WASHER=PISTON CUP COMP LIMIT   |          |
| all   | 19   | 5N0ECLSBE2  | NPT NIP 1/4XCLS TBE BRASS 125# |          |
| all   | 20   | 51V015      | TEE 1/4 FGDBRASS 101T7-444     |          |
| all   | 21   | 53A008B     | BODYMALECON.25X.25COMP#B68A-4B |          |
| all   | 22   | 5SCC0EBE    | NPT COUP 1/4 BRASS 125# W/HEX  |          |
| all   | 23   | 15G185      | HXNUT 5/16-18UNC2B SAE ZINC GR |          |
| all   | 24   | 96M055      | DELTROL QUICK EXHAUST VLV.1/4" |          |
| all   | 25   | 27A005      | MUFFLER 3/8" BANTAM B38        |          |