

Published Manual Number/ECN: MPP48BHEBE/2007044A

- Publishing System: TPAS
- Access date: 1/24/2007
- Document ECN's: Latest Available



Service—

48032 BHP/BTL/BTN

48036 QHP/QTL/QTN

48036 J6P Washer-Extractors



**Read the
separate
safety
manual
before
installing,
operating,
or servicing**

Please Read

About the Manual Identifying Information on the Cover—The front cover displays pertinent identifying information for this manual. Most important, are the published manual number (part number) /ECN (date code). Generally, when a replacement manual is furnished, it will have the same published manual number, but the latest available ECN. This provides the user with the latest information applicable to his machine. Similarly all documents comprising the manual will be the latest available as of the date the manual was printed, even though older ECN dates for those documents may be listed in the table of contents.

When communicating with the Milnor factory regarding this manual, please also provide the other identifying information shown on the cover, including the publishing system, access date, and whether the document ECN's are the latest available or exact.

Best Available Information—This manual contains the most accurate and complete information available when Milnor shipped your machine/software. Products are occasionally released with the best available documentation, even though the device identification (model numbers, etc.) on the documentation does not explicitly include the delivered model. In such cases, use the documentation provided.

Although unlikely, incorrect manuals may have been shipped with your machine. If you believe you received the wrong manuals, or if you need specific information about any aspect of your machine not addressed in the provided documentation, contact the Milnor Customer Service group.

References to Yellow Troubleshooting Pages—This manual may contain references to “yellow pages.” Although the pages containing trouble-shooting procedures are no longer printed on yellow paper, troubleshooting instructions, if any, will be contained in the easily located “Troubleshooting” section. See the table of contents.

Trademarks of Pellerin Milnor Corporation—The following terms, some of which may be used in this publication, are trademarks of Pellerin Milnor Corporation:

CBW [®]	E-P OneTouch [®]	Gear Guardian [®]	Mildata [®]	Milnor [®]	Staph-Guard [®]
E-P Express [®]	E-P Plus [®]	Mentor [®]	Milnet [®]	MultiTrac [™]	Visionex [™]

Trademarks of Other Companies—The following terms, some of which may be used in this publication, are trademarks of their respective companies:

Acronis [®]	Microsoft Windows 2000 [®]	Yaskawa [®]	Siemens [®]
Atlas 2000 [®]	Microsoft Office XP [®]	Microsoft Access [®]	Seagate Crystal Reports [®]
IBM [®]	Microsoft Windows NT [®]	Microsoft Windows XP [®]	

Comments and Suggestions

Help us to improve this manual by sending your comments to:

Pellerin Milnor Corporation
Attn: Technical Publications
P. O. Box 400
Kenner, LA 70063-0400
Fax: (504) 469-1849

Table of Contents

for MPP48BHEBE/2007044A

48032 BHP/BTL/BTN 48036 QHP/QTL/QTN 48036 J6P Washer-Extractors

Page	Description	Document/ECN
1	About This Manual	MHPHYDROAE/2007044A
2	Warranty	BMP720097/92732A
3	How to Order Parts	BMP720097R/72332A
4	Safety—Tilting Washer-Extractors	BIUUUS27/20051111
10	About the Forces Transmitted by Milnor Washer-Extractors	BIWUUI02/20001108
12	Glossary of Tag Illustrations - Suspended Washer-Extractors	MSIUPUTGAE/2003026V
18	Avoiding Damage from Allied Remote Chemical Delivery Systems	BIWUUI03/20030306
23	Section 1: Service and Maintenance	
24	Lubrication and Preventive Maintenance for Hydrocushion Machines	MSSM0201CE/2004046V
34	Maintenance Checklist - 48032BHP/BTL/BTN, 48036QHP/QTL/QTN Models	MSSM0279AE/9719AV
36	Lubricants for Milnor Machines	MSSM0132AE/9903AV
37	Baldor Motor Maintenance	MSSM0274AE/9731AV
41	Flushing Water Seals and Leak-Offs in 48" Washer-Extractors	MSSM0272AE/9704AV
44	General Assembly	BMP830047/96121V
46	Fastener Torque Requirements	MSSM0101CE/9906AV
65	Section 2: Shell and Door Assemblies	
66	Shell Front & Door Assembly 4832BHE	BMP830049/84047C
67	Parts List - Shell front & Door Assembly (48032BHE)	BMP830049R/85463A
68	Interlock Plunger Assembly	BMP700630/94087V
69	Section 3: Drive Assemblies	
70	Drive Base Components on Hydro-Cushion Machines	MSSMA407BE/85047V
80	Drive Base Assy & Drive Chart - 4832BHE & 4836QHE	BMP820064/84102C
81	Drive Base Assembly and Drive Chart	BMP820064R/97106V
83	Gear Reducer / Air Clutch Assembly	BMP820106/97281V
85	Reducer Air Seal	BMP700392/2002496V
86	Brake Assembly - 4226QHE & QTG, 4832BHE	BMP830023/86092C
87	Parts List - Brake Assembly, 42026 QHE, QTG, 48036 BHE	BMP830023R/86092A
89	Centrifugal Switch Assembly	BMP701195/2000242V
91	V-Belt Tension Adjustments for 30" and 36" B-Type Machines and 42" Q-Type Machines	MSSM0204AE/8332BV
92	V-Belt Tension Adjustments for 48", 52", 60" and 72" Washer-Extractors	MSSMA405AE/8737BV
97	Section 4: Bearing Assemblies	

Table of Contents, cont.

Page	Description	Document/ECN
98	Main Bearing Assembly - 48032/48036	BMP820066/94036D
99	Parts List - Main Bearing Assembly	BMP820066R/91446A
101	Section 5: Frame, Pivots, and Suspension	
102	Footguard Assembly - 4226QTH, 4832BTH, 4836QTH	BMP840019/84153B
103	Parts List - Footguard Assembly - 42 & 48	BMP840019R/84276B
105	42+48 Tilt Wheel Lock Down	BMP840018/99471V
106	Suspension Adjustments for Open Pocket, Hydro-Cushion Machines	MSSM0208AE/8506BV
117	Section 6: Control and Sensing Devices	
118	Vibration Safety Switch Adjustments	MSSMA408BE/9273BV
120	Vibration Switch Assembly	BMP700613/83211A
121	Parts List - Vibration Switch Assembly	BMP700613R/83211A
122	Commutator Assembly	BMP701253/89296A
123	Parts List - Commutator Assembly	BMP701253R/89296A
124	Description and Maintenance of the Electronic Balancing System for Washer-Extractors and Textile Machines	MSSMA401BE/9526AV
132	Balancing Valve System - 4832BHE	BMP830046/83221A
133	Parts List - Balancing Valve System (4832BHE)	BMP830046R/83221A
134	Excursion Switch Assembly	BMP830043/83207A
135	Parts List - Excursion Switch Assembly	BMP830043R/83207A
136	Pressure Regulators	BMP900031/96081V
138	Hydraulic Sensing Device Assembly	BMP700847/91523B
139	Parts List - Hydraulic Sensing Device Assembly	BMP700847R/92492A
141	Tilt Limit Switch Assembly 4226QTH, 4832BTH, 4836QTH	BMP840020/84186A
142	Parts List - Tilt Limit Switch Assembly (4226QTH, 4832BTH, 4836QTH)	BMP840020R/85482A
143	Up and Down Limit Switch Adjustments for 42", 48", and 64" Tilting Machines	MSSM0203AE/8450BV
145	Up and Down Limit Switch Adjustments for 52" and 72" Tilting Machines	MSSMA415AE/8452BV
149	Section 7: Chemical Supply Devices	
150	Rules for the Field Installation of Pumped-Type Liquid Supply Systems	MSSM0213AE/89457V
152	Supply Injector & Manifold Assy. - 4226QHE & QTH, 4832BHE, BTG & BTH, 4836QHE, QTH & QTH	BMP830024/83171C
153	Parts List - Supply Injector and Manifold Assembly	BMP830024R/83426A
155	Section 8: Water and Steam Piping Assemblies	
156	Cooldown Inlet Assembly	BMP830042/90152A
157	Parts List - Cooldown Inlet Assembly	BMP830042R/90152A
158	Water Level Float Chamber	BMP810111/2003262V
160	Water Level Switch Assembly	BMP800186/2002226V

Table of Contents, cont.

Page	Description	Document/ECN
161	3 & 4 Inch Dump Valve Assembly	BMP800228/2002226V
163	Section 9: Pneumatic Piping and Assemblies	
164	Servicing Air Cylinders	MSSM0130AE/9313AV
166	3 Way Pilot Valves	BMP900032/91182V
167	Asco 3-way Solenoid Valves	BMP701359/97086V
169	Quick Exhaust Valves	BMP701406/2002382V
171	Air Cylinder Assemblies	BMP830078/2005525B
174	Air Valves & Mounting Hardware	BMP780087/83457B
175	Parts List - Air Valves & Mounting Hardware	BMP780087R/83457A
177	Universal Airvalve Box Assembly	BMP780088/83457C
178	Parts List - Universal Airvalve Box	BMP780088R/93046N
180	Burket Steam Valve	BMP800020/96066V
181	Section 10: Hydraulic Schematics and Devices	
182	Hydrocushion Cylinder Assembly w/Bypass - 4226, 4832, 4836, 4840	BMP890047/94476C
183	Parts List - Hydrocushion Cylinder Assembly with Bypass	BMP890047R/97266V
184	Hydrocushion Cylinder Assembly - 4226QHE, 4832BHE, 4836QHE	BMP820068/94476C
185	Parts List - Hydrocushion Clyinder Assembly (4226QHE, 4832BHE, 4836QHE)	BMP820068R/97266V
186	4226QTH, 4832BTH, 4836QTH - Hydraulic Assembly	BMP840023/84186D
187	Parts List - Hydraulic Assembly - 4226QTH, 4832BTH, 4836QTH	BMP840023R/85106A
189	4226QTG, 4832BTG, 4836QTG - Hydraulic Power Unit Schematic	BMP840024/84196A
190	4226QTH, 4832BTH, 4836QTH - Hydraulic Power Unit Schematic	BMP840009/84193A

ABOUT THIS MANUAL

Scope—This instruction manual is intended to provide preventive maintenance, service procedures, and mechanical parts identification for your machine. See the safety manual for safety instructions before installing, servicing, or operating this machine. See the installation guide for facility requirements, installation instructions, and assembly instructions. See the operator guide for operator instructions. See the reference manual for programming, operating, and troubleshooting instructions. See the schematic manual for electrical parts identification and electrical troubleshooting.

Manual Number/Date Code (When To Discard or Save)—The manual number/date code is located on the inside front cover, upper right corner just above the manual name. Whenever the manual is reprinted with new information, part of this number changes. **If the *date code* after the “/” changes, the new version applies to all machines covered by the old version, but is improved— thus the old version can be discarded. If the *manual number* before the “/” changes, the new manual covers only new machines.** Example: Discard MATMODELAE/8739**CV** when MATMODELAE/8739**DV** is received (minor improvements). Also, discard MATMODELAE/8739**DV** when MATMODELAE/8746**AV** is received (major improvements). But keep MATMODELAE/8746**FV** when MATMODEL**BE**/8815AV is received, since the new manual no longer applies to machines originally shipped with the old manual.

Documents and Change Bars—The individual documents comprising this manual use the same revision criteria as the manual. Text documents also display change bars. Example: When sectionMSOP0599AE/9135**BV** becomes MSOP0599AE/9135**CV**, change bars with the letter “C” appear next to all changes for this revision. For a major rewrite (e.g., MSOP0599AE/9226**AV**), all change bars are deleted.

For Assistance—Please call:

Pellerin Milnor Corporation
Attn: Service Department
P. O. Box 400
Kenner, LA 70063-0400

Phone:(504) 467-9591
Fax:(504) 467-9777

PELLERIN MILNOR CORPORATION

LIMITED STANDARD WARRANTY

We warrant to the original purchaser that MILNOR machines including electronic hardware/software (hereafter referred to as "equipment"), will be free from defects in material and workmanship for a period of one year from the date of shipment from our factory with no operating hour limitation. This warranty is contingent upon the equipment being installed, operated and serviced as specified in the operating manual supplied with the equipment, and operated under normal conditions by competent operators.

Providing we receive written notification of a warranted defect within 30 days of its discovery, we will – at our option – repair or replace the defective part or parts, FOB our factory. We retain the right to require inspection of the parts claimed defective in our factory prior to repairing or replacing same. We will not be responsible, or in any way liable, for unauthorized repairs or service to our equipment, and this warranty shall be void if the equipment is repaired or altered in any way without MILNOR's written consent.

Parts which require routine replacement due to normal wear – such as gaskets, contact points, brake and clutch linings and similar parts – are not covered by this warranty, nor are parts damaged by exposure to weather or to chemicals.

We reserve the right to make changes in the design and/or construction of our equipment (including purchased components) without obligation to change any equipment previously supplied.

ANY SALE OR FURNISHING OF ANY EQUIPMENT BY MILNOR IS MADE ONLY UPON THE EXPRESS UNDERSTANDING THAT MILNOR MAKES NO EXPRESSED OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE. MILNOR WILL NOT BE RESPONSIBLE FOR ANY COSTS OR DAMAGES ACTUALLY INCURRED OR REQUIRED AS A RESULT OF: THE FAILURE OF ANY OTHER PERSON OR ENTITY TO PERFORM ITS RESPONSIBILITIES, FIRE OR OTHER HAZARD, ACCIDENT, IMPROPER STORAGE, MISUSE, NEGLIGENCE, POWER OR ENVIRONMENTAL CONTROL MALFUNCTIONS, DAMAGE FROM LIQUIDS, OR ANY OTHER CAUSE BEYOND THE NORMAL RANGE OF USE. REGARDLESS OF HOW CAUSED, IN NO EVENT SHALL MILNOR BE LIABLE FOR SPECIAL, INDIRECT, PUNITIVE, LIQUIDATED, OR CONSEQUENTIAL COSTS OR DAMAGES, OR ANY COSTS OR DAMAGES WHATSOEVER WHICH EXCEED THE PRICE PAID TO MILNOR FOR THE EQUIPMENT IT SELLS OR FURNISHES.

WE NEITHER ASSUME, NOR AUTHORIZE ANY EMPLOYEE OR OTHER PERSON TO ASSUME FOR US, ANY OTHER RESPONSIBILITY AND/OR LIABILITY IN CONNECTION WITH THE SALE OR FURNISHING OF OUR EQUIPMENT TO ANY BUYER.

How to order repair parts

Repair parts may be ordered either from the authorized dealer who sold you this machine, or directly from the MILNOR factory. In most cases, your dealer will have these parts in stock.

When ordering parts, please be sure to give us the following information:

1. Model and serial number of the machine for which the parts are required
2. Part number
3. Name of the part
4. Quantity needed
5. Method of shipment desired
6. In correspondence regarding motors or electrical controls, please include all nameplate data, including wiring diagram number and the make or manufacturer of the motor or controls.

All parts will be shipped C.O.D. transportation charges collect only.

Please read this manual

It is strongly recommended that you read the installation and operating manual before attempting to install or operate your machine. We suggest that this manual be kept in your business office so that it will not become lost.

PELLERIN MILNOR CORPORATION

P.O. BOX 400, KENNER, LA., 70063-0400, U.S.A.

FAX: Administration 504/468-9307, Engineering 504/469-1849, Service 504/469-9777

BMP720097R
72332A

Safety—Tilting Washer-Extractors

1. General Safety Requirements—Vital Information for Management Personnel [Document BIUUUS04]

Incorrect installation, neglected preventive maintenance, abuse, and/or improper repairs, or changes to the machine can cause unsafe operation and personal injuries, such as multiple fractures, amputations, or death. The owner or his selected representative (owner/user) is responsible for understanding and ensuring the proper operation and maintenance of the machine. The owner/user must familiarize himself with the contents of all machine instruction manuals. The owner/user should direct any questions about these instructions to a Milnor® dealer or the Milnor® Service department.

Most regulatory authorities (including OSHA in the USA and CE in Europe) hold the owner/user ultimately responsible for maintaining a safe working environment. Therefore, the owner/user must do or ensure the following:

- recognize all foreseeable safety hazards within his facility and take actions to protect his personnel, equipment, and facility;
- work equipment is suitable, properly adapted, can be used without risks to health or safety, and is adequately maintained;
- where specific hazards are likely to be involved, access to the equipment is restricted to those employees given the task of using it;
- only specifically designated workers carry out repairs, modifications, maintenance, or servicing;
- information, instruction, and training is provided;
- workers and/or their representatives are consulted.

Work equipment must comply with the requirements listed below. The owner/user must verify that installation and maintenance of equipment is performed in such a way as to support these requirements:

- control devices must be visible, identifiable, and marked; be located outside dangerous zones; and not give rise to a hazard due to unintentional operation;
- control systems must be safe and breakdown/damage must not result in danger;
- work equipment is to be stabilized;
- protection against rupture or disintegration of work equipment;
- guarding, to prevent access to danger zones or to stop movements of dangerous parts before the danger zones are reached. Guards to be robust; not give rise to any additional hazards; not be easily removed or rendered inoperative; situated at a sufficient distance from the danger zone; not restrict view of operating cycle; allow fitting, replacing, or maintenance by restricting access to relevant area and without removal of guard/protection device;
- suitable lighting for working and maintenance areas;
- maintenance to be possible when work equipment is shut down. If not possible, then protection measures to be carried out outside danger zones;
- work equipment must be appropriate for preventing the risk of fire or overheating; discharges of gas, dust, liquid, vapor, other substances; explosion of the equipment or substances in it.

- 1.1. **Laundry Facility**—Provide a supporting floor that is strong and rigid enough to support—with a reasonable safety factor and without undue or objectionable deflection—the weight of the fully loaded machine and the forces transmitted by it during operation. Provide sufficient clearance for machine movement. Provide any safety guards, fences, restraints, devices, and verbal and/or posted restrictions necessary to prevent personnel, machines, or other moving machinery from accessing the machine or its path. Provide adequate ventilation to carry away heat and vapors. Ensure service connections to installed machines meet local and national safety standards, especially regarding the electrical disconnect (see the National Electric Code). Prominently post safety information, including signs showing the source of electrical disconnect.
- 1.2. **Personnel**—Inform personnel about hazard avoidance and the importance of care and common sense. Provide personnel with the safety and operating instructions that apply to them. Verify that personnel use proper safety and operating procedures. Verify that personnel understand and abide by the warnings on the machine and precautions in the instruction manuals.
- 1.3. **Safety Devices**—Ensure that no one eliminates or disables any safety device on the machine or in the facility. Do not allow machine to be used with any missing guard, cover, panel or door. Service any failing or malfunctioning device before operating the machine.
- 1.4. **Hazard Information**—Important information on hazards is provided on the machine safety placards, in the Safety Guide, and throughout the other machine manuals. **Placards must be kept clean so that the information is not obscured. They must be replaced immediately if lost or damaged. The Safety Guide and other machine manuals must be available at all times to the appropriate personnel.** See the machine service manual for safety placard part numbers. Contact the Milnor Parts department for replacement placards or manuals.
- 1.5. **Maintenance**—Ensure the machine is inspected and serviced in accordance with the norms of good practice and with the preventive maintenance schedule. Replace belts, pulleys, brake shoes/disks, clutch plates/tires, rollers, seals, alignment guides, etc. before they are severely worn. Immediately investigate any evidence of impending failure and make needed repairs (e.g., cylinder, shell, or frame cracks; drive components such as motors, gear boxes, bearings, etc., whining, grinding, smoking, or becoming abnormally hot; bending or cracking of cylinder, shell, frame, etc.; leaking seals, hoses, valves, etc.) Do not permit service or maintenance by unqualified personnel.

2. **Safety Alert Messages—Internal Electrical and Mechanical Hazards** [Document BIUUUS11]

The following are instructions about hazards inside the machine and in electrical enclosures.



WARNING 1: Electrocution and Electrical Burn Hazards—Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.

- Do not unlock or open electric box doors.
- Do not remove guards, covers, or panels.
- Do not reach into the machine housing or frame.
- Keep yourself and others off of machine.
- Know the location of the main machine disconnect and use it in an emergency to remove all electric power from the machine.



WARNING 2: Entangle and Crush Hazards—Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.

- Do not remove guards, covers, or panels.
- Do not reach into the machine housing or frame.
- Keep yourself and others off of machine.
- Know the location of all emergency stop switches, pull cords, and/or kick plates and use them in an emergency to stop machine motion.



WARNING 3: Crush Hazards—Tilting machines only—The machine housing will crush your body or limbs if it descends or falls while you are under it. Housing can descend with power off or on. Manual operation of tilting valves overrides safety interlocks. Improper operation of manual tilting valves may cause the housing to descend.

- Do not remove guards, covers, or panels.
- Do not reach into the machine housing or frame.

3. Safety Alert Messages—External Mechanical Hazards [Document BIUUUS12]

The following are instructions about hazards around the front, sides, rear or top of the machine.



WARNING 4: Strike and Crush Hazards—Machines with power operated door—The moving door can strike you or crush or pinch your limbs if caught between the door and machine. Some doors move automatically.

- Keep yourself and others clear of movement areas and paths.
- Keep both hands on the controls while operating.
- Do not operate the machine with malfunctioning two-hand manual controls.



WARNING 5: Crush Hazards—Tilting machines only—The machine can crush your body or limbs if you are caught between the tilting housing and a stationary object. Some machines tilt automatically.

- Keep yourself and others clear of movement areas and paths.
- Keep both hands on the controls while operating.
- Do not operate the machine with malfunctioning two-hand manual controls.



WARNING 6: Crush Hazards—Suspended machines only—Spaces between the shell and housing can close and crush or pinch your limbs. The shell moves within the housing during operation.

- Do not reach into the machine housing or frame.
- Keep yourself and others clear of movement areas and paths.

4. Safety Alert Messages—Cylinder and Processing Hazards

[Document BIUUUS13]

The following are instructions about hazards related to the cylinder and laundering process.



DANGER 7: Entangle and Sever Hazards—Contact with goods being processed can cause the goods to wrap around your body or limbs and dismember you. The goods are normally isolated by the locked cylinder door.

- Do not attempt to open the door or reach into the cylinder until the cylinder is stopped.
- Do not touch goods inside or hanging partially outside the turning cylinder.
- Do not operate the machine with a malfunctioning door interlock.
- Open pocket machines only—Do not jog the cylinder and pull the goods at the same time.
- Open pocket machines only—Keep yourself and others clear of cylinder and goods during jogging operation.
- Do not operate the machine with malfunctioning two-hand manual controls.
- Know the location of all emergency stop switches, pull cords, and/or kick plates and use them in an emergency to stop machine motion.
- Know the location of the main machine disconnect and use it in an emergency to remove all electric power from the machine.



WARNING [8]: Crush Hazards—Contact with the turning cylinder can crush your limbs. The cylinder will repel any object you try to stop it with, possibly causing the object to strike or stab you. The turning cylinder is normally isolated by the locked cylinder door.

- Do not attempt to open the door or reach into the cylinder until the cylinder is stopped.
- Do not place any object in the turning cylinder.
- Do not operate the machine with a malfunctioning door interlock.
- Open pocket machines only—Keep yourself and others clear of cylinder and goods during jogging operation.
- Do not operate the machine with malfunctioning two-hand manual controls.



WARNING [9]: Confined Space Hazards—Confinement in the cylinder can kill or injure you. Hazards include but are not limited to panic, burns, poisoning, suffocation, heat prostration, biological contamination, electrocution, and crushing.

- Do not attempt unauthorized servicing, repairs, or modification.



WARNING [10]: Explosion and Fire Hazards—Flammable substances can explode or ignite in the cylinder, drain trough, or sewer. The machine is designed for washing with water, not any other solvent. Processing can cause solvent-containing goods to give off flammable vapors.

- Do not use flammable solvents in processing.
- Do not process goods containing flammable substances. Consult with your local fire department/public safety office and all insurance providers.

5. Safety Alert Messages—Unsafe Conditions [Document BIUUUS14]

5.1. Damage and Malfunction Hazards

5.1.1. Hazards Resulting from Inoperative Safety Devices



DANGER [11]: Entangle and Sever Hazards—Cylinder door interlock—Operating the machine with a malfunctioning door interlock can permit opening the door when the cylinder is turning and/or starting the cycle with the door open, exposing the turning cylinder.

- Do not operate the machine with any evidence of damage or malfunction.



WARNING 12: Multiple Hazards—Operating the machine with an inoperative safety device can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.

- Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.



WARNING 13: Electrocution and Electrical Burn Hazards—Electric box doors—Operating the machine with any electric box door unlocked can expose high voltage conductors inside the box.

- Do not unlock or open electric box doors.



WARNING 14: Entangle and Crush Hazards—Guards, covers, and panels—Operating the machine with any guard, cover, or panel removed exposes moving components.

- Do not remove guards, covers, or panels.



WARNING 15: Crush Hazards—Down limit switches (machines with front and rear tilt cylinders)—Failure of both front or both rear limit switches allows the seated tilt wheels on a tilted machine to lift from their cradles. The housing will fall and lunge forward or rearward.

- Do not operate the machine with any evidence of damage or malfunction.

5.1.2. Hazards Resulting from Damaged Mechanical Devices



WARNING 16: Multiple Hazards—Operating a damaged machine can kill or injure personnel, further damage or destroy the machine, damage property, and/or void the warranty.

- Do not operate a damaged or malfunctioning machine. Request authorized service.



WARNING 17: Explosion Hazards—Cylinder—A damaged cylinder can rip apart during extraction, puncturing the shell and discharging metal fragments at high speed.

- Do not operate the machine with any evidence of damage or malfunction.



WARNING 18: Explosion Hazards—Clutch and speed switch (multiple motor machines)—A damaged clutch or speed switch can permit the low speed motor to engage during extract. This will over-speed the motor and pulleys and can cause them to rip apart, discharging metal fragments at high speed.

- Stop the machine immediately if any of these conditions occur:
 - abnormal whining sound during extract
 - skidding sound as extract ends
 - clutches remain engaged or re-engage during extract

5.2. Careless Use Hazards

5.2.1. Careless Operation Hazards—Vital Information for Operator Personnel (see also operator hazards throughout manual)



WARNING 19: Multiple Hazards—Careless operator actions can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.

- Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.
- Do not operate a damaged or malfunctioning machine. Request authorized service.
- Do not attempt unauthorized servicing, repairs, or modification.

- Do not use the machine in any manner contrary to the factory instructions.
- Use the machine only for its customary and intended purpose.
- Understand the consequences of operating manually.

5.2.2. Careless Servicing Hazards—Vital Information for Service Personnel (see also service hazards throughout manuals)



WARNING 20: Electrocutation and Electrical Burn Hazards—Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.

- Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.
- Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.



WARNING 21: Entangle and Crush Hazards—Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.

- Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.
- Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.



WARNING 22: Crush Hazards—Tilting machines only—The machine housing will crush your body or limbs if it descends or falls while you are under it. Housing can descend with power off or on. Manual operation of tilting valves overrides safety interlocks. Improper operation of manual tilting valves may cause the housing to descend.

- Secure both red safety supports in accordance with the instructions furnished, then lock out and tag out power at the main machine disconnect before working under the tilted machine.
- Do not operate the manual tilt valves with anyone under the machine.
- Do not operate the tilt controls with anyone under the machine.



WARNING 23: Crush Hazards—Tilting machines with front and rear tilt cylinders—The housing will fall and lunge forward or rearward if the tilt wheels on the non-tilted end lift out of their cradles, even with safety supports in place.

- Understand the consequences of operating manually.



WARNING 24: Confined Space Hazards—Confinement in the cylinder can kill or injure you. Hazards include but are not limited to panic, burns, poisoning, suffocation, heat prostration, biological contamination, electrocution, and crushing.

- Do not enter the cylinder until it has been thoroughly purged, flushed, drained, cooled, and immobilized.

— End of BIUUUS27 —

About the Forces Transmitted by Milnor® Washer-extractors

Document BIWUUI02
Specified Date 20001108
As-of Date 20001108
Access Date 20001108

Applicability.....WUU

During washing and extracting, all washer-extractors transmit both static and dynamic (cyclic) forces to the floor, foundation, or any other supporting structure. During washing, the impact of the goods as they drop imparts forces which are quite difficult to quantify. Size for size, both rigid and flexibly-mounted machines transmit approximately the same forces during washing. During extracting, rigid machines transmit forces up to 30 times greater than equivalent flexibly-mounted models. The actual magnitude of these forces vary according to several factors:

- machine size,
- final extraction speed,
- amount, condition, and type of goods being processed,
- the liquor level and chemical conditions in the bath preceding extraction, and
- other miscellaneous factors.

Estimates of the maximum force normally encountered are available for each Milnor® model and size upon request. Floor or foundation sizes shown on any Milnor® document are only for on-grade situations based only on previous experience without implying any warranty, obligation, or responsibility on our part.

1. Rigid Machines

Size for size, rigid washer-extractors naturally require a stronger, more rigid floor, foundation, or other supporting structure than flexibly-mounted models. If the supporting soil under the slab is itself strong and rigid enough and has not subsided to leave the floor slab suspended without support, on grade installations can often be made directly to an existing floor slab if it has enough strength and rigidity to safely withstand our published forces without transmitting undue vibration. If the subsoil has subsided, or if the floor slab itself has insufficient strength and rigidity, a deeper foundation, poured as to become monolithic with the floor slab, may be required. Support pilings may even be required if the subsoil itself is “springy” (i.e., if its resonant frequency is near the operating speed of the machine). Above-grade installations of rigid machines also require a sufficiently strong and rigid floor or other supporting structure as described below.

2. Flexibly-mounted Machines

Size for size, flexibly-mounted machines generally do not require as strong a floor, foundation, or other supporting structure as do rigid machines. However, a floor or other supporting structure having sufficient strength and rigidity, as described in section 3, is nonetheless vitally important for these models as well.

3. How Strong and Rigid?

Many building codes in the U.S.A. specify that laundry floors must have a minimum live load capacity of 150 pounds per square foot (732 kilograms per square meter). However, even compliance with this or any other standard does not necessarily guarantee sufficient rigidity. In any event, it is the sole responsibility of the owner/user to assure that the floor and/or any other supporting structure exceeds not only all applicable building codes, but also that the floor and/or any other supporting structure for each washer-extractor or group of washer-extractors actually

has sufficient strength and rigidity, plus a reasonable factor of safety for both, to support the weight of all the fully loaded machine(s) including the weight of the water and goods, and including the published 360° rotating sinusoidal RMS forces that are transmitted by the machine(s). Moreover, the floor, foundation, or other supporting structure must have sufficient rigidity (i.e., a natural or resonant frequency many times greater than the machine speed with a reasonable factor of safety); otherwise, the mentioned 360° rotating sinusoidal RMS forces can be multiplied and magnified many times. It is especially important to consider all potential vibration problems that might occur due to all possible combinations of forcing frequencies (rotating speeds) of the machine(s) compared to the natural frequencies of the floor and/or any other supporting structure(s). A qualified soil and/or structural engineer must be engaged for this purpose.

Figure 1: How Rotating Forces Act on the Foundation








Figure 1 above is intended to depict both on-grade and above-grade installations and is equally applicable to flexibly-mounted washer-extractors, as well as to rigid models installed either directly on a floor slab or on a foundation poured integrally with the slab. Current machine data is available from Milnor® upon request. All data is subject to change without notice and may have changed since last printed. It is the sole responsibility of every potential owner to obtain written confirmation that any data furnished by Milnor® applies for the model(s) and serial number(s) of the specific machines.


Glossary of Tag Illustrations— Suspended Washer-Extractors

MSIUPUTGAE/2003026V

Illustration	Explanation
	Stop! Read the manual first for complete instructions before continuing.
	Do not jack the machine here. Do not lift the machine here.
	Use three point or four point lifting as determined by the lifting eyes furnished. Rig the load using lifting cables of sufficient size and length to ensure cables are not over-stressed.
	Do not lift the machine from one corner or one side edge.

Illustration


Explanation



Do not start this machine until the packing materials, lifting brackets, etc. with this tag attached or behind this panel are removed. These materials are painted red. Safety stands or brackets (also painted red) may be provided with this machine. Do not discard safety stands or brackets



Do not step or stand on this machine part.




Maintain a 25 mm. (1") minimum clearance between float clips. Set "low level" so that the bottom of the float is always at least 25mm (1") above the bottom of the float tube.




This motor or pump should rotate in the direction of the arrow.




Do not start this machine until the part with this tag is installed on the machine.




Do not remove this component from the machine.




Install the appropriate part here before operating the machine.




Do not strap or chain over box




Do not pump grease here.




During drain and extract, the cylinder must rotate counterclockwise when viewed from here (rear of machine).



During drain and extract, the cylinder must rotate clockwise when viewed from here (front of machine).




Do not strike shell front of washer-extractors during fork lifting. Striking shell front will cause door to leak.




Brake assembly under machine is fragile. Forklift blades should only be placed under main structural beams

10 psi
.70 kg/cm²




Set main bearing air pad gauge at 10 psi (.70 kg/cm²), 64" and 72" ExN and JxN models only.


Set disc brake air gauge at 10 psi (.70 kg/cm²), 64" and 72" ExN and JxN models only.




Make cold water connection here.



Make hot water connection here.



Make third (reuse) water connection here.



Hold the connection side of the valve with a wrench when connecting plumbing.

Avoiding Damage From Allied Remote Chemical Delivery Systems

Milnor® does not manufacture or supply remote chemical delivery systems and this document is meant only to illustrate some of the possible problems that can be minimized during installation of such systems by the chemical supply company. Milnor washer-extractors and CBW® batch washers (tunnels) are available with convenient inlets for such systems (see Figure 1). Most common of the types of systems currently used in commercial laundering operations are pumped chemical systems. Other types, such as constant pressure, re-circulating ring main systems have also been, and may continue to be used with Milnor equipment.

This document warns about some of the possible hazards posed by chemical systems and lists certain requirements needed to minimize those hazards. The procedures for interfacing with allied chemical systems and information pertinent to chemical use in general are provided elsewhere in the product manuals (see Note 1).

Figure 1: Pumped Chemical Inlets on CBW Batch Washer



Note 1: Misuse of laundering chemicals (such as injecting excessive concentrations of chlorine bleach or permitting acid sours to react with hypo chlorite) due to incorrect formulation can also be hazardous. Information pertinent to chemical use is provided elsewhere in the product manuals.

1. How a Chemical System Can Damage the Machine It Serves

Milnor has manufactured washer-extractors and tunnel washers with the same stainless steel specification since its founding. Every batch of steel used is certified and documented by the steel mill. Testing of samples damaged by corrosion have, in every case, proven the steel to be well within the AISI 304 specification.

Chemical products commonly found in the laundry industry, when used in **established** dosages and proper operating parameters, under the auspices of an experienced chemical specialist, should produce satisfactory results, with no consequential detrimental effects. The industry has published standards in Riggs and Sherrill, “Textile Laundering Technology”. However, the stainless steel can be damaged and even destroyed by **abnormal** contact with chlorine bleach, hydrofluosilicic acid and other commonly used chemicals, as will occur if chemicals are unintentionally leaked into the machine, particularly when it is no longer in use and especially when machine surfaces are dry.

Some chemical systems have been found to permit chemicals to dribble from the supply lines, or worse, to siphon from the supply tank into the machine, during operation and long after the system is shut down—as after working hours and during weekends. If this occurs, **deterioration (rusting) of the stainless steel and damage to any textiles therein will inevitably result. If this condition goes undetected, machine damage is likely to be catastrophic.** No machine is immune to such damage.



CAUTION 1: Equipment and Textile Damage Hazards—Chemicals leaked into the machine, particularly when it is idle can destroy machine components and textiles left in the machine. **Pellerin Milnor Corporation accepts absolutely no responsibility for damage to its equipment or to textiles therein from abnormal contact with chemicals.**


- Ensure that the chemical system prevents unintentional release of chemicals.
- Inspect regularly for proper operation and evidence of damage.

2. Requirements for Chemical Systems Used With Milnor Machines

It is the responsibility of the chemical system manufacturer and supplier to ensure that their system is safe for personnel and equipment. Some important points are described below.


- 2.1. **Ensure the System Cannot Siphon.**—The supply system must be designed to counteract any siphoning that could occur as a result of having a sealed supply line between the bottom of the chemical tank and the internal machine connection at the drain trough. As shown in the Figure 2 examples, if the pump (P) and/or the valving does not provide positive closure and there is no vacuum breaker protection, siphoning is likely to occur. In each of the Figure 2 illustrations, the volume of chemical in the tank above the siphon level (S), and indicated by shading, will flow into the machine.

Figure 2: Siphoning From the Chemical Tank into the Machine



2.2. **Ensure the Chemical Lines Cannot Dribble**—The pumped chemical system may provide a means of positively closing the chemical line at the pump location, but not at the injection site. Hence, any concentrated chemical that remains in the injection line between the pump and the machine is free to flow into the machine. Some examples of this are shown in Figure 3.

**Figure 3: Dribbling From Chemical Supply Line Into Machine
(assumes positive closure at the pump)**




3. Design and Installation Recommendations

It is the responsibility of the chemical system manufacturer and supplier to use whatever measures are necessary to ensure that their system is safe for personnel and equipment. The following are some of the possible methods the manufacturer or supplier may wish to use, as appropriate.

- 3.1. **Siphoning: Positively close the line.**—If the pump does not provide positive closure when the system is off, employ a shutoff valve in the line to serve this purpose.
- 3.2. **Siphoning: Break the siphon.**—Provide an air gap or vacuum breaker in the chemical delivery line. This must be located above the “full” line of the tank.
- 3.3. **Dribbling: Flush the entire chemical delivery line.**—If any concentrated chemical that remains in the injection line between the pump and the machine is free to flow into the machine, employ a system that flushes the entire line between the pump and the injection point with fresh water after each injection.

- 3.4. **Dribbling: Locate the entire chemical line below the machine inlet.**— Assuming the chemical system does not retain any line pressure and that the pump provides positive closure when the system is off, locate the entire chemical delivery line below the level of the chemical inlet. An example of this is shown in Figure 4.

Figure 4: Locating a Pumped Chemical System With Positive Closure To Protect Against Machine Damage



4. Guarding Against Leaks

All personnel who may work with the chemical system (e.g., chemical system manufacturer, chemical system supplier, chemical supplier, operator, maintenance personnel) should be vigilant in observing for leaks in the system. When connecting, or reconnecting chemical lines, whether at installation, after taking samples, or when replacing components, at a minimum ensure that:

1. the proper components are used,
2. all connections are the proper fit, and
3. all components are securely connected.



CAUTION [2]: Injury and Damage Hazards—Chemicals leaking from a chemical system may be corrosive or toxic. Such chemicals can injure personnel and damage equipment.

- Use care when connecting chemical lines.
- Inspect regularly for leaks.

— End of BIWUI03 —

Section
Service and Maintenance

1

LUBRICATION AND PREVENTIVE MAINTENANCE FOR HYDRO-CUSHION[®] MACHINES

General Requirements

Maintenance procedures require:

- A hand operated grease gun.
- The correct lubricants (see “LUBRICANTS FOR MILNOR MACHINES,” in the Table of Contents).

Lubricant Requirements

To achieve the optimum performance and service life from the Milnor[®] machine and as a warranty requirement, the machine must be lubricated in strict accordance with the instructions in this section.

⚠ DANGER ⚠



ENTANGLE AND CRUSH HAZARD—Belts and pulleys can entangle and crush body parts.

- ☞ Lock OFF and tag out power at the wall disconnect before servicing, except where specifically instructed otherwise in this section.
- ☞ Insure belt and pulley guards are in place during service procedures.
- ☞ Permit only qualified maintenance personnel to perform these procedures.

⚠ DANGER ⚠



CRUSH/SEVER HAZARD—Tilting mechanism can crush or sever parts of your body caught in them.

- ☞ Install the safety stands before performing maintenance under a tilted machine.
- ☞ NEVER test or operate (manually or automatically) any machine function with any portion of a person’s body under the tilted machine—even if the safety stands are installed.

⚠ DANGER ⚠



CRUSH/SEVER HAZARD—Tilting machines with tilt wheels/cradles may lunge forward or rearward and even fall over if the tilt wheels at the non-tilted end are raised out of their cradles—killing/injuring personnel and/or damaging property.

- ☞ **NEVER** manually tilt (lift) both ends of the machine at the same time. One end must always be seated in its cradle.
- ☞ **ALWAYS** visually inspect the tilt wheels to be sure they are all fully seated in their cradles before each manual tilt up.
- ☞ Hydraulic valve manual operation must be done by trained competent maintenance personnel who thoroughly understand the system and all the consequences of manual operations.
- ☞ **ALWAYS** understand beforehand all the consequences of manually operating hydraulic valves.
- ☞ Never permit operation with malfunctioning tilt limit switches.

Correct Grease Gun Procedures

1. **Do not use a pneumatic grease gun.** Pump grease slowly, taking 10-15 seconds to complete each stroke. A grease gun can build up extremely high pressure which will force seals out of position and cause them to leak, even though both the seal and the bearing housing are equipped with spring loaded relief plugs.
2. **Apply quantity of grease called for in the checklist.** Over-lubrication can be as damaging as under-lubrication. Where quantities are stated in strokes, one stroke of the grease gun is assumed to provide .0624 fluid ounces (1.77 grams) (by volume) of grease. Therefore, one fluid ounce (28.3 grams) of grease would be provided by 16 strokes of the grease gun. Determine the flow rate of your grease gun by pumping one ounce into a calibrated container. If fewer than 16 strokes are required, all quantities in strokes in the chart should be reduced accordingly, and if more than 16 strokes are required, the number of strokes should be increased. Before starting lubrication, **make sure your grease gun is working and that you get a full charge of grease with every stroke.**
3. **Do not pump grease in until it oozes out of the spring loaded relief plugs.** Plugs bleed out excess grease and help prevent abnormal pressures from building up in the housing during operation (especially when the machine is first commissioned and after each lubrication). **Plugs will not protect against over-lubrication.**
4. **Do not over-lubricate motors.** Over-lubrication of a motor can seriously damage it by forcing grease into motor windings. Over-lubrication of the extract motor can force grease into the centrifugal switch causing it to malfunction.
5. **Do not allow grease to drip on the brake disk or clutch tire/drum during lubrication.** This will reduce the braking action considerably, and may permit the cylinder to creep while loading and unloading.




FIGURE 1 (MSSM0201CE)
Hydraulic Fluid Reservoir Fill and Level Check Point
 (located at rear of 48", 52", and 72" tilt machines only)




FIGURE 2 (MSSM0201CE)
Typical Hydro-Cushion Maintenance Points



FIGURE 3 (MSSM0201CE)
Typical Upper Hydro-Cushion Grease Fitting

Daily and Weekly Maintenance Items

Frequency	Component	Action
Daily	Hydraulic Tilt System (48", 52", and 72" Tilt machines) • Reservoir FIGURE 1 and NOTE 1	Check fluid with machine not tilted
	Hydro-Cushions® (all machines) FIGURES 2 and 3	Check for leaks
Weekly	Final stage and other v-belts (throughout all machines) FIGURES 1 and 12 NOTES 2 and 3	Check for wear and tension

NOTE 1: Tank should be approximately three-quarters full when the machine is not tilted. Do not over-fill.

NOTE 2: V-belt instructions for the first week of operation

- After 24 hours operation (three eight hour days), tighten final stage v-belts.
- After 80 hours operation (ten eight hour days), tighten final stage v-belts again.
- After 160 hours of operation (twenty eight hour days), tighten final stage v-belts, and check all other v-belts and tighten if necessary.

NOTE 3: All v-belts are not alike. "Super" or "High Capacity" v-belts frequently have considerably higher capacities than "Standard" belts. Sometimes, one brand of v-belt is more suitable than another brand of v-belt, although both v-belts are "interchangeable". It is always best to purchase replacement belts from the original manufacturer of the equipment. Purchasing exact replacements of the original belts is the best way to assure belt life equal to the original set. Occasionally, Milnor® will change a belt specification to improve belt life. Belts purchased from Milnor® are as currently specified.

Monthly Maintenance Items

Frequency	Component	Action
Monthly (see NOTE 4)	All Divided cylinder and Staph-Guard® main bearing and seals FIGURES 4 through 10, NOTES 5 and 6	
	• Each bearing grease fitting	0.37 ounces (10.6 grams), six strokes at two locations
	• Each seal grease fitting	0.12 ounces (3.54 grams), two strokes at two locations

NOTE 4: Once a month or once every 200 operating hours, whichever occurs first.

NOTE 5: Main bearings and jackshaft bearings (if so equipped) are prepacked with lubricant at the factory. Do not add grease for thirty days. During the first month's operation, some grease will ooze out of the automatic grease fittings at the bottom of the housing(s). This is normal. These grease fittings allow excess grease to escape, thus avoiding over-heating. This escaping lubricant need not be replaced. Every time these bearings are lubricated, the surplus grease will come out of the spring loaded relief fittings after a few hours running time.

NOTE 6: Bearings can run hot enough to make it extremely uncomfortable for a person to hold his hand on the bearing housing for more than a few seconds. This is normal.




FIGURE 5 (MSSM0201CE)
42" Staph-Guard® Front and Rear Bearing and Seal Grease




FIGURE 4 (MSSM0201CE)
42" Divided Cylinder Front Bearing and Seal Grease Fittings




FIGURE 6 (MSSM0201CE)
42" Divided Cylinder Rear Bearing and Seal Grease Fittings



FIGURE 7 (MSSM0201CE)
60" and 72" Divided Cylinder Front Seal and Bearing Grease Fittings




FIGURE 8 (MSSM0201CE)
60" and 72" Divided Cylinder Rear Seal and Bearing




FIGURE 9 (MSSM0201CE)
60044 and 72044 Staph-Guard®
Front Bearing and Seal Grease Fit-




FIGURE 10 (MSSM0201CE)
60044 and 72044 Staph-Guard®
Rear Bearing and Seal Grease Fittings (lo-




FIGURE 11 (MSSM0201CE)
All Open-Pocket Machine Seal and Bearing Grease Fitting Plate

Frequency	Component	Action
Monthly (see NOTE 4)	42" Open pocket main bearings and seals FIGURE 11, NOTES 5 and 6	
	• Front and rear bearing grease fitting	0.12 ounces (3.54 grams), two strokes at two locations
	• Seal grease fitting	0.06 ounces (1.77 grams), one stroke at one location
	48" Open pocket main bearings, seals and Hydro-Cushions® FIGURES 11 and 13, NOTES 4, 5, 6 and 7	
	• Front and rear bearing grease fitting	0.31 ounces (8.85 grams), five strokes at two locations
	• Seal grease fitting	See "Semi-Annual Maintenance Items" in this section
	• Hydro-Cushion® bypass (48" open-pocket only)	Drain small quantity of oil. If milky, see note 7 below
	52" and 72" Open pocket main bearings and seals FIGURE 11, NOTES 4, 5, and 6	
	• Front bearing grease fitting	0.62 ounces (17.7 grams), ten strokes at one location
	• Rear bearing grease fitting	0.31 ounces (8.8 grams), five strokes at one location
• Seal grease fitting	0.19 ounces (5.31 grams), three strokes at one location	
Drive train components FIGURE 12		
• Pulleys and clutches	Check for wear	
• All components	Remove soil build-up	

NOTE 7: "Milky" oil is contaminated by water. Drain cylinder and unscrew cap on bottom of bypass (See BMP890047). Remove piston rod and inspect the upper piston cups and lower piston for wear or damage. Worn piston cups allow water from the air supply to enter hydrocushion. Repair worn parts and change oil.




FIGURE 12 (MSSM0201CE)
Typical Drive Train Components (48" machine shown)




FIGURE 13 (MSSM0201CE)
Hydrocushion Bypass Valve (48" machines only")



FIGURE 14 (MSSM0201CE)
Handwheel Screw
 (42" Divided Cylinder and Staph-Guard® only)




FIGURE 15 (MSSM0201CE)
Typical Door Hinge




FIGURE 16 (MSSM0201CE)
Handwheel Stop
 (42" Divided Cylinder and Staph-Guard® only)




FIGURE 17 (MSSM0201CE)
42" Staph-Guard®
Idler Shaft
Grease Fitting




FIGURE 18 (MSSM0201CE)
60" and 72" Staph-Guard® Idler Shaft
and Disc Brake Grease Fittings
 (60" shown)




FIGURE 19 (MSSM0201CE)
Typical Jackshaft
Grease Fittings
 (52" machine shown)

Monthly Maintenance Items

Frequency	Component	Action
Monthly (see NOTE 4)	Handwheel screw (42" Divided Cylinder and Staph-Guard®) • Screw thread FIGURE 14	Three drops of light machine oil
	Door hinges • Grease fittings FIGURE 15	0.12 ounces (3.54 grams), two strokes at each location
	Handwheel stop (42" Divided Cylinder and Staph-Guard®) • Grease fitting FIGURE 16	0.06 ounces (1.77 grams), one stroke at one location
	Idler shaft (Staph-Guard® only) • Grease fittings FIGURES 17 and 18	0.31 ounces (8.85 grams), five strokes at two locations
	Disc brake (60" and 72" Staph-Guard® only) • Grease fittings FIGURE 18	0.12 ounces (3.54 grams), two strokes at one location
	Jackshaft (if equipped) • Grease fittings FIGURE 19 NOTES 5 and 6	0.12 ounces (3.54 grams) two strokes at two locations
	Tilt wheels (42", 48", and 72" Tilt Models) • Grease fittings FIGURE 20	0.12 ounces (3.54 grams), two strokes at each location




FIGURE 20 (MSSM0201CE)
Tilt Wheels
 (42" and 48" tilt machines only)





FIGURE 21 (MSSM0201CE)
Disk Brake Reservoir
(Staph-Guard® only)



Brake band
grease fittings

FIGURE 22 (MSSM0201CE)
Brake Band Grease Fittings
(60044 and 72044WP2/WP3)



Brake
shoes

FIGURE 23 (MSSM0201CE)
Brake Shoes (all machines)



FIGURE 24 (MSSM0201CE)
Disk Brake
(Staph-Guard® only)



FIGURE 25 (MSSM0201CE)
Hydraulic Tilt Pressure Gauge
(On rear of 42", 48", and 72" tilt models)



FIGURE 26 (MSSM0201CE)
Door Seal Pressure Regulator

Quarterly Maintenance Items

Frequency	Component	Action
Quarterly	Brake Components	
	• Disk brake reservoir (60" and 72" Staph-Guard [®] only) FIGURE 21	Check level, refill as required (Always use fresh fluid from a sealed container)
	• Brake band grease fittings (60044 and 72044 WP2/WP3 only) FIGURE 22	0.06 ounces (1.77 grams), one stroke at two locations. Do not allow grease to drip on brake surfaces.
	• Brake shoes FIGURE 23	Check for wear, adjust or replace as required.
	• Disc brake pads (60" and 72" Staph-Guard [®] only) FIGURE 24	Check for wear, replace as required
	Hydro-Cushions[®] FIGURES 2 and 3	Check oil level, add as necessary Inspect washer, replace as necessary
	Motors FIGURE 12 NOTES 8 and 9	See "BALDOR MOTOR MAINTENANCE..." MSSM0274AE in this manual.
	Hydraulic tilt pressure gauge FIGURE 25	Check pressure while machine is returning from a tilted position
	• 42" Open pocket	800 PSI (55 Bar)
	• 48" Open pocket	900 PSI (62 Bar)
	• 72" Open pocket	1000 PSI (69 Bar)
	Door seal pressure regulator FIGURE 26	Check settings with machine in bare manual and clockwise wash rotation. See instructions for operating individual outputs in the reference manual.
	• 42" and 48" Open pocket	48 - 50 PSI (3.37 - 3.51 Kg/cm ²)
	• 60" and 72" Rapid load	25 - 28 PSI (1.76 - 1.97 Kg/cm ²)
	• 60" and 72" Staph-Guard [®]	18 - 20 PSI (1.27 - 1.41 Kg/cm ²)

NOTE 8: If motor manufacturer's instructions conflict with manual section, follow nameplate instructions. motors are warranted by their manufacturers, not by Milnor[®].

NOTE 9: Pump grease slowly with relief ports open. Do not over-lubricate.




FIGURE 27 (MSSM0201CE)
Typical Gear Reducer Fill and Drain




FIGURE 28 (MSSM0201CE)
**Push Back and Forward Hydraulic System
 Gauges and Regulators
 (42", 48", and 72" Tilt Models)**




FIGURE 29 (MSSM0201CE)
**Push-Down Control Valve
 (72" Rapid load and Staph-Guard® only)**




FIGURE 30 (MSSM0201CE)
**Shell Door Recirculation Hose
 (48" dye machine only - cover removed for clarity)**

Semi-Annual Maintenance Items

Frequency	Component	Action
Semi-Annual	Main bearings and seals • 48" Seal grease fittings FIGURE 11	0.12 ounces (3.54 grams), two strokes at one location
	Gear reducer FIGURE 27	Check oil level, refill as required
	Push Back and Forward System FIGURE 28 and NOTE 10	
	• Down position pressure gauge and regulator	Check pressure in a "wash step" 3 - 5 PSI (.21- 0.35 Kg/cm ²)
	• Tilt position pressure regulator and gauge	Check pressure in a "wash step" 30 PSI (2.11Kg/cm ²)
	Push-down control valves (72" Rapid load and Staph-Guard®) FIGURE 29 and NOTE 11	Observe operation and adjust if required
	Recirculation (48" dye models only) FIGURE 30	Replace hose

Annual or Less Frequent Maintenance Items

Frequency	Component	Action
Annual	Gear reducer FIGURE 27	Change oil and clean magnetic plug (if so equipped)
	Hydro-Cushions® FIGURE 2	Change oil
Every 2 years	Hydraulic system FIGURE 28	Change oil

NOTE 10: 52" and 72" machines are not equipped with a tilt pressure regulator or gauge.

NOTE 11: Adjust push-down control valves so that machine moves down evenly, and all push-down sockets meet simultaneously. If the back of the machine comes down first, close the valve slowly. If the front comes down first, open the valve.

Maintenance Procedures for 48" Machines	Frequency	12 Month Checklist											
		1	2	3	4	5	6	7	8	9	10	11	12
Check brake shoes for wear, adjust or replace as required	Quarterly												
Check Hydro-Cushion [®] oil levels and inspect mounting washers	Quarterly												
Inspect door seal pressure regulator setting 48 - 50 psi (3.37 - 3.51 kg/cm ²)	Quarterly												
Check gear reducer quick release air valve operation	Quarterly												
Check gear reducer air vent for air leaks	Quarterly												
Observe push-down operation, check quick release air valve operation	Quarterly												
Inspect motors (see BALDOR MOTOR MAINTENANCE...MSSM0274AE)	Quarterly												
Grease main bearing seals (0.12 ounces - 3.54 grams), two strokes at one location	Semi-annually												
Check balancing system breaker point clearance 0.15 - 0.18 inch, (see NOTE 1)	Semi-annually												
Check gear reducer oil, refill as required	Semi-annually												
Flush seals and leak-offs (see NOTE 3)	Semi-annually												
Change recirculation hose, if so equipped	Semi-annually												
Change gear reducer oil and clean magnetic plug	Annually												
Change Hydro-Cushion [®] oil	Annually												
The following items apply to tilting models only													
Check hydraulic tilt reservoir level with machine not tilted	Daily	Daily											
Grease tilt wheels (0.12 ounces - 3.54 grams), two strokes at each location	Monthly												
Check hydraulic tilt pressure gauge (900 psi - 62 bar)	Quarterly												
Replace hydraulic filter (see NOTE 2)	Semi-annually												
Check push-back and push-forward pressure gauge in wash step. (3 - 5 psi / 0.21 kg - 0.35 kg/cm ²) Check tilt position pressure gauge in wash step. (30 psi - 2.11 kg/cm ²)	Semi-annually												
Change hydraulic oil*	Every two years*	*											

NOTE 1: Mechanical balancing system only.

NOTE 2: Replace filter every three months in a heavy soil environment.

NOTE 3: See “FLUSHING WATER SEALS AND LEAK-OFFS...MSSM0272AE” in this manual.

LUBRICANTS FOR MILNOR® MACHINES

The following are lubricants used in Milnor® machines. Always refer to the preventive maintenance instructions for specific lubricating instructions. Consult lubricant manufacturer to verify equivalence before using a substitute. Mixing different base greases can cause bearing and seal damage.

Washer-Extractors											
	Bearing housings	Gear reducers	Isolators	Hydro-Cushions®	Motors	Commutator cam	Balancing mechanism	Disc brake (if so equipped)	Hydraulic tilt mechanism	Door latches	Other grease points
Open Pocket Machines											
30015, 20, 22, C, S, and M	30										
3022F8J	220		220								
36021Q4x, 36026Q4x											
36021BWP							1540				
36021Q6x, 36026Q6x, 42024Q4x, 42026Q6x	EPLF 2	220			EPLF 2			DOT 3	1030	Door	EPLF 2
36030Fxx			1030								
42032Fxx											
42026QHP 48032BHP/BTL/BTN 48036QHP/QTL/QTN		220		220							
52038WP1/WTL/WTN											
64046ExN 72046ExN 72058JxN			1030	1030				DOT 3	68		
Divided Cylinder Machines											
42031 - 44 WP2/3 42031 - 44 SP2/3 60044 SP2/3 72044 SP2/3	EPLF 2	220		1030	EPLF 2			DOT 3		Door	EPLF 2

CBW®, Extractor, Press, Shuttles, Conveyors, and Dryvacs															
	Bearing housings	Gear reducer	Drive motors	Hydro-Cushions®	Hydraulic mechanisms	Disc brake	Mist oiler	Guide rollers	Drive/Support rollers	Blower shaft bearings	Press pressure pump	Blower motors	Inflatable rib couplings	Shuttle chain	All other grease points
CBW®		220					T32	EPLF 2	EPLF 2						EPLF 2
42032M7E	EPLF 2			220	68	DOT 3					630		SRI		
42032M9E			EPLF 2	32											
Single Stage Press		1030													
Press							23								
Dryer									EPLF 2	EP2		R			
Shuttle & Conveyor		634												FL	
Dryvac															

Oils

DOT 3	= NAPA Super Heavy Duty Brake Fluid DOT 3
23	= Shell Tellus® 23
30	= High quality SAE 30, 40, or 50 weight motor oil (non-detergent, if available)
32	= Shell Tellus® 32
T32	= Shell Turbo® T32
68	= Shell Tellus® 68
220	= Shell Morlina® 220
630	= Valvoline Special Moly® EP 630
634	= Mobile SHC® 634 Oil
1030	= Shell Rotella T® 10W30
1540	= Shell Rotella T® HD 15W40

Greases

Door	= Doorease® Stick lubricant
EPLF 2	= Shell Alvania® EP-LF Type 2
EP2	= Shell Darina® EP-2
FL	= Recol Food Lubricant
R	= Shell Dolium® R
Wells	= Wells CL200 Cam Lubricant
SRI	= Chevron SRI oil

BALDOR MOTOR MAINTENANCE

MSSM0274AE/9731AV

Most of the information in this document is taken from the *Baldor Electric Company Instruction, Operation, and Maintenance Manual*, and provides a means of more accurately determining motor lubrication requirements based on local conditions.

General Maintenance

Inspect, clean, and test motors at regular intervals— approximately every 500 operating hours or every three months, whichever comes first. Lubricate motors at the intervals determined herein. Keep accurate maintenance records.

DANGER: Electrocuting and Electrical Burn Hazards



Contact with high voltage will electrocute or burn you. Power switches on the machine and the control box do not eliminate these hazards. High voltage is present at the machine unless the main power is off. Electrical power can cause death or severe injury.

- Do not service machine unless qualified and authorized.
- Lock OFF and tag out power at the wall disconnect before servicing, or in accordance with factory service procedures.

DANGER: Entangle and Crush Hazard



Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.

- Do not service machine unless qualified and authorized.
- Lock OFF and tag out power at the wall disconnect before servicing, or in accordance with factory service procedures.

Clean—Keep the exterior of the motor free of dirt, oil, grease, water, etc. Keep ventilation openings clear. Oily vapor, paper pulp, textile lint, etc., can accumulate and block ventilation, causing overheating and early motor failure.

Test—Periodically, check the motor and winding insulation integrity using a “megger.” Record the megger readings and immediately investigate any significant drop in insulation resistance. Check all electrical connectors to be sure they are tight.

Lubricate—Determine the proper lubrication interval for your motor as explained in “How to Determine Lubrication Interval” in this section, and lubricate accordingly.




FIGURE 1 (MSSM0274AE)
Typical Motor Data Plate

How to Determine Lubrication Interval—The useful life of antifriction bearing grease can be estimated, based on service conditions, frame type, and motor rpm. An example of determining the correct lubrication interval is provided below.

Ex: A fan motor, operating at an ambient temperature of 109°F (43°C) in a moderately corrosive atmosphere. The motor has a NEMA 286T/(IEC 180) frame and is rated at 1750 rpm.

1. Table 1 classifies the service condition as “severe.”
2. Table 2 specifies a 0.5 service condition multiplier value for “severe” service condition.
3. Table 3 specifies 9500 hours as the recommended lubrication interval for frame sizes 254 to 286 (see nameplate), given standard service conditions.
4. Multiply .5 (*service condition multiplier value*) by 9500 hours (*recommended lubrication interval*) = 4750 hours (*calculated lubrication interval*).
5. Table 4 shows that the amount of grease to be added is 0.32 ounces (9.1 grams).

Table 1 — Determining the Service Condition

Severity of Service	Maximum Ambient Temperature	Atmospheric Contamination	Type of Bearing
Standard	104°F (40°C)	Clean, little corrosion	Deep groove ball bearing
Severe	122°F (50°C)	Moderate dirt, corrosion	Ball thrust, Roller
Extreme	>122°F (>50°C) or Class H Insulation (Note 1)	Severe dirt, abrasive dust, corrosion	All bearings
Low Temperature	-22°F (-30°C) (Note 2)		

Note 1: Special high temperature grease is recommended.

Note 2: Special low temperature grease is recommended.

Table 2 — Service Condition Multiplier Value

Operating Condition	Multiplier
Standard	1.0
Severe	0.5
Extreme	0.1

Table 3 — Recommended Lubrication Intervals at Standard Service Conditions

NEMA (IEC) Frame Size	Rated Speed - RPM			
	3600	1800	1200	900
Up to 215 (132)	5500 Hrs.	12000 Hrs.	18000 Hrs.	22000 Hrs.
254 to 286 (160 - 180)	3600 Hrs.	9500 Hrs.	15000 Hrs.	18000 Hrs.
324 to 365 (200 - 225)	2200 Hrs.(Note 3)	7400 Hrs.	12000 Hrs.	15000 Hrs.
404 to 5000 (280 - 315)	2200 Hrs.(Note 3)	3500 Hrs.	7400 Hrs.	10500 Hrs.

Note 3: Bearings in 404 through 5000 frame, 2 pole motors are either 6313 or 6314 bearings and the lubrication interval is shown in the table. **If roller bearings are used, the bearings must be lubricated more frequently. Divide the listed lubrication interval by two.**

Table 4 — Lubrication Amounts per Frame

NEMA (IEC) Frame Size	Bearing Description					
	These are the “Large” bearings (Shaft End) in each frame size (Note 4)					
	Largest bearing in size category	OD D mm	Width B mm	Grease gun strokes (Note 5)	Volume of grease to be added	
ounces					grams	
Up to 215 (132)	6307	80	21	2.5	0.16	4.7
254 to 286 (160 - 180)	6311	120	29	5.0	0.32	9.1
324 to 365 (200 - 225)	6313	140	33	7.0	0.43	12.2
404 to 5000 (280 - 315)	NU322	240	50	18.0	1.11	31.5

Note 4: Smaller bearings in size category may require reduced amounts of grease.

Note 5: See “Correct Grease Gun Procedures” for information on estimating the output of hand-operated grease guns.

Lubrication Recommendations

Type of Grease—Use Shell Dolium R (factory installed) or Chevron SRI greases for standard service conditions. The extreme and low temperature conditions are not normally encountered in the laundry. However, for extreme conditions, use Darmex 707 and for low temperature conditions, use Arrowsell 7. Contact Baldor for equivalents, if necessary.

Correct Grease Gun Procedures

1. Use hand-operated grease gun, not a pneumatic grease gun. Pump grease slowly, taking 10 to 12 seconds to complete each stroke.
2. Apply quantity of grease called for. Over-lubrication can be as damaging as under-lubrication. Where quantities are stated in strokes, one stroke of the grease gun is assumed to provide .0624 fluid oz. (1.77 grams) (by volume) of grease. Therefore, one fluid ounce (28.3 grams) of grease would be provided by 16 strokes of the grease gun. Determine the flow rate of your grease gun by pumping one ounce into a calibrated container. If fewer than 16 strokes are required, all quantities in strokes in the chart should be reduced accordingly. If more than 16 strokes are required, the number of strokes should be increased. **Before starting lubrication, make sure your grease gun is working and that you get a full charge of grease with every stroke.**
3. Do not over-lubricate motors. Over-lubrication of a motor can seriously damage it by forcing grease into motor windings. Over-lubrication of the extract motor can force grease into the centrifugal switch causing it to malfunction.
4. Do not allow grease to drip on the brake disk or clutch tire/drum during lubrication. This will reduce the braking action considerably, and may permit the cylinder to creep while loading and unloading.

Lubrication Procedure

	NOTICE: Motor Damage
---	-----------------------------

To avoid damage to motor bearings, grease must be kept free of dirt. For an extremely dirty environment, contact your Baldor distributor or an authorized Baldor Service Center for additional information.

1. Clean grease fittings.
2. Remove grease outlet plug.
3. Add recommended amount of grease. Be sure grease to be added is compatible with the grease already in motor. Consult your Baldor distributor or an authorized Baldor Service Center if grease other than recommended is to be used. Stop when new grease appears at shaft hole in the endplate or grease outlet plug.
4. Replace grease outlet plug.

FLUSHING WATER SEALS AND LEAK - OFFS IN 48" WASHER-EXTRACTORS


MSSM0272AE/9704AV

DANGER: ENTANGLE AND CRUSH HAZARD



Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.

 Do not service unless qualified and authorized.

 Lock OFF and tag out power at the wall disconnect before servicing, or in accordance with factory service procedures.

Required Kits—This procedure requires bulb pump kit (p/n KZ5CP00100), one gallon (3.8 liters) of mineral spirits, a hand operated grease pump, and the specified lubricants.

Background—The grease filled bearing housings for 48 inch open pocket machines are supplied with two water seals and a grease seal as shown in FIGURES 1 and 2. Bath liquor is prevented from entering the bearings by two water seals separated by grease filled cavity (FIGURE 2). Any water leaking past the water seals is drained by the leak-off cavity. The grease seal retains the grease in the housing. The seal grease cavity and the leak-off cavity can become clogged with lint and debris, resulting in seal and bearing failure. Every six months, flush out these cavities with mineral spirits, as described within. Normally, flushing is done less often than greasing. However, whenever flushing is due, it should be done just prior to greasing, during the same maintenance session.




FIGURE 1 (MSSM0272AE) — Typical Bearing Housing for 48" Washer-Extractor




FIGURE 2 (MSSM0272AE) — Seal Details

NOTICE: BEARING DAMAGE HAZARD



BEARING DAMAGE HAZARD—Bearings will quickly burn up if grease is contaminated by mineral spirits.

☞ **DO NOT attempt to force mineral spirits into the bearing housing.** If mineral spirits do not flow easily through the seal cavity grease relief and leak-off, ream out grease relief and leak-off drain.

☞ **DO NOT attempt to flush the main or rear bearing.**

Flushing the Seal Grease Cavity—Before beginning, study the main bearing assembly drawing in the service manual to identify inlets, connections, reliefs, and leak-offs.

1. Locate the tubing running from the seal cavity grease point to the bearing housing (FIGURE 3). Disconnect this tubing at the bearing housing.
2. Install the bulb pump.
3. Remove the seal cavity grease relief fitting (if so equipped) to prevent the mineral spirits and contaminated grease from being pushed back into the shell under the first water seal. FIGURE 4 shows the internal passage from the seal cavity grease inlet to the seal grease cavity (FIGURE 2) and the internal relief passage from the seal grease cavity to the grease relief fitting (if so equipped) on the housing.
3. Flush until the mineral spirits dripping from the water seal relief are clear (approximately two quarts - 1.9 liters).
4. Re-install seal cavity grease tubing and grease relief fitting (if so equipped).




FIGURE 3 (MSSM0272AE) — Identifying the Seal Cavity Grease Point




FIGURE 4 (MSSM0272AE) — Internal Seal Cavity Grease Passage and Relief

Flushing the Leak-off Cavity

1. Remove the vented plug at the flushing connection and install the bulb pump.
2. Pump approximately two quarts (1.9 liters) of mineral spirits into the flushing connection until the spirits flow easily out of the leak-off drains. FIGURE 5 shows the internal passage from the flushing connection, through the leak-off cavity, and the internal drain to the exterior of the housing.
3. After flushing, replace the vented plug, then see "Greasing Seals and Bearings" in the Preventive Maintenance section.




FIGURE 5 (MSSM0272AE) — Internal Flushing Passage and Leak-off

GENERAL ASSEMBLY 4832BHE







Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP830047/96121V (1 of 2)

Litho in U.S.A.

BMP830047/96121V
(Sheet 1 of 2)





Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP830047/96121V (2 of 2)

Litho in U.S.A.

BMP830047/96121V
(Sheet 2 of 2)

Parts List—General Assembly
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

				Parts List, cont.—Document Name		
Used In	Item	Part Number	Description	Used In	Item	Part Number
			-----ASSEMBLIES-----			
			none			
			-----COMPONENTS-----			
all	1	AGS48001	87491C COVER ASSY R/H 27.62X52			
all	2	AGS48005	89281T COVER ASSY UP/R/H 18.87X52			
all	3	AGS11007	83371C*SM COVER ASSY RIGHT 42+48			
all	4	AGS11008	83126Y*LONG COR COV ASSY 42 & 48			
all	5	60B100	REPLACED BY KIT K15 0004			
all	6	AGS48002	87491 @ COVER ASSY LT/H 52X66.125			
all	7	AGS48003	87491 @ CVR ASY RR LO RT 31.25X55.75			
all	8	AGS48004	87491 @ CVR ASY RR UP RT 18.5X23.625			
all	11	03 E5152N	94187D ENCL. MK5 SWITCHPANEL MOUNTG			
all	12	03 48163	89333D UPPER BELT GUARD 4832+36Q			
all	13	ECD51BWE1	83187Z* DOOR ASSY BAL SENSE MARK 5			
all	14	96M051	USE KZK5B00100			
all	14	27A005	MUFFLER 3/8" ALLIED #B38 "BANTAM"			

FASTENER TORQUE REQUIREMENTS

The specifications in this section apply to 1/4 inch and larger Unified National fine and coarse fasteners used on Milnor[®] machines. This information is to be used only when torque specifications are not stated in the installation or service instructions.

When tightening applicable fastener, abide by the following precautions:

1. Always use new fasteners. Replace bolts, nuts, flat washers, and lock washers in the order shown on the parts drawing.
2. Unless otherwise specified, use:
 - Loctite[®] 271 threadlocker or equivalent for bearing housing mounting bolts from one half to one inch in diameter.
 - Loctite[®] 277 threadlocker or equivalent for bearing housing mounting bolts of one inch diameter or larger.
 - Loctite[®] 242 threadlocker for all other fasteners requiring thread locking compound.
3. Use a torque wrench to assure proper tightness.
4. Never lubricate fasteners. The values specified herein are maximum recommended torques and are calculated from published ASTM and SAE data. Actual allowable torques are application dependent and can vary for many reasons, (joint types, gaskets, etc.). Use these values as a guide.
5. Although FIGURE 1 depicts hex head bolts, the table applies to all head types.




FIGURE 1 (MSSM0101CE)
Fastener Grade Markings

Fasteners and Threadlocker

How Fasteners Loosen—Standard threaded fasteners are manufactured with a clearance fit for easy assembly. With the fastener at the proper torque, 85% of the tightening torque is absorbed in the threads and under the fastener head. The remaining 15% provides the friction that prevents the thread from slipping. When this friction is overcome (by bending, thermal expansion, internal pressures, functional loads, or impact) the thread slips and loosens. Although higher torques reduce the likelihood of thread slippage, if slippage occurs, the threads unwind and the fastener loosens. Once thread slippage begins, vibration increases the rate of loosening.

Preventing Loosening—The most effective way to prevent loosening of threaded parts is by proper application of a threadlocking compound. Threadlocker provides lubrication during assembly, then hardens to seal the threads against corrosion and provide resistance to thread slippage.

Applying Threadlocker

NOTE: The following threadlocker information and illustrations are excerpts from the Loctite® User's Guide and are used with permission.

For maximum strength, threadlocker must fill the thread voids completely, as shown in FIGURE 2. Organic or petroleum solvent will remove excess uncured adhesive from joints. Consult information below for the specific fastener application.

Bolts and Nuts—See FIGURE 3.

1. Clean all threads (bolt and nut) with cleaning solvent.
2. Spray all threads with Loctite® Primer N. Allow to dry.
3. Insert bolt into through hole assembly.
4. Apply several drops of threadlocker onto bolt engagement area.
5. Assemble and tighten nut to correct torque for the threadlocker.

Blind Holes—See FIGURE 4.

1. Clean all threads (bolt and nut) with cleaning solvent.
2. Spray all threads with Loctite® Primer N. Allow to dry.
3. Squirt several drops down female threads into bottom of hole.
4. Apply several drops to bolt.
5. Tighten to correct torque for the threadlocker.




FIGURE 2 (MSSM0101CE)
Correct Threadlocker Use




FIGURE 3 (MSSM0101CE)
Applying Threadlocker to Through Hole




FIGURE 4 (MSSM0101CE)
Applying Threadlocker to Blind Holes

Removing Fasteners

High strength threadlockers like Loctite[®] 271 (or equivalent) may be weakened by heating to at least 500° F (260° C) as follows.

1. Apply localized heat to fastener as shown in FIGURE 5.
2. Disassemble while hot. Once disassembled, the cured adhesive can be removed with Loctite[®] Gasket Remover #790 (or equivalent).




FIGURE 5 (MSSM0101CE)
Removing High Strength Threadlocker

Carbon Steel Fasteners

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1/4 - 20	SAE Grade 1 ASTM A307	2.5 (3.39)	3.0 (4.06)	3.3 (4.47)	3.6 (4.88)	4.6 (6.23)	4.3 (5.83)	3.3 (4.47)
	SAE Grade 2	4.1 (5.56)	4.9 (6.64)	5.5 (7.45)	6.0 (8.13)	7.7 (10.44)	7.1 (9.63)	5.5 (7.46)
	SAE Grade 4	4.8 (6.50)	5.8 (7.86)	6.4 (8.67)	7.0 (9.49)	9.0 (12.20)	8.3 (11.25)	6.4 (8.67)
	SAE Grade 5 ASTM A449	6.3 (8.54)	7.6 (10.3)	8.4 (11.38)	9.3 (12.60)	11.8 (15.99)	11.0 (14.91)	8.4 (11.39)
	SAE Grade 7	7.9 (10.7)	9.4 (12.7)	10.5 (14.23)	11.5 (15.59)	14.7 (19.93)	13.6 (18.44)	10.5 (14.23)
	SAE Grade 8 ASTM A354 Grade BD	8.9 (12.0)	10.7 (14.5)	11.9 (16.13)	13.1 (17.76)	16.6 (22.50)	15.4 (20.88)	11.9 (16.13)
	ASTM A354 Grade BC	7.9 (10.7)	9.4 (12.7)	10.5 (14.23)	11.5 (15.59)	14.7 (19.93)	13.6 (18.44)	10.5 (14.23)

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1/4 - 28	SAE Grade 1 ASTM A307	2.8 (3.80)	3.4 (4.61)	3.8 (5.15)	4.1 (5.56)	5.3 (7.18)	4.9 (6.64)	3.8 (5.15)
	SAE Grade 2	4.7 (6.37)	5.6 (7.60)	6.3 (8.54)	6.9 (9.36)	8.8 (11.93)	8.1 (10.98)	6.3 (8.54)
	SAE Grade 4	5.5 (7.46)	6.6 (8.95)	7.3 (9.90)	8.1 (10.98)	10.3 (13.96)	9.5 (12.88)	7.3 (9.90)
	SAE Grade 5 ASTM A449	7.3 (9.90)	8.7 (11.80)	9.7 (13.15)	10.7 (14.50)	13.6 (18.44)	12.6 (17.08)	9.7 (13.15)
	SAE Grade 7	8.9 (12.07)	10.7 (14.50)	11.9 (16.13)	13.1 (17.76)	16.6 (22.51)	15.4 (20.88)	11.9 (16.13)
	SAE Grade 8 ASTM A354 Grade BD	10.2 (13.83)	12.2 (16.54)	13.6 (18.44)	15.0 (20.34)	19.0 (25.76)	17.7 (23.99)	13.6 (18.44)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
5/16 - 18	SAE Grade 1 ASTM A307	5.1 (6.91)	6.2 (8.40)	6.8 (9.22)	7.5 (10.17)	9.6 (13.02)	8.9 (12.07)	6.8 (9.22)
	SAE Grade 2	8.5 (11.52)	10.2 (13.83)	11.3 (15.32)	12.5 (16.95)	15.9 (21.56)	14.7 (19.93)	11.3 (15.32)
	SAE Grade 4	10.0 (13.56)	12.0 (16.27)	13.3 (18.03)	14.6 (19.79)	18.6 (25.22)	17.3 (23.46)	13.3 (18.03)
	SAE Grade 5 ASTM A449	13.0 (17.63)	15.6 (21.15)	17.4 (23.60)	19.1 (25.90)	24.3 (32.95)	22.6 (30.64)	17.4 (23.60)
	SAE Grade 7	16.1 (21.83)	19.3 (26.17)	21.5 (29.15)	23.6 (31.99)	30.1 (40.81)	27.9 (37.83)	21.5 (29.15)
	SAE Grade 8 ASTM A354 Grade BD	18.5 (25.08)	22.1 (29.96)	24.6 (33.35)	27.1 (36.74)	34.5 (46.78)	32.0 (43.39)	24.6 (33.35)
	ASTM A354 Grade BC	16.1 (21.83)	19.3 (26.17)	21.5 (29.15)	23.6 (31.99)	30.1 (40.81)	27.9 (37.83)	21.5 (29.15)

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
5/16 - 24	SAE Grade 1 ASTM A307	5.6 (7.59)	6.7 (9.08)	7.4 (10.03)	8.2 (11.12)	10.4 (14.10)	9.6 (13.01)	7.4 (10.03)
	SAE Grade 2	9.4 (12.74)	11.3 (15.32)	12.5 (16.94)	13.8 (18.71)	17.5 (23.73)	16.3 (22.09)	12.5 (16.94)
	SAE Grade 4	11.0 (14.91)	13.2 (17.90)	14.6 (19.79)	16.1 (21.83)	20.5 (27.79)	19.0 (25.76)	14.6 (19.79)
	SAE Grade 5 ASTM A449	14.4 (19.52)	17.2 (23.32)	19.1 (25.90)	21.1 (28.60)	26.8 (36.35)	24.9 (33.76)	19.1 (25.90)
	SAE Grade 7	17.9 (24.27)	21.4 (29.01)	23.8 (32.27)	26.2 (35.52)	33.4 (45.28)	31.0 (42.03)	23.8 (32.27)
	SAE Grade 8 ASTM A354 Grade BD	20.4 (27.66)	24.4 (33.08)	27.1 (36.74)	29.9 (40.54)	38.0 (51.52)	35.3 (47.86)	27.1 (36.74)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
3/8 - 16	SAE Grade 1 ASTM A307	9.0 (12.20)	10.8 (14.64)	12.0 (16.27)	13.1 (17.76)	16.7 (22.64)	15.5 (21.01)	12.0 (16.27)
	SAE Grade 2	14.9 (20.20)	17.9 (24.27)	19.9 (26.98)	21.9 (29.69)	27.9 (37.83)	25.9 (35.11)	19.9 (26.98)
	SAE Grade 4	17.8 (24.13)	21.3 (28.88)	23.7 (32.13)	26.0 (35.25)	33.1 (44.87)	30.8 (41.76)	23.7 (32.13)
	SAE Grade 5 ASTM A449	23.2 (31.45)	27.8 (37.69)	30.9 (41.89)	34.0 (46.09)	43.3 (58.70)	40.2 (54.50)	30.9 (41.89)
	SAE Grade 7	28.7 (38.91)	34.4 (46.64)	38.2 (51.79)	42.0 (56.94)	53.5 (72.54)	49.7 (67.39)	38.2 (51.79)
	SAE Grade 8 ASTM A354 Grade BD	32.7 (44.33)	39.2 (53.15)	43.6 (59.11)	48.0 (65.08)	61.0 (82.70)	56.7 (76.87)	43.6 (59.11)
	ASTM A354 Grade BC	28.7 (38.91)	34.4 (46.64)	38.2 (51.79)	42.0 (56.94)	53.5 (72.54)	49.7 (67.39)	38.2 (51.79)

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
3/8 - 24	SAE Grade 1 ASTM A307	10.2 (13.83)	12.2 (16.54)	13.6 (18.44)	15.0 (20.33)	19.0 (25.76)	17.7 (24.00)	13.6 (18.44)
	SAE Grade 2	16.9 (22.91)	20.3 (27.52)	22.5 (30.52)	24.8 (33.62)	31.5 (42.70)	29.3 (39.73)	22.5 (30.50)
	SAE Grade 4	20.0 (27.11)	24.0 (32.54)	26.7 (36.20)	29.4 (39.86)	37.4 (50.70)	34.7 (47.04)	26.7 (36.20)
	SAE Grade 5 ASTM A449	26.2 (35.52)	31.4 (42.57)	34.9 (47.32)	38.4 (52.06)	48.9 (66.30)	45.4 (61.55)	34.9 (47.32)
	SAE Grade 7	32.3 (43.79)	38.8 (52.60)	43.1 (58.44)	47.4 (64.26)	60.4 (81.89)	56.1 (76.06)	43.1 (58.43)
	SAE Grade 8 ASTM A354 Grade BD	36.9 (50.02)	44.3 (60.06)	49.2 (66.70)	54.1 (73.35)	68.9 (93.41)	64.0 (86.77)	49.2 (66.70)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
7/16 - 14	SAE Grade 1 ASTM A307	14.0 (18.98)	17.0 (23.04)	19.14 (25.95)	21.0 (28.47)	27.0 (36.60)	25.0 (33.89)	19.0 (25.76)
	SAE Grade 2	24.0 (32.54)	28.8 (39.05)	32.0 (43.39)	35.2 (47.72)	44.8 (60.74)	41.6 (56.40)	32.0 (43.39)
	SAE Grade 4	28.3 (38.37)	34.0 (46.10)	37.7 (51.11)	41.5 (56.27)	52.8 (71.59)	49.1 (66.57)	37.7 (51.11)
	SAE Grade 5 ASTM A449	37.1 (50.30)	44.5 (60.33)	49.5 (67.11)	54.4 (73.76)	69.3 (93.96)	64.3 (87.18)	49.5 (67.11)
	SAE Grade 7	45.9 (62.23)	55.1 (74.70)	61.3 (83.11)	67.4 (91.38)	85.8 (116.33)	79.6 (107.92)	61.3 (83.11)
	SAE Grade 8 ASTM A354 Grade BD	52.5 (71.18)	63.0 (85.41)	70.0 (94.90)	77.0 (104.40)	98.0 (132.87)	91.0 (123.38)	70.0 (94.90)
	ASTM A354 Grade BC	45.7 (61.96)	54.9 (74.43)	61.0 (82.70)	67.1 (90.97)	85.4 (115.79)	79.3 (107.52)	61.0 (82.70)

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
7/16 - 20	SAE Grade 1 ASTM A307	16.0 (21.70)	19.2 (26.03)	21.3 (28.88)	23.5 (31.86)	29.9 (40.54)	27.7 (37.56)	21.3 (28.88)
	SAE Grade 2	26.9 (36.48)	32.2 (43.66)	35.8 (48.54)	39.4 (53.42)	50.1 (67.93)	46.6 (63.18)	35.8 (48.54)
	SAE Grade 4	31.6 (42.84)	37.9 (51.39)	42.1 (57.08)	46.3 (62.77)	59.0 (79.99)	54.7 (74.16)	42.1 (57.08)
	SAE Grade 5 ASTM A449	41.4 (56.13)	49.7 (67.38)	55.2 (74.84)	60.8 (82.43)	77.3 (104.80)	71.8 (97.35)	55.2 (74.84)
	SAE Grade 7	51.3 (69.55)	61.5 (83.38)	68.4 (92.74)	75.2 (101.96)	95.7 (129.75)	88.9 (120.53)	68.4 (92.74)
	SAE Grade 8 ASTM A354 Grade BD	58.2 (78.90)	69.9 (94.77)	77.7 (105.35)	85.4 (115.78)	108.7 (147.37)	101.0 (136.94)	77.7 (105.35)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1/2 - 13	SAE Grade 1 ASTM A307	22.0 (29.83)	26.0 (35.25)	29.38 (39.83)	32.0 (43.39)	41.0 (55.59)	38.0 (51.52)	29.0 (39.32)
	SAE Grade 2	36.6 (49.62)	43.9 (59.52)	48.8 (66.16)	53.6 (72.67)	68.3 (92.60)	63.4 (85.96)	48.8 (66.16)
	SAE Grade 4	43.1 (58.44)	51.8 (70.23)	57.5 (77.96)	63.3 (85.82)	80.5 (109.14)	74.8 (101.42)	57.5 (77.96)
	SAE Grade 5 ASTM A449	56.7 (76.87)	68.1 (92.33)	75.6 (102.5)	83.2 (112.80)	105.9 (143.58)	98.3 (133.27)	75.6 (102.50)
	SAE Grade 7	69.8 (94.64)	83.8 (113.62)	93.1 (126.23)	102.4 (138.84)	130.4 (176.80)	121.1 (164.19)	93.1 (126.23)
	SAE Grade 8 ASTM A354 Grade BD	79.7 (108.05)	95.6 (129.62)	106.3 (144.12)	116.9 (158.50)	148.8 (201.75)	138.1 (187.24)	106.3 (144.12)
	ASTM A354 Grade BC	69.8 (94.64)	83.8 (113.62)	93.1 (126.23)	102.4 (138.84)	130.4 (176.80)	121.1 (164.19)	93.1 (126.23)

All values in foot pounds and (Newton meters)

Nominal bolt size	Standard and Grade Designation	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1/2 - 20	SAE Grade 1 ASTM A307	24.8 (33.62)	29.8 (40.40)	33.1 (44.88)	36.4 (49.35)	46.4 (62.91)	43.1 (58.44)	33.1 (44.88)
	SAE Grade 2	41.3 (56.00)	49.5 (67.11)	55.0 (74.57)	60.5 (82.02)	77.0 (104.40)	71.5 (96.94)	55.0 (74.57)
	SAE Grade 4	48.8 (66.16)	58.5 (79.32)	65.0 (88.13)	71.5 (96.94)	91.0 (123.38)	84.5 (114.57)	65.0 (88.13)
	SAE Grade 5 ASTM A449	63.8 (86.50)	76.5 (103.72)	85.0 (115.24)	93.5 (126.77)	119.0 (161.34)	110.5 (149.82)	85.0 (115.24)
	SAE Grade 7	78.8 (106.84)	94.5 (128.12)	105.0 (142.36)	115.5 (156.60)	147.0 (199.30)	136.5 (185.07)	105.0 (142.36)
	SAE Grade 8 ASTM A354 Grade BD	90.0 (122.02)	108.0 (146.43)	120.0 (162.70)	132.0 (179.00)	168.0 (277.78)	156.0 (211.51)	120.0 (162.70)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
9/16 - 12	SAE Grade 1 ASTM A307	32.0 (43.39)	38.0 (51.52)	42.19 (57.20)	46.0 (62.37)	59.0 (80.00)	55.0 (74.57)	42 (56.94)
	SAE Grade 2	52.7 (71.45)	63.3 (85.82)	70.3 (95.31)	77.3 (104.80)	98.4 (133.41)	91.4 (123.92)	70.3 (95.31)
	SAE Grade 4	62.2 (84.33)	74.7 (101.28)	83.0 (112.53)	91.3 (123.79)	116.2 (157.55)	107.9 (146.30)	83.0 (112.53)
	SAE Grade 5 ASTM A449	81.7 (110.77)	98.1 (133.00)	109.0 (147.78)	119.9 (162.56)	152.6 (206.90)	141.7 (192.17)	109.0 (147.78)
	SAE Grade 7	100.7 (136.53)	120.9 (163.92)	134.3 (182.09)	147.7 (200.25)	188.0 (254.89)	174.6 (236.73)	134.3 (182.09)
	SAE Grade 8 ASTM A354 Grade BD	115.0 (155.92)	138.0 (187.10)	153.3 (207.85)	168.6 (228.59)	214.6 (290.96)	199.3 (270.21)	153.3 (207.85)
	ASTM A354 Grade BC	100.7 (136.53)	120.9 (163.92)	134.3 (182.09)	147.7 (200.25)	188.0 (254.89)	174.6 (236.73)	134.3 (182.09)

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for:					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
9/16 - 18	SAE Grade 1 ASTM A307	35.3 (47.86)	42.4 (57.49)	47.1 (63.86)	51.8 (70.23)	66.0 (89.48)	61.2 (82.98)	47.1 (63.86)
	SAE Grade 2	59.1 (80.13)	70.9 (96.13)	78.8 (106.84)	86.6 (117.41)	110.3 (149.55)	102.4 (138.84)	78.8 (106.84)
	SAE Grade 4	69.6 (94.36)	83.5 (113.21)	92.8 (125.82)	102.1 (138.43)	129.9 (176.12)	120.7 (163.65)	92.8 (125.85)
	SAE Grade 5 ASTM A449	91.2 (123.65)	109.5 (148.46)	121.6 (164.87)	133.8 (181.40)	170.3 (230.90)	158.1 (214.36)	121.6 (164.87)
	SAE Grade 7	112.3 (152.26)	134.8 (182.76)	149.8 (203.10)	164.7 (223.30)	209.7 (284.32)	194.7 (263.98)	149.8 (203.10)
	SAE Grade 8 ASTM A354 Grade BD	128.7 (174.61)	154.4 (209.34)	171.6 (232.66)	188.7 (255.84)	240.2 (325.67)	223.0 (302.35)	171.6 (232.66)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for:					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
5/8 - 11	SAE Grade 1 ASTM A307	44 (59.66)	52 (70.50)	58.2 (78.90)	64 (86.77)	81 (109.82)	76 (103.04)	58 (78.64)
	SAE Grade 2	72.7 (98.57)	87.2 (118.23)	96.9 (131.38)	106.6 (144.53)	135.6 (183.85)	125.9 (170.70)	96.9 (131.38)
	SAE Grade 4	86.1 (116.74)	103.4 (140.19)	114.8 (155.65)	126.3 (171.24)	160.8 (218.02)	149.3 (202.42)	114.8 (155.65)
	SAE Grade 5 ASTM A449	112.5 (152.53)	135.0 (183.04)	150.0 (203.37)	165.0 (223.71)	210.0 (284.72)	195.0 (264.38)	150.0 (203.37)
	SAE Grade 7	138.9 (188.32)	166.6 (225.88)	185.2 (251.10)	203.7 (276.18)	259.2 (351.43)	240.7 (326.35)	185.2 (251.10)
	SAE Grade 8 ASTM A354 Grade BD	158.8 (215.30)	190.5 (258.28)	211.7 (287.03)	232.9 (315.77)	296.4 (401.86)	275.2 (373.12)	211.7 (287.03)
	ASTM A354 Grade BC	139.2 (188.73)	167.0 (226.42)	185.5 (251.50)	204.1 (276.72)	259.8 (352.24)	241.2 (327.02)	185.5 (251.50)

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for:					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
5/8 - 18	SAE Grade 1 ASTM A307	49.5 (67.11)	59.4 (80.54)	66.0 (89.48)	72.6 (98.43)	92.4 (125.27)	85.8 (116.33)	66.0 (89.48)
	SAE Grade 2	82.6 (112.00)	99.1 (134.36)	110.2 (149.41)	121.2 (164.33)	154.2 (209.07)	143.2 (194.15)	110.2 (149.41)
	SAE Grade 4	97.3 (131.92)	116.7 (158.22)	129.7 (175.85)	142.7 (193.48)	181.6 (246.22)	168.6 (228.59)	129.7 (175.85)
	SAE Grade 5 ASTM A449	127.7 (173.14)	153.3 (207.85)	170.3 (230.90)	187.3 (253.95)	238.4 (323.23)	221.4 (300.18)	170.3 (230.90)
	SAE Grade 7	157.6 (213.68)	189.1 (256.39)	210.2 (285.00)	231.2 (313.47)	294.2 (398.88)	273.2 (370.41)	210.2 (285.00)
	SAE Grade 8 ASTM A354 Grade BD	179.9 (243.91)	215.9 (292.72)	239.8 (325.13)	263.8 (357.66)	335.8 (455.28)	311.8 (422.74)	239.8 (325.13)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for:					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
3/4 - 10	SAE Grade 1 ASTM A307	77 (104.40)	93 (126.09)	103.1 (139.78)	113 (153.20)	144 (195.24)	134 (181.68)	103 (139.65)
	SAE Grade 2	129.4 (175.44)	155.3 (210.55)	172.5 (233.88)	189.8 (257.33)	241.5 (327.43)	224.3 (304.11)	172.5 (233.88)
	SAE Grade 4	152.6 (206.90)	183.1 (248.25)	203.4 (275.77)	223.8 (303.43)	284.8 (386.14)	264.5 (358.61)	203.4 (275.77)
	SAE Grade 5 ASTM A449	199.7 (270.76)	239.6 (324.85)	266.3 (361.05)	292.9 (397.12)	372.8 (505.45)	346.1 (469.25)	266.3 (361.05)
	SAE Grade 7	246.8 (334.62)	296.2 (401.60)	329.1 (446.20)	362.0 (490.13)	460.7 (624.63)	427.8 (580.02)	329.1 (446.20)
	SAE Grade 8 ASTM A354 Grade BD	282.0 (382.34)	338.3 (458.67)	375.9 (509.65)	413.5 (560.63)	526.3 (713.57)	488.7 (662.59)	375.9 (509.65)
	ASTM A354 Grade BC	246.4 (334.07)	295.7 (400.92)	328.6 (445.53)	361.5 (490.13)	460.0 (623.67)	427.2 (579.20)	328.6 (445.53)

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for:					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
3/4 - 16	SAE Grade 1 ASTM A307	86.5 (117.28)	103.8 (140.73)	115.3 (156.33)	126.8 (171.92)	161.4 (218.83)	149.9 (203.24)	115.3 (156.33)
	SAE Grade 2	144.1 (195.37)	173.0 (234.56)	192.2 (260.59)	211.4 (286.62)	269.1 (364.85)	249.8 (338.68)	192.2 (260.59)
	SAE Grade 4	170.2 (230.76)	204.2 (276.86)	226.9 (307.64)	249.6 (338.41)	317.6 (430.61)	294.9 (399.15)	226.9 (307.64)
	SAE Grade 5 ASTM A449	222.9 (302.21)	267.5 (362.68)	297.2 (402.95)	326.9 (443.22)	416.1 (564.16)	386.3 (523.75)	297.2 (402.95)
	SAE Grade 7	275.6 (373.66)	330.8 (448.50)	367.5 (498.26)	404.3 (548.16)	514.5 (697.57)	477.8 (647.81)	367.5 (498.26)
	SAE Grade 8 ASTM A354 Grade BD	315.0 (427.08)	378.0 (512.50)	420.0 (569.44)	462.0 (626.39)	588.0 (797.22)	546.0 (740.28)	420.0 (569.44)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for:					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
7/8 - 9	SAE Grade 1 ASTM A307	124.7 (169.07)	149.6 (202.83)	166.3 (225.47)	182.9 (247.98)	232.8 (315.63)	216.1 (293.0)	166.3 (225.47)
	SAE Grade 2	124.7 (169.07)	149.6 (202.83)	166.3 (225.47)	182.9 (247.98)	232.8 (315.63)	216.1 (293.00)	166.3 (225.47)
	SAE Grade 4	246.1 (333.67)	295.3 (400.37)	328.1 (444.84)	360.9 (489.32)	459.4 (622.86)	426.6 (578.40)	328.1 (444.84)
	SAE Grade 5 ASTM A449	322.4 (437.11)	386.9 (524.57)	429.8 (582.73)	472.8 (641.03)	601.8 (815.93)	558.8 (757.63)	429.8 (582.73)
	SAE Grade 7	397.9 (539.48)	477.4 (647.27)	530.5 (719.26)	583.5 (791.12)	742.7 (1007.00)	689.6 (935.00)	530.5 (719.26)
	SAE Grade 8 ASTM A354 Grade BD	454.5 (616.22)	545.3 (739.33)	605.9 (821.49)	666.5 (903.65)	848.3 (1150.14)	787.7 (1067.98)	605.9 (821.49)
	ASTM A354 Grade BC	397.9 (539.48)	477.4 (647.27)	530.5 (719.26)	583.5 (791.12)	742.7 (1007.00)	689.6 (935.00)	530.5 (719.26)

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for:					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
7/8 - 14	SAE Grade 1 ASTM A307	137.8 (186.83)	165.4 (224.25)	183.8 (249.20)	202.1 (274.01)	257.3 (348.85)	238.9 (323.90)	183.8 (249.20)
	SAE Grade 2	137.8 (186.83)	165.4 (224.25)	183.8 (249.20)	202.1 (274.01)	257.3 (348.85)	238.9 (323.90)	183.8 (249.20)
	SAE Grade 4	271.5 (368.11)	325.8 (441.73)	362.0 (490.80)	398.2 (539.89)	506.8 (687.13)	470.6 (638.05)	362.0 (490.80)
	SAE Grade 5 ASTM A449	355.2 (481.59)	426.2 (577.85)	473.6 (642.12)	521.0 (706.38)	663.0 (898.91)	615.7 (834.78)	473.6 (642.12)
	SAE Grade 7	438.0 (593.85)	525.7 (712.75)	584.1 (791.93)	642.5 (871.11)	817.7 (1108.65)	759.3 (1029.47)	584.1 (791.93)
	SAE Grade 8 ASTM A354 Grade BD	501.2 (679.54)	601.5 (815.53)	668.3 (906.09)	735.1 (996.66)	935.6 (1268.50)	868.8 (1177.94)	668.3 (906.09)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for:					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1 - 8	SAE Grade 1 ASTM A307	187.5 (254.22)	225.0 (305.06)	250.0 (338.95)	275.0 (372.85)	350.0 (474.54)	325.0 (440.64)	250.0 (338.95)
	SAE Grade 2	187.5 (254.22)	225.0 (305.06)	250.0 (338.95)	275.0 (372.85)	350.0 (474.54)	325.0 (440.64)	250.0 (338.95)
	SAE Grade 4	369.4 (500.84)	443.3 (601.03)	492.5 (667.74)	541.8 (734.58)	689.5 (934.84)	640.3 (868.13)	492.5 (667.74)
	SAE Grade 5 ASTM A449	482.8 (654.59)	579.4 (785.56)	643.8 (872.88)	708.1 (960.05)	901.3 (1222.00)	836.9 (1134.69)	643.8 (872.88)
	SAE Grade 7	596.3 (808.47)	715.5 (970.09)	795.0 (1077.88)	874.5 (1185.66)	1113.0 (1509.03)	1033.5 (1401.24)	795.0 (1077.88)
	SAE Grade 8 ASTM A354 Grade BD	681.6 (924.13)	817.9 (1108.92)	908.8 (1232.17)	999.6 (1355.28)	1272.3 (1725.00)	1181.4 (1601.77)	908.8 (1232.17)
	ASTM A354 Grade BC	596.7 (809.01)	716.1 (970.90)	795.6 (1078.69)	875.2 (1186.61)	1113.9 (1510.25)	1034.3 (1402.32)	795.6 (1078.69)

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1 - 12	SAE Grade 1 ASTM A307	205.3 278.35	246.4 (334.07)	273.8 (371.22)	301.1 (408.24)	383.3 (519.69)	355.9 (482.54)	273.8 (371.22)
	SAE Grade 2	205.3 (278.35)	246.4 (334.07)	273.8 (371.22)	301.1 (408.24)	383.3 (519.69)	355.9 (482.54)	273.8 (371.22)
	SAE Grade 4	404.1 (547.88)	484.9 (657.44)	538.8 (730.52)	592.6 (803.46)	754.3 (1022.70)	700.4 (949.62)	538.8 (730.52)
	SAE Grade 5 ASTM A449	528.8 (716.96)	634.5 (860.27)	705.0 (955.85)	775.5 (1051.44)	987.0 (1338.19)	916.5 (1242.61)	705.0 (955.85)
	SAE Grade 7	652.5 (884.67)	783.0 (1061.60)	870.0 (1179.56)	957.0 (1297.52)	1218.0 (1651.39)	1131.0 (1533.42)	870.0 (1179.56)
	SAE Grade 8 ASTM A354 Grade BD	746.3 (1011.85)	895.5 (1214.14)	995.0 (1349.04)	1094.5 (1483.49)	1393.0 (1888.66)	1293.5 (1753.73)	995.0 (1349.04)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1 - 14	SAE Grade 1 ASTM A307	210.0 (284.72)	252.0 (341.66)	280.0 (379.63)	308.0 (417.60)	392.0 (531.48)	364.0 (493.52)	280.0 (379.63)
	SAE Grade 2	210.0 (284.72)	252.0 (341.66)	280.0 (379.63)	308.0 (417.60)	392.0 (531.48)	364.0 (493.52)	280.0 (379.63)
	SAE Grade 4	413.4 (560.50)	496.1 (672.62)	551.3 (747.46)	606.4 (822.17)	771.8 (1046.42)	716.6 (971.58)	551.3 (747.46)
	SAE Grade 5 ASTM A449	540.9 (733.36)	649.1 (880.06)	721.3 (977.95)	793.4 (1075.70)	1009.8 (1369.10)	937.6 (1271.22)	721.3 (977.95)
	SAE Grade 7	668.4 (906.23)	802.1 (1087.50)	891.3 (1208.44)	980.4 (1329.25)	1247.8 (1691.79)	1158.6 (1570.85)	891.3 (1208.44)
	SAE Grade 8 ASTM A354 Grade BD	764.1 (1035.98)	916.9 (1243.15)	1018.8 (1381.31)	1120.6 (1519.33)	1426.3 (1933.80)	1324.4 (1795.65)	1018.8 (1381.30)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1-1/8 • 7	SAE Grade 1 ASTM A307	265.8 (360.37)	318.9 (432.37)	354.4 (480.50)	389.8 (528.50)	496.1 (672.62)	460.7 (624.63)	354.4 (480.50)
	SAE Grade 2	265.8 (360.37)	318.9 (432.37)	354.4 (480.50)	389.8 (528.50)	496.1 (672.62)	460.7 (624.63)	354.4 (480.50)
	SAE Grade 4	523.1 (709.23)	627.8 (851.18)	697.5 (945.68)	767.3 (1040.32)	976.5 (1323.96)	906.8 (1229.46)	697.5 (945.68)
	SAE Grade 5 ASTM A449	595.9 (807.93)	715.1 (969.55)	794.5 (1077.20)	874.0 (1184.99)	1112.3 (1508.07)	1032.9 (1400.43)	794.5 (1077.20)
	SAE Grade 7	844.8 (1145.40)	1013.8 (1374.53)	1126.4 (1527.20)	1239.0 (1679.86)	1577.0 (2138.13)	1464.3 (1985.33)	1126.4 (1527.20)
	SAE Grade 8 ASTM A354 Grade BD	966.1 (1309.86)	1159.3 (1571.80)	1288.1 (1746.43)	1416.9 (1921.06)	1803.4 (2445.08)	1674.6 (2270.46)	1288.1 (1746.43)
	ASTM A354 Grade BC	844.8 (1145.40)	1013.8 (1374.53)	1126.4 (1527.20)	1239.0 (1679.86)	1577.0 (2138.13)	1464.3 (1985.33)	1126.4 (1527.20)

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1-1/8 • 12	SAE Grade 1 ASTM A307	297.4 (403.22)	356.9 (483.89)	396.6 (537.72)	436.2 (591.40)	555.2 (752.75)	515.5 (698.93)	396.6 (537.72)
	SAE Grade 2	297.4 (403.22)	356.9 (483.89)	396.6 (537.72)	436.2 (591.40)	555.2 (752.75)	515.5 (698.93)	396.6 (537.72)
	SAE Grade 4	586.4 (795.05)	703.7 (954.09)	781.9 (1060.12)	860.1 (1166.14)	1094.6 (1484.08)	1016.4 (1378.06)	781.9 (1060.12)
	SAE Grade 5 ASTM A449	667.6 (905.14)	801.1 (1086.15)	890.2 (1206.95)	979.2 (1327.62)	1246.2 (1689.62)	1157.2 (1568.95)	890.2 (1206.95)
	SAE Grade 7	948.2 (1285.58)	1137.8 (1542.65)	1264.2 (1714.02)	1390.6 (1855.40)	1769.9 (2399.66)	1643.5 (2228.30)	1264.2 (1714.02)
	SAE Grade 8 ASTM A354 Grade BD	1083.2 (1468.62)	1299.8 (1762.30)	1444.2 (1958.07)	1588.6 (2153.85)	2021.9 (2741.33)	1877.5 (2545.55)	1444.2 (1958.07)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1-1/4 • 7	SAE Grade 1 ASTM A307	375.0 (508.43)	450.0 (610.11)	500.0 (677.91)	550.0 (745.70)	700.0 (949.07)	650.0 (881.28)	500.0 (677.91)
	SAE Grade 2	375.0 (508.43)	450.0 (610.11)	500.0 (677.91)	550.0 (745.70)	700.0 (949.07)	650.0 (881.28)	500.0 (677.91)
	SAE Grade 4	738.3 (1001.00)	885.9 (1201.12)	984.4 (1334.67)	1082.8 (1468.08)	1378.1 (1868.45)	1279.7 (1735.04)	984.4 (1334.67)
	SAE Grade 5 ASTM A449	840.2 (1139.16)	1008.3 (1367.07)	1120.3 (1518.93)	1232.3 (1670.78)	1568.4 (2126.47)	1456.4 (1974.62)	1120.3 (1518.93)
	SAE Grade 7	1191.8 (1615.87)	1430.2 (1939.09)	1589.1 (2154.53)	1748.0 (2369.97)	2224.7 (3016.30)	2065.8 (2800.85)	1589.1 (2154.53)
	SAE Grade 8 ASTM A354 Grade BD	1362.9 (1847.85)	1635.5 (2217.44)	1817.2 (2463.80)	1998.9 (2710.15)	2544.1 (3449.34)	2362.3 (3202.85)	1817.2 (2463.80)
	ASTM A354 Grade BC	1192.4 (1616.68)	1430.9 (1940.04)	1589.8 (2155.48)	1748.8 (2371.05)	2225.8 (3017.78)	2066.8 (2802.20)	1589.8 (2155.48)

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1-1/4 • 12	SAE Grade 1 ASTM A307	414.8 (562.40)	497.8 (674.93)	553.1 (749.90)	608.4 (824.88)	774.4 (1049.95)	719.1 (974.97)	553.1 (749.90)
	SAE Grade 2	414.8 (562.40)	497.8 (674.93)	553.1 (749.90)	608.4 (824.88)	774.4 (1049.95)	719.1 (974.97)	553.1 (749.90)
	SAE Grade 4	816.8 (1107.43)	980.2 (1328.97)	1089.1 (1476.62)	1198.0 (1624.27)	1524.7 (2067.22)	1415.8 (1919.57)	1089.1 (1476.62)
	SAE Grade 5 ASTM A449	930.5 (1261.60)	1116.6 (1513.90)	1240.6 (1682.03)	1364.7 (1850.29)	1736.9 (2354.92)	1612.8 (2186.66)	1240.6 (1682.03)
	SAE Grade 7	1320.7 (1790.63)	1584.8 (2148.70)	1760.9 (2387.46)	1937.0 (2626.22)	2465.3 (3342.50)	2289.2 (3103.74)	1760.9 (2387.46)
	SAE Grade 8 ASTM A354 Grade BD	1509.4 (2046.47)	1811.3 (2455.80)	2012.5 (2728.59)	2213.8 (3001.51)	2817.5 (3820.02)	2616.3 (3547.23)	2012.5 (2728.58)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1-3/8 • 6	SAE Grade 1 ASTM A307	491.1 (665.84)	589.4 (799.12)	654.8 (887.79)	720.3 (976.60)	916.8 (1243.00)	851.3 (1154.21)	654.8 (887.80)
	SAE Grade 2	491.1 (665.84)	589.4 (799.12)	654.8 (887.79)	720.3 (976.60)	916.8 (1243.00)	851.3 (1154.21)	654.8 (887.80)
	SAE Grade 4	968.1 (1312.57)	1161.7 (1575.06)	1290.8 (1750.10)	1419.9 (1925.13)	1807.1 (2450.10)	1678.0 (2275.07)	1290.8 (1750.09)
	SAE Grade 5 ASTM A449	1102.1 (1494.25)	1322.6 (1793.20)	1469.5 (1992.38)	1616.5 (2191.68)	2057.3 (2789.33)	1910.4 (2590.16)	1469.5 (1992.38)
	SAE Grade 7	1563.6 (2119.96)	1876.4 (2544.06)	2084.8 (2826.61)	2293.3 (3109.30)	2918.8 (3957.37)	2710.3 (3674.68)	2084.8 (2826.61)
	SAE Grade 8 ASTM A354 Grade BD	1786.6 (2422.30)	2144.0 (2906.88)	2382.2 (3229.83)	2620.4 (3552.79)	3335.1 (4521.80)	3096.8 (4198.70)	2382.2 (3229.83)
	ASTM A354 Grade BC	1563.6 (2119.96)	1876.4 (2544.06)	2084.8 (2826.61)	2293.3 (3109.30)	2918.8 (3957.37)	2710.3 (3674.68)	2084.8 (2826.61)

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1-3/8 • 12	SAE Grade 1 ASTM A307	559.5 (758.58)	671.3 (910.16)	745.9 (1011.30)	820.5 (1112.45)	1044.3 (1415.88)	969.7 (1314.74)	745.9 (1011.30)
	SAE Grade 2	559.5 (758.58)	671.3 (910.16)	745.9 (1011.30)	820.5 (1112.45)	1044.3 (1415.88)	969.7 (1314.74)	745.9 (1011.30)
	SAE Grade 4	1102.1 (1494.25)	1322.6 (1793.21)	1469.5 (1992.38)	1616.5 (2191.68)	2057.3 (2789.33)	1910.4 (2590.16)	1469.5 (1992.38)
	SAE Grade 5 ASTM A449	1254.3 (1700.60)	1505.1 (2040.64)	1672.3 (2267.34)	1839.6 (2494.16)	2341.3 (3174.38)	2174.0 (2947.55)	1672.3 (2267.34)
	SAE Grade 7	1780.2 (2413.63)	2136.2 (2896.30)	2373.6 (3218.17)	2611.0 (3540.04)	3323.0 (4505.39)	3085.7 (4183.65)	2373.6 (3218.17)
	SAE Grade 8 ASTM A354 Grade BD	2034.1 (2757.87)	2441.0 (3309.56)	2712.2 (3677.25)	2983.4 (4044.95)	3797.1 (5148.18)	3525.8 (4780.35)	2712.2 (3677.25)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1-1/2 • 6	SAE Grade 1 ASTM A307	652.5 (884.67)	783.0 (1061.60)	870.0 (1179.56)	957.0 (1297.52)	1218.0 (1651.39)	1131.0 (1533.43)	870.0 (1179.56)
	SAE Grade 2	652.5 (884.67)	783.0 (1061.60)	870.0 (1179.56)	957.0 (1297.52)	1218.0 (1651.39)	1131.0 (1533.43)	870.0 (1179.56)
	SAE Grade 4	1283.9 (1740.74)	1540.7 (2088.91)	1711.9 (2321.03)	1883.1 (2553.14)	2396.6 (3249.36)	2225.4 (3017.24)	1711.9 (2321.03)
	SAE Grade 5 ASTM A449	1462.5 (1982.88)	1755.0 (2379.46)	1950.0 (2643.85)	2145.0 (2908.23)	2730.0 (3701.39)	2535.0 (3437.00)	1950.0 (2643.85)
	SAE Grade 7	2074.2 (2812.24)	2489.1 (3374.77)	2765.6 (3749.66)	3042.2 (4124.67)	3871.9 (5249.60)	3595.3 (4874.58)	2765.6 (3749.66)
	SAE Grade 8 ASTM A354 Grade BD	2370.9 (3214.51)	2845.1 (3857.44)	3161.3 (4286.15)	3477.4 (4714.73)	4425.8 (6000.58)	4109.6 (5571.88)	3161.3 (4286.15)
	ASTM A354 Grade BC	2074.9 (2813.20)	2489.9 (3375.85)	2766.6 (3751.01)	3043.2 (4126.03)	3873.2 (5251.36)	3596.5 (4876.20)	2766.6 (3751.01)

All values in foot pounds and (Newton meters)

Nominal bolt size	Grade Designation and Standard	Zinc or Cadmium Plated	If instructions call for :					
			Loctite 222 or 262	Loctite 242	Loctite 271	Loctite 272	Loctite 277	Bare
1-1/2 • 12	SAE Grade 1 ASTM A307	734.1 (995.30)	880.9 (1194.34)	978.8 (1327.07)	1076.6 (1459.67)	1370.3 (1857.88)	1272.4 (1725.14)	978.8 (1327.07)
	SAE Grade 2	734.1 (995.30)	880.9 (1194.34)	978.8 (1327.07)	1076.6 (1459.67)	1370.3 (1857.88)	1272.4 (1725.14)	978.8 (1327.07)
	SAE Grade 4	1445.6 (1959.97)	1734.8 (2352.07)	1927.5 (2613.34)	2120.3 (2874.33)	2698.5 (3658.68)	2505.8 (3397.41)	1927.5 (2613.34)
	SAE Grade 5 ASTM A449	1645.3 (2230.73)	1974.4 (2676.93)	2193.8 (2974.40)	2413.1 (3271.73)	3071.3 (4164.13)	2851.9 (3866.66)	2193.8 (2974.40)
	SAE Grade 7	2334.4 (3165.02)	2801.3 (3798.06)	3112.5 (4219.99)	3423.8 (4642.05)	4357.5 (5907.98)	4046.3 (5486.05)	3112.5 (4219.99)
	SAE Grade 8 ASTM A354 Grade BD	2667.7 (3616.92)	3201.2 (4340.25)	3556.9 (4822.51)	3912.6 (5304.78)	4979.6 (6751.44)	4623.9 (6269.17)	3556.9 (4822.51)
	ASTM A354 Grade BC	—	—	—	—	—	—	—

Other Fastener Torque Specifications

All values in foot-pounds and (Newton-meters)

Nominal bolt size	18 - 8 Stainless Steel	316 Stainless Steel	Brass	Aluminum 2024 - T4
1/4 - 20	6.3 (8.54)	6.6 (8.95)	5.1 (6.91)	3.8 (5.15)
1/4 - 28	7.8 (10.57)	8.3 (11.25)	6.4 (8.67)	4.8 (6.50)
5/16 - 18	11.0 (14.90)	11.5 (15.60)	8.9 (12.06)	6.7 (9.08)
5/16 - 24	11.8 (16.00)	12.3 (16.67)	9.7 (13.15)	7.2 (9.76)
3/8 - 16	19.7 (26.71)	20.6 (27.93)	16.0 (21.70)	11.9 (16.13)
3/8 - 24	21.6 (29.28)	22.6 (30.64)	17.7 (24.00)	13.1 (17.76)
7/16 - 14	31.3 (42.44)	32.8 (44.47)	26.4 (35.80)	19.0 (25.76)
7/16 - 20	33.3 (45.15)	34.8 (47.18)	27.3 (37.00)	20.2 (27.38)
1/2 - 13	43.1 (58.43)	45.2 (61.28)	35.2 (47.72)	26.1 (35.38)
1/2 - 20	45.1 (61.14)	47.1 (63.86)	36.9 (50.00)	27.3 (37.00)
9/16 - 12	56.8 (77.00)	59.4 (80.53)	46.5 (63.04)	34.4 (46.64)
9/16 - 18	62.7 (85.00)	65.6 (88.94)	51.3 (69.55)	38.0 (51.52)
5/8 - 11	92.5 (125.41)	96.7 (131.10)	75.6 (102.50)	59.6 (80.80)
5/8 - 18	103.7 (140.60)	108.4 (146.97)	84.7 (114.84)	66.5 (90.16)
3/4 - 10	127.5 (172.86)	131.8 (178.70)	104.1 (141.14)	81.7 (110.77)
3/4 - 16	124.2 (168.39)	129.8 (175.98)	101.7 (137.88)	79.8 (108.19)

Other Fastener Torque Specifications

All values in foot-pounds and (Newton-meters)

Nominal bolt size	18 - 8 Stainless Steel	316 Stainless Steel	Brass	Aluminum 2024 - T4
7/8 - 9	194.0 (263.03)	202.5 (274.55)	158.8 (215.30)	124.6 (168.93)
7/8 - 14	193.2 (261.94)	201.7 (273.47)	157.9 (214.08)	124.2 (168.40)
1 - 8	286.7 (388.71)	299.6 (406.20)	234.6 (318.07)	183.8 (249.20)
1 - 14	259.2 (351.43)	270.8 (367.16)	212.1 (287.57)	166.3 (225.47)
1-1/8 • 7	413.0 (559.95)	432.0 (585.71)	337.0 (456.91)	265.0 (359.29)
1-1/8 • 12	390.0 (528.77)	408.0 (553.17)	318.0 (431.15)	251.0 (340.31)
1-1/4 • 7	523.0 (709.09)	546.0 (740.28)	428.0 (580.30)	336.0 (455.55)
1-1/4 • 12	480.0 (650.80)	504.0 (683.33)	394.0 (534.19)	308.0 (417.60)
1-1/2 • 6	888.0 (1203.97)	930.0 (1260.91)	727.0 (985.68)	570.0 (772.82)
1-1/2 • 12	703.0 (953.14)	732.0 (992.46)	575.0 (779.60)	450.0 (610.12)

Section






2

Shell and Door Assemblies



SHELL FRONT & DOOR ASSEMBLY 4832BHE

BMP830049
84047C



Shellfront & Door Assembly

48032BHE

BMP830049R/85463A

(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts ListóShell Front & Door Assembly

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	ASD48001	86417W*ASSY=SHELLDOOR 4832BHE	CONTAINS ITEMS 001-016
-----COMPONENTS-----				
all	1	03 48048A	88511D DRAWN SECTION=26"DOOR 4832	
all	2	12P1AGSB	SNAPBUSH 3/8MHX1/4 T=1/8HEYCO#2030	
all	3	02 15633B	88092B DR LATCH ADJ PLATE-16 GA	
all	4	X2 15016A	92622#DR HINGE MACHINED 7.499 LG	
all	5	60E004TE	04Z 1/4"OD X.170"ID NYLON TUBING *	
all	6	02 15633	ADJPLATE=DOORLATCH	
all	7	15K096A	HEXCAPSCR 3/8-16UNCX1SS18-8 1/2HEAD	
all	8	60B090	01Z AIRMT STY131 1CONV F#W013587731	
all	9	03 48060	93361D CHANNEL=DOOR OUTER 4832BWE	
all	10	03 48061	83112D CHANNEL=DOOR INNER 4832BWE	
all	11	03 48152	89137C DOOR GASKET RING 26" DOOR	
all	12	03 48157	84223B RETAINER=DOOR GASKET RING	
all	13	03 48052	84496B GASKET=DR GLASS 26"OPENING48	
all	14	03 48049	87331C RING=DR GLASS RETAINING 4832	
all	15	03 48050	84496B DR GLASS=26"DOOR OPENING 48	
all	16	SA 15 028	70239D* DOOR LATCH ASSY-DIVCYLS	
all	19	02 11162B	84527B HINGE PIN=20"DOOR-INTNLTHDS	
all	20	03 48053	93362C GASKET=53+1/2BC4832 1/16 TH	
all	21	03 48053A	93362#GASKET=53+1/2BC4832 1/8 THK	
all	22	W3 48154	93241#*RING=SHFT COSMET WELD 48	
all	23	02 11432	87321C RING LOCK 4226 QHE	
all	25	60C075	TRUCK BUMPER 2+1/2"OD+3/8"HOLE#613	
all	26	15K125	HEXCAPSCR 3/8-16UNC2AX2.5 GR5-PLTD	
all	27	15U240	FLATWASHER(USS STD) 3/8" ZNC PLT	
all	28	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	29	02 18187	83081B SPRING=OUTER DOOR 60WEHU CAD	

Interlock Plunger Assembly


BMP700630/94087V
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP700630/94087V (1 of 1)

Litho in U.S.A.



Parts List—Interlock Plunger Assembly
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
	A	SA 15 028	70239D* DOOR LATCH ASSY-DIVCYLS	
			ASSEMBLIES	
			COMPONENTS	
all	1	02 15105	RETAINER LATCHSPRING	
all	2	02 15297	91103B PLUNGER=DOORLOCK(DIVCYL)	
all	3	02 15298	CYLINDER-DOORLATCH INTERLOCK	
all	4	02 15836	68201A DOOR LATCH SPRING (302SS)	
all	5	15H090	01Z SPRNG PIN 1/4X1+7/8 LONG PLAIN	
all	6	60C122	ORING 1" ID 1/8CS BN 70 DURO #214	
all	7	60C128	ORING 1+3/8 ID 1/8CS BN 70DURO #220	

Section
Drive Assemblies

3

DRIVE BASE COMPONENTS ON HYDRO-CUSHION[®] MACHINES

General Description of Drive Mechanism

Major drive train components of the drive base include the following:

1. Drive motors: Wash, Drain, E-1 (low extract), E-2 (high extract) and Autospot. (The E1 motor is optional on 42" machines and standard on larger models except for 64" machines, which use one 2-speed extract motor. Autospot is optional on divided cylinder machines and not applicable to open pocket machines.)
2. Belts and pulleys
3. Jackshaft (The jackshaft assembly is used on 52", 60", 64" and 72" machines only. On 42" and 48" machines, the E2 (high extract) motor also serves as the jackshaft.)
4. Clutch and drum assembly
5. Gear reducer
6. Brake assembly (The brake is located on the drive base on 42" and 48" machines only. On larger models, it is located elsewhere.)
7. Centrifugal switch

Concept of Drive Train Operation—See FIGURE 1. During washing and inching, the cylinder is driven by the wash motor through the gear reducer and the clutch, while the drain motor and the extract motors merely coast. As soon as the drain valve opens, the wash motor is shut off and coasts with the extract motors, while the drain motor drives the cylinder through the reducer and clutch. During extraction, both the wash and drain motors are shut off, the clutch disengages, and the extract motor drives the cylinder through the jackshaft pulley and main "V" belt drive. At the expiration of extract, the extract motor shuts off, the brake is applied, and either the drain or wash motor (depending upon whether the drain valve is open or closed) starts and runs idle while the brake decelerates the machine. When the machine has slowed down sufficiently to actuate the centrifugal switch, the brake is automatically released, and the clutch engages, returning the machine to wash or drain speed.

Advance Preparations for Drive Assembly Maintenance

The drive train on your Milnor[®] machine has been designed to give long, trouble-free service under continuous use. Strict adherence to the lubrication schedule, proper belt tensioning, and the normal good practice of inspecting your machine regularly for possible problems is the best way of prolonging service life.




FIGURE 1 (MSSMA407BE)

Drive Base: 42" and 48" Machines

(Shows Concept of Operation For All Hydro-cushion® Washers and Dye-extractors®)

Eventually, however, drive train components may require replacement. If this becomes necessary, the following preparations and precautions will help to minimize down time:

1. Inspect belts regularly and purchase a replacement set for future use, before those on your machine become severely worn. This is especially important for the main drive belts. Purchase a belt tension tester (see "V-BELT TENSION ADJUSTMENTS") and familiarize yourself with its use. It is also recommended to stock an extra clutch tire.
2. Although any motor can fail with no prior warning, two signs of potential failure are 1) motor running slower than normal and 2) motor emitting a loud or unusual noise. If either condition is detected, immediately check for voltage fluctuations in your electrical supply. Fluctuations greater than 10% below or 10% above those specified may cause the above symptoms and are extremely detrimental to the motor. If voltage fluctuations are not detected, yet the symptom persists, then the motor will probably soon fail. A slow running motor may indicate a bad rotor; whereas a loud or unusual noise likely indicates worn bearings. If possible, make immediate repairs to avert complete failure. If this is not possible, make sure replacement parts will be on hand when needed. Note however, that if a motor is allowed to fail, this is almost sure to require a new or completely rebuilt motor.
3. Familiarize yourself with the various components of the drive base and with the procedures herein.

Motor, Belt, and Pulley Replacement

Part numbers for belts, pulleys, and related components may be found on the Drive Chart and/or Drive Assembly drawings for your machine. When ordering motors and motor parts from the Milnor[®] factory, provide the machine model and serial number and the motor function (i.e., wash, drain, E1 (low extract), E2 (high extract) or Autospot). Replacement rotors and bearings are available from Milnor[®] for some motors.

Whenever a motor, belt, or pulley is replaced, the corresponding pulleys must be precisely aligned when reinstalled, the taper lock bushing properly tightened and the belt(s), properly tensioned. (See “V-BELT TENSION ADJUSTMENTS” for tensioning procedure using a tension testing device available from the Milnor[®] factory.)

All pulleys (used for power transmission) on Milnor[®] Hydro-cushion[®] machines use taper lock bushings. This feature greatly facilitates the removal and/or adjustment of these pulleys. Components of the taperlock bushing are identified below.

To Remove a Pulley

1. See FIGURE 2.
2. Remove the belts. Release belt tension by adjusting the position of the component to which the pulley is attached with the jack screws, until the belts easily slip off of the sheave. **Do not force belts off by using a pry bar or rolling the sheave.**
3. Loosen all three bushing cap screws.
4. Put two cap screws into the push-off holes in the bushing flange and tighten alternately until the sheave has loosened from the bushing (see FIGURE 2).
5. Remove sheave and bushing from the shaft.




FIGURE 2 (MSSMA407BE)
Typical Taperlock Bushing Construction

To Maximize Belt Life

1. Never mix new and used belts on a drive.
2. Never mix belts from more than one manufacturer.
3. Always replace with the right type of belt and observe V-belt matching limits.
4. Inspect belt grooves in sheaves and replace sheave for any of the following reasons:
 - a. Worn groove side walls. Walls should be straight (not curved inward) when viewed in cross section.
 - b. Chipped or broken side walls.
 - c. Shiny groove bottoms (indicating that belt is bottoming out).

To Replace Pulleys and Belt(s)

1. Clean the tapered bore of the sheave, mating surface of the bushing, bore of the bushing, and the shaft until free of any foreign substance (including paint).

NOTE: Do not use lubricants, “Locktite,” or other adhesives on these mating surfaces.

2. Assemble the key in the shaft keyway checking to ensure the key is a snug fit, neither too tight nor too loose.
3. Loosely assemble the sheave and bushing on the shaft in the approximate location for proper belt alignment, allowing for take-up movement of the sheave. Make certain Grade 5 bolts, identified by the head marking shown in FIGURE 3, were supplied.
4. Carefully tighten the cap screws alternately and progressively until the taper is seated (approximately the “Initial Torque” as shown in the “Taperlock Bushing Bolt Torque Specs” elsewhere herein). Rotate the sheave to detect any wobble or runout (see FIGURE 2 next page).
5. Install the belts onto the sheaves (driving and driven) and with the slack of each belt on the same side, adjust




FIGURE 3 (MSSMA407BE)
Test for Pulley Alignment
(Straight edge must touch points A, B, C, and D)

the motor position with the motor mount (or other component) jack screws until all slack is taken up. **Do not force belts onto the sheaves by using a pry bar or rolling the sheaves.**

6. Check for sheave alignment as shown in FIGURES 3. The sheaves must be aligned within 1/64" per foot between shaft centerlines and in no case greater than 1/8". Readjust the sheave position as required to correct alignment.
7. Continue to alternately and progressively tighten cap screws to the "Final Torque" shown in the table. Use a torque wrench for the final torque check. When properly mounted, the gap between the bushing flange should not be less than .078" nor more than .130".
8. Check for proper belt tension and adjust if required. See "V-BELT TENSION ADJUSTMENTS" (see Table of Contents).

Taperlock Bushing Bolt Torque Specifications

Size Code (Stamped on bushing)	Bolt Size (All National Coarse Thread)	Initial torque (in lb.)	Final torque (in lb.)
G	1/4 x 5/8	48	115
H	1/4 x 3/4	48	115
P ₁	5/16 x 1	96	240
P ₂	5/16 x 1	96	240
Q ₁	3/8 x 1 1/4	174	430
Q ₂	3/8 x 1 1/4	174	430
R ₁	3/8 x 1 3/4	174	430
R ₂	3/8 x 1 3/4	174	430
S ₁	1/2 x 2 1/4	420	1080
S ₂	1/2 x 2 1/4	420	1080
SH	1/4 x 1 3/8	54	115
SDS	1/4 x 1 3/8	54	115
SD	1/4 x 1 7/8	54	115
SK	5/16 x 2	90	240
SF	3/8 x 2	180	430
M	3/4 x 6 3/4	1350	3700

Gear Reducer and Clutch

For gear reducer part numbers, see Gear Reducer Assembly and Reducer Air Seal drawings for your machine. For clutch components, see Drive Assembly drawing for your machine.

Concept of Clutch Operation—The clutch (see cross section view, next page) consists of a tubeless tire mounted to the gear reducer output shaft and a drum similar to an automobile brake drum, mounted to the jackshaft (or E2 motor shaft), within which the tire nests. When the tire is automatically inflated on command from the machine controls, it grips the inside of the drum, thus engaging the gear reducer and the jackshaft. When air pressure is released, the tire deflates, thus disengaging the gear reducer and jackshaft and allowing the machine to run in extract without overspeeding the reducer, wash motor or drain motor.

Air controlled by a solenoid valve is admitted to the clutch through a hole in the center of the gear reducer shaft. The air is prevented from entering the reducer housing itself by a mechanical end face seal located inside the air inlet on the gear reducer. The reducer is also fitted with a vented fill plug to prevent build up of air pressure in the housing, should the mechanical seal fail. A quick release valve permits instant clutch release by providing a large area “short circuit” exhaust connection near the clutch. The quick release valve is necessary for the clutch used on Milnor[®] washer-extractors, and is furnished as original equipment. The air supplied to the clutch must be free of oil and moisture.

▲ CAUTION ▲

If the machine makes a loud screeching sound like skidding automobile tires during deceleration from extract speed to wash speed, turn the *Master switch* to off immediately and refer to the troubleshooting procedures.

Alignment Requirements—The gear reducer must be positioned on the drive base such that its output shaft is on the same axis as the jackshaft (or E2 motor shaft), as shown in FIGURE 4. Otherwise, the clutch tire will not properly engage the drum. Slight misalignment reduces the service life of the clutch tire and perhaps other components. Severe misalignment may result in serious damage to the jackshaft, clutch, or gear reducer (i.e., broken shaft).

To Remove the Gear Reducer and Clutch

1. Remove all belts from the gear reducer and clutch drum pulleys as previously explained.
2. Remove the air line to the quick release valve located on the reducer air seal.
3. Remove any other components which may be mounted to the gear reducer mounting bracket, such as Autospot motor, brake assembly, etc.
4. *On all machines except 64" models*, shims are used under the gear reducer mounting bracket, to align the gear reducer.




FIGURE 4 (MSSMA407BE)
Cross Section View of Clutch

It is essential when removing the gear reducer, to record the positions of these shims so that they may be replaced in the exact same position later. Bearing this in mind, carefully remove the gear reducer mounting bracket (with the reducer attached) from the drive base. Note that the clutch tire, attached to the reducer output shaft, must be allowed to slip out of the clutch drum as the reducer is removed.

- 4a. On 64" machine models only (i.e., 64042BTN),** check and adjust the jacking bolts on the gear reducer support bracket under the input shaft side of the reducer to be sure they are just touching the drive base. Leave the angle bracket between the reducer mounting bracket and the drive base side members firmly attached to the drive base. Remove only the two bolts and one dowel pin on each side of the reducer mounting bracket that attaches it to the angle brackets.
- 5.** The gear reducer should not be unbolted from the mounting bracket unless absolutely necessary (i.e., replacing an old gear reducer with a new one); since this will complicate clutch alignment. The clutch tire may be removed from the gear reducer by removing the retaining locknut, as well as the connection where the short length of copper tubing meets the reducer shaft, then gently working the assembly off of the tapered shaft with a rubber mallet or pulling fixture. The clutch drum may also be removed from the jackshaft, if required, by removing the retaining locknut and pulling the drum off with a pulling fixture. **Do not attempt to drive the drum off with a hammer or mallet.**
- 6.** In addition to any other required maintenance, inspect the various belts and the clutch tire. These components should be replaced at this time if they show appreciable wear. It is highly recommended to replace the belts that drive the clutch drum pulley, unless these are brand new.

To Replace the Gear Reducer and Clutch—Reassemble all components in reverse order of their removal. **Remember that all components such as motors, brake, etc. must be properly adjusted, using the alignment procedures described herein.**

When the gear reducer and mounting brackets are replaced on the drive base, *with the shims replaced in their original positions*, this should achieve rough alignment of the reducer. If, however, the gear reducer was removed from its mounting brackets, or the jackshaft was removed from its housing, the reducer may be out of rough alignment.

To align the gear reducer and clutch:

- 1.** Observe the position of the clutch tire within the drum and check for clearance between the tire and drum all around, with a feeler gauge. **Determine that the tire is roughly centered within the drum. If it is, skip to step 3.** If not, proceed to step 2a or 2b.
- 2a. For all machines except 64" models,** add or remove shims from between the gear reducer mounting brackets and drive base as required to roughly position the clutch tire within the drum in accordance with the "CLUTCH ALIGNMENT REQUIREMENTS" drawing.
- 2b. On 64" machine models only (i.e., 64042BTN),** remove the two bolts and one dowel pin from each side of the gear reducer mounting bracket and using C-clamps to secure the mounting bracket to the angle brackets, adjust the position of the gear reducer to achieve rough alignment in accordance with the "CLUTCH ALIGNMENT REQUIREMENTS" drawing. If the existing bolt holes are now misaligned, either enlarge the existing holes or drill new holes as required and reinstall the four bolts. Mark any new bolt holes as being the correct ones. Do not reinstall the dowel pins.

-
3. Temporarily disconnect the internal air line to the gear reducer and connect an external, valve-controlled air line to the reducer, but do not inflate the tire yet.
 4. Loosen but do not remove the bolts that attach the gear reducer mounting brackets to the drive base. (On 64" machine models, check to be sure the jacking bolts under the input shaft side of the reducer are resting on the drive base then loosen the bolts and remove the dowel pins if they were reinstalled.)
 5. Inflate the clutch tire to cause the gear reducer to position itself with the clutch precisely centered. (It should move very little, if at all.)
 - 6a. **On all machines except 64" models**, add or remove shims as required to firmly seat the reducer mounting brackets on the drive base and tighten down the mounting bolts.
 - 6b. **On 64" machine models only (i.e., 64042BTN)**, tighten down the mounting bolts. If the dowel pin holes are aligned, reinstall the pins. If the holes are not aligned, drill new holes, install the dowel pins, and mark the new holes as being the correct ones.
 7. Replace the internal air line to the gear reducer.
 8. Energize power to the machine and run in wash, while observing for any evidence of gear reducer misalignment such as 1) wobbling of the gear reducer or related components, or 2) any apparent difficulty of the clutch tire to engage the drum (i.e., an extended squealing sound).
 9. If any of the above symptoms are observed, repeat the alignment procedures.

Jackshaft Replacement: 52", 60", 64", and 72" Machines

Jackshaft components may be found in the JACKSHAFT BEARING ASSEMBLY drawing for your machine. Replacement jackshafts are supplied, preassembled and are installed as a one-piece unit. To replace the jackshaft, proceed as follows:

1. Remove belts, gear reducer, and clutch drum exactly as previously explained.
2. Lower the drive base using the drive base jacking bolts. Remove the main drive belts and the jackshaft pulley.
3. Remove the grease fittings (or grease lines as appropriate).
4. To remove the jackshaft bearing assembly from its housing, it is convenient to remove the mounting plates from both ends of the housing. Shims may have been installed between the mounting plates and the housing to align the jackshaft within the housing. **It is essential to record the positions of these shims, so that they may be replaced in the exact same position later.**

On some models, the front mounting plate differs from the rear plate. Therefore, it is also necessary to identify the mounting plates as front or rear, so that they will be returned to the same positions. Remove each mounting plate by first unbolting the jackshaft from the plate then unbolting the plate from the housing.

5. Remove the jackshaft bearing assembly from the housing.
6. In addition to any other required maintenance, inspect all belts that were removed and replace with new belts, if they show appreciable wear.

To replace the jackshaft, reassemble all components in reverse order of their removal. Make certain that the jackshaft is properly oriented with the clutch end of the shaft to the front of the machine and that all shims are returned to their original positions. Install all jackshaft mounting bolts hand tight. Lift each end of the jackshaft with a pry bar (one end at a time) then tighten the bolts on that end, so that the jackshaft will sit as high as possible in the housing. This will provide for greater clearance between the clutch pulley and the drive base for the belts and easier alignment of the jackshaft. When tightening the bolts, tighten first the bolts that secure the jackshaft to the mounting plate, then those that secure the mounting plate to the housing. **Remember that all components such as motors, gear reducers, brakes, etc., must be properly adjusted, using the alignment procedures explained herein.**

Brake Assembly

Concept of Operation—On 42" and 48" Hydro-cushion[®] machines, the brake is located on the drive base. (The clutch drum is also the brake drum.) On 60" and 72" Staph-guard[®] machines, the brake is located on the idlershaft. On all other 52", 60", 64", and 72" machines, it is located on the cylinder shaft (thus, the main drive pulley and brake drum are combined). Machines covered by these instructions use spring loaded air cylinders to hold the brake band against the drum. Open-pocket machines use only one level of braking ("first brake") and divided cylinder machines (WE's and SG's) use two levels ("first" and "second" brake). The "first" brake is normally *on*, and braking pressure is supplied by the action of the springs inside the brake air cylinder. The "first" brake is released by applying air to the top of the air cylinder to counteract the springs. This occurs whenever the cylinder rotates under power. On divided cylinder machines, the "second" brake which is *on* whenever the cylinder is at rest *with the door open*, supplements the "first" brake with air pressure applied to the back of the air cylinder.

Brake Assembly Maintenance—For identification of brake components and specific adjustment procedures refer to the Brake Assembly, Drive Assembly and/or Brake Air Cylinder drawings for your machine. Specific adjustment procedures are also found on the Brake Assembly drawing for your machine.

The brake may be readily adjusted to compensate for wear by adjusting the nuts on the air cylinder stem. If brake components must be removed or repaired, it is essential to adjust the brake upon replacement in accordance with the Brake Assembly drawing.

NOTE: For any adjustment procedure requiring air pressure to the brake, do not attempt to perform this procedure by energizing the washer as it is not possible to release the "first" brake without the cylinder rotating under power.

To release the "first" brake without energizing the washer:

1. Disconnect the internal air line to the air cylinder. (This is the only air line to the air cylinder on open-pocket machines and the air line closest to the air cylinder stem on divided cylinder machines.)
2. Temporarily connect a direct air line to the air cylinder where the internal line was removed and apply air to release the brake.
3. On divided cylinder machines, make sure the doors are closed (to release the "second" brake).

Centrifugal Switch

Concept of Operation—After an extraction, the centrifugal switch will signal the Miltrol as soon as the washer cylinder has slowed sufficiently to permit the wash speed clutch to re-engage. Also, until this low speed has been attained, the Miltrol circuits prevent the opening of the shell door, thus providing safety interlocking.

This centrifugal switch assembly consists of three mercury tube switches wired in parallel, and connected to two copper rings. The shaft of the centrifugal switch is driven by the extract motor shaft and rotates at the same speed as the extract motor. At a predetermined speed, centrifugal force will cause the mercury switches to open the circuit. At lower speeds, there is always at least one switch closed, thus maintaining the circuit continuity. Two spring loaded carbon brushes, riding on the copper contact rings, transmit this electrical signal to the Miltrol.

This electrical signal is used to energize the speed relay at the expiration of extraction, when the predetermined reclutching speed has been reached. The combined operation of the extract relay and the speed relay in the Miltrol perform all the functions of operating the brake, clutch, and extract motors incidental to the automatic entrance into extraction, and subsequent return to wash speed.

Centrifugal Switch Maintenance—See Centrifugal Switch Assembly for your machine for identification of switch components.

The centrifugal switch is very simple, yet of *vital* importance. Failure of one of the mercury switches to make contact, an irregular contact between the brushes and the contact rings, a loose connection in the wiring, or any other condition that would cause an open circuit will prevent the clutch from engaging, in which case the machine will not operate after having braked down from extract speed.

The carbon brushes should be inspected occasionally, and replaced when worn. The copper contact rings may be cleaned with *fine* emery when needed. (Do not scratch the surface of the contact rings.)

▲ WARNING ▲

A short circuit or ground in the centrifugal switch or its associated wiring will cause the wash speed clutch to engage in high speed rotation. This condition would be identified by an extremely loud screeching sound as soon as the machine stops extracting. The sound would be similar to skidding auto tires. Such a malfunction is very dangerous and must be corrected at once before further operation.

▲ CAUTION ▲

Turn *off* power at main wall switch before entering centrifugal switch. This assembly carries high voltage, and remains energized when Miltrol master switch is *off*.


▲ CAUTION ▲

Over-lubrication of extract motor bearings will force grease into centrifugal switch housing and will cause the centrifugal switch to malfunction.



DRIVE BASE ASSY. + DRIVE CHART
4832BHE & 4836QHE

BMP820064
84102C



Drive Base Assembly and Drive Chart

48023BHE & 48036QHE

BMP820064R/97106V
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Drive Base Assembly + Drive Chart

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	ADB48001	87403D DRIVE BASE ASSY 4832BHE	
	B	D48 00160	86462R DRIVE CHART 4832BHE 60HZ	4832BHE 60HZ
	C	D48 00150	86462P DRIVE CHART 4832BHE 50HZ	4832BHE 50HZ
	D	D48 00250	92441S DRIVE CHART 4836QHE 50HZ	4836QHE 50HZ
	E	D48 00260	89373S DRIVE CHART 4836QHE 60 HZ	4836QHE 60HZ
	F	D48 00350	89373S DRIVE CHART 4836QHE 2EXT 50HZ	4836QHE 50HZ 2 EXTRACT
	G	D48 00360	89373S DRIVE CHART 4836QHE 2EXT 60HZ	4836QHE 60HZ 2 EXTRACT
-----COMPONENTS-----				
C	1	56VB120X	VBELT Bx120 RAWEDGE COG	
B,D,F,	1	56VB115XM5	VBELT Bx115 MATCHSET=5, EA = 1 BELT	
E,G	1	56VB113XM5	VBELT Bx113 MATCHSET=5, EA=1BELT	
All	2	56V40390S	FHP VBELT 4L390 A-SECTION	
B,C,F,G	3	56VB055S	VBELT SN6-5396 BP55 MATCHSET=2 EA=1	
All	4	56VB051X	VBELT Bx51 RAWEDGE COG	
B,C	5	56VR050S	VBELT 3V500	
D,E,F,G	5	56VR050S	VBELT 3V500	
All	6	560445R4SE	VPUL 4G3V4.45(SDS) TYPE QD	USE SDS BUSHING
All	6	560525R4SE	VPUL 4G3V5.25(SDS) TYPE QD	USE SDS BUSHING
B,C	7	560795R2SE	VPUL 2G3V7.95 (SDS) TYPE QD	
All	7	561055R2SK	VPUL 2G3V10-55 (SK) TYPE QD	USE SK_BUSHING
All	8	02 15918A	92102C V-PUL 3B5.2PD QD TYPE"SD"STL	USE SD BUSHING
All	9	56048B2SDS	VPUL 2B4.8/A4.0 (SDS) TYPE QD	USE SDS BUSHING
All	9	56060B2SDS	VPUL 2B6.0/A5.6 (SDS) TYPE QD	USE SDS BUSHING
All	10	02 15917	71064B VPUL=CENT SW DR A1GR 5.0PD	
All	11	56054B1H	VPUL 1B5.4/A5.0 BK60H OR EQUAL	
C only	12	56106B5SF	VPUL 5B10.6 (SF) TYPE QD	
All	12	56086B5SF	VPUL 5B8.6/A8.2 (SF) TYPE QD	USE SF BUSHING
All	12	56070B5SF	VPUL 5B7.0/A6.6 (SF) TYPE QD	USE SF BUSHING
All	13	03 48101A	89123C VPUL 5B20 BWN Pe5182 SM HUB	
All	14	X2 14075	93246# CLUTCHDRUM+2B12.4 3621WE	
All	15	56Q0RH	7/8" BUSH VPUL TYPE H,D, OR QT	
B,C	16	56Q1CSDS	1+1/8" BUSH VPUL QD TYPE SDS	
D,E,F,G	16	56Q1CQ1	1+1/8" BUSH VPUL BROWNING Q1	
All	17	56Q1AP1	1.0"BUSH VPUL BROWNING P1	
B,C,F,G	18	56Q1GP1	1+3/8" BUSH VPUL BROWNING P1	



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Drive Base Assembly + Drive Chart


Used In	Item	Part Number	Description	Comments
All	19	56Q0MHS	05Z.627" BUSH VPUL TYPE H,D,OR QT	
All	20	56Q1PQ2S	01Z1+3/4" SPLIT BUSH B#Q2	
All	21	X2 14076	962523 DRIVEFLANGE=AIRCLUTCH	
All	22	15E007	KEY #7 WOODRUFF 3/4X1/8 SAE1035	
All	23	W3 48090	93053D DRIVE BASE WELD 4832/4836	
All	24	02 19285	76688C MTRPLATE 184/215T BEND@PRINT	
All	25	02 19288	87483B BRACKET=ADJUSTING-1.5X1.75	
All	26	W2 19285B	83266# PLATE=MOTOR MTG WELDMENT	
All	28	02 16322	91282B TAP STRIP-MOTOR MTG	
All	29	5SP0GFFSSV	NPT PLUG 3/8 SQSOLIDVENTBLKSTL	
All	30	AD 28 008	93456B DRAIN=DIVCYL GAER REDUCER	
All	31	17R125A13K	83287B STUD=DRIVEBASEADJ 1+1/4X13.5	
All	32	27A005	MUFFLER 3/8" BANTAM B38	
All	33	96M051	USE KZK5B00100	
All	34	W3 48090	93053D DRIVE BASE WELD 4832/4836	
All	35	03 48138	83037B TAP STRIP=MOTOR MNT BRKT 48"	
All	36	17W050	04Z SPHERICALWASHER SET 7/8 M/F	
All	37	02 11311B	89253B MTR BASE PIVOT CLAMP 4226QHE	
All	38	54S014HC	01Z REDUCER 15.4 DORRIS#1115-60HC	
All	39	02 11430	85217C TAP STRIP=GEAR REDCR 4226QHE	



DRAWING
 (See other page for parts list,
 if applicable.)

GEAR REDUCER & AIR CLUTCH ASSY
36021, 36026 & 42026Q6x 36021BWP,CPE,NSP 42026DA1

BMP820106/97281V (Page 1)





PARTS LIST

(See other page for drawing.)

GEAR REDUCER & AIR CLUTCH ASSY

36021, 36026 & 42026Q6x 36021BWP,CPE,NSP 42026DA1

BMP820106/97281V (Page 2)

ITEM	PART NUMBER	DESCRIPTION	HOW PART IS USED IN ASSEMBLY (Only if pertinent)
00A	ADG11002	83363D*REDRCR+CLU & MTG BRACKETS 42Q	42026DA1
00B	ADG11002A	89000ZREDRCR+CLU&BRKTS INST 42	36021/26+42026Q6G/J/P
00C	A14 09900	80296\$*GEAR REDUCE+CL+MTG BKT 36021	36021BWP,CPE,NSP
001A	54S015	REDUCER 19.6 DORRIS 3220-60C OURBOX	00A
001B	54S014HC	REDUCER 15.4 DORRIS#1115-60HC OURBX	00B,00C
002	54H148A	REPLACED BY KIT PK14-0001	(SOLD AS PK14 0001)
003	X2 14076	91477# DRIVEFLANGE=AIRCLUTCH	PART OF KIT PK14 0001
004	15E225	SQMACHKEY 3/8X1+1/2 NOTAPER-NOHEAD	
005	56AHW108	TW108 BEARING LOCKWASHER	
006	56AHN08	N08 BEARING LOCKNUT	
007	02 14383	87372B PLATE=GEAR REDUCER ADAPTOR	00C
008	02 14094M	87482# ANGL=LO RDUCEER 25.25 LGBD@PT	00C
009	51A025	HEXPIPBUSH 3/8X1/4GAL 125#C1	PART OF KIT PK14 0001
010	53A040B	BODY=MAL90EL 5/16X1/4COMP W#B69X5X4	PART OF KIT PK14 0001
011	53A019B	BODY=BRMALCON 5/16X1/8COMP W#B68X5	PART OF KIT PK14 0001
012	53A060A	NUT BRASS 5/16 COMP W#61X5	PART OF KIT PK14 0001
013	53A060	SLEEVE 5/16 COMP IMP#60-F	PART OF KIT PK14 0001
014	90A020A18A	COPPER*TUBING 5/16"OD X.032 X 18"L	PART OF KIT PK14 0001
015	15U280	FLATWASHER(USS STD) 1/2" ZNC PLT	
016A	15K180	HXCAPSCR 1/2-13UNCAX2 GR5 ZINC/CAD	00A
016B	15K175	HXCAPSCR 1/2-20 UNF2A X1.75 GR5 ZNC	00B,00C
017	15G235	HEXNUT 1/2-20UNF2B SAE ZINC GR2	
018	15U300	LOKWASHER MEDIUM 1/2 ZINCPL	
019	15K145	HXCAPSCR 1/2-13UNC2AX3/4 GR5 PLATED	
020	X2 14075	82431# CLUTCHDRUM=3621WE	
021	15K043	HXCAPSCR 1/4-20UNC2AX1.5 GR5 STL/ZN	
022	15U180	LOCKWASHER MEDIUM 1/4 ZINCPL	
023	15E225	SQMACHKEY 3/8X1+1/2 NOTAPER-NOHEAD ***** END OF PARTS LIST *****	

How to Read Parts List

Reference Item Numbers—Items 00A, 00B, 00C, etc., or 00X, 00Y, 00Z, etc., appearing at the top of some parts lists, are for reference and provide:

1. The part number for the entire assembly depicted in the drawing or a major sub-assembly thereof, and/or
2. The range of machine models this drawing applies to.

If more than one reference item appears, this usually means this drawing applies to more than one assembly (and thus to more than one range of machines).

Component Item Numbers—For any item on the drawing (e.g., item ①), there may be several corresponding items on the parts list (e.g., 001A, 001B, 001C, etc.) which are similar components on different assemblies. "How Part Is Used In Assembly" identifies which components apply to your machine, by listing either the machine model, or the reference item number from the top of the parts list (e.g., 00A, 00B, 00C, etc.), or a particular characteristic (e.g., bronze or stainless steel), or special ordering information, such as a repair kit number.


Reducer Air Seal

BMP700392/2002496V
(Sheet 1 of 1)




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



00A-00C



00D-00F

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
A		54S014HC	REDUCER 15.4 DORRIS#1115-60HC	3621,3626,4226,4832, 4836
B		54S012HC	REDUCER 15.4 DORRIS #1115-25HC	SHUTL36/40/48R+L
C		54S015	REDUCER 19.6 SKK/DOR 3220-60C	4226DYE
D		54S022A	REDUCR 19.59:1 3220-300EC1	4231,4244,5238
E		54S023B	REDUCR 10.16:1 3210-375EC2	6044
F		54S025A	REDUCR 10.16:1 3210-600EC2	6442,6446,7244 6440/50
			-----COMPONENTS-----	
B-F	1	K10 0002	KIT=ROTARY AIR SEAL	
B-F	2	02 15111	GASKET AIRSEALHOUSING COVER	
B-F	3	15Q077	SOKSETSCR 1/4-20X1/4 ZINC ALLE	
all	4	02 10380	Z SHAFT COLLAR FOR AIR SEAL	
A-C	5	02 15108	COVER=ROTARY AIRSEAL HOUSING	
D-F	5	02 15108A	AIRINLET=CLUTCH DIECAST+TAP	


Parts List—Reducer Air Seal
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.



BRAKE ASSEMBLY


4226QHE & QTG. 4832BHE

BMP83DD23
86092C




NOTES:


- 1) ADJUST CLEVIS ON AIR-CYL. SO THAT CYL. ROD IS EXTENDED 1" AS SHOWN, WITH BRAKE HAND TIGHT AGAINST DRUM.
- 2) DO NOT OVERTIGHTEN PIVOT JOINTS. TIGHTEN ENOUGH TO PREVENT EXCESS LATERAL PLAY ONLY. JOINT MUST PIVOT EASILY ON THE BOLTS.
- 3) ADJUST SCREW STOPS TO APPROXIMATE DIM. SHOWN.
- 4) APPLY AIR TO BRAKE CYL. AND ROTATE 1 1/2" HEXNUT (ITEM 5) FOR 1/16" CLEARANCE AT POINT 'A', AND BRAKE LOCK FIRMLY AGAINST BOTH ANGLE AND SCREW STOPS.
- 5) THESE POINTS MUST NOT RUB ON BRAKE DRUM WHEN BRAKE IS RELEASED.



SECTION 'A-A'



SECTION 'B-B'



Brake Assembly

42026QHE,QTG 48036BHE

BMP830023R/86092A
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Brake Assembly

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
----- ASSEMBLIES -----				
	U	G15 15200	83242D BRAKE INSTALLATION 42"WED	
	V	A15 15000	83536Y STAMPED BRAKE ASSY 42WE	
	W	SA 10 019A	89483U BRAKE AIRCYL, 2WAY =42WE+DAU	
	X	G15 15200B	841772 BRAKE INSTALLATION 48"	
	Y	A15 15000B	84196Y STAMPED=BRAKE ASSY 48"	
	Z	SA 10 019	89497U BRAKE AIRCYL =BALCOM+DIVCYL	
----- COMPONENTS -----				
all	1	02 15983	80131C PLATE=BRAKE SHOE ZINCPLAT	
all	2	02 15983	80131C PLATE=BRAKE SHOE ZINCPLATE	FOR 42" MACHINES
L	3	02 15983A	84462C PLATE=BRAKE SHOE ASSY 48"	FOR 48" MACHINES
l	3	02 15984A	83093C PLATE REINFORC BRAKE SHOE	
all	4	SA 14 044B	83102B BRKSH ASSY(NON-ASB) 36,42Q+D+H	
all	5	02 02556	SUPPORT=AIRCYL 12GA ZINC PLT	
All	6	02 02547	97437B LT BRACKET=AIRCYL CAD	
all	7	02 02550	97437A BRKT=AIRCYL=RIGHT ZINC/CAD	
all	8	15G230	HXNUT 1/2-13UNC2B SAE ZINC Gr2	
all	9	15U280	01Z FL+WASHER(USS STD) 1/2 ZNC PL+D	
all	10	15K151	HXCAPSCR 1/2-13UNC24X1.25 Gr5 PLATE	
all	11	15K191	HXCAPSCR 1/2-13UNC2AX2.5 Gr5 ZNC/CD	
all	12	15K208	HXXAPSCR 9/16-12UNC2AX3.25 Gr5 ZNC	
all	13	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	14	15U280	01Z FL+WASHER(USS STD) 1/2 ZNC PL+D	
all	15	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	16	15A030	CARRIAGSCR 3/8-16UNC2X3 BLKGR2	
all	17	15K198	HXCAPSCR 1/2-13UNC2AX3 GR5-ZINC	
all	18	15U312	FLAWASHER 3/4ODX33/64IDX11GA ZINCPL	
all	19	17A020	ADJ CLEVIS MACHINES 1/2-13 ZINC PLT	
all	20	27B2750L1P	SPACER 14.3MMID 45MML 1.8MMT ST/Z	
all	21	15K100	HEXCAPSCR 3/8-16X1-1/4 SS18-8	
all	22	15U245A	01Z FLAWASH 25/64IDX1.25ODX3/32 S/S	
all	23	15G206H	HVYHEXNUT 3/8-16UNC2 SS18-8	

Brake Assembly

42026QHE,QTG 48036BHE

BMP830023R/86092A
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List, cont.—Brake Assembly

Used In	Item	Part Number	Description	Comments
all	24	03 48122	84332C BRAKE CYL BRKT 4832 BHR	FOR 48" MACHINES ONLY
	25	02 15992	91476C STOP MTG BKT=42"BRAKE BD@PRT	FOR 42" MACHINES ONLY
	25	02 15992A	95246C BRAKE STOP	FOR 48" MACHINES ONLY
	26	02 15999	73091A NUT=ADJ+SPACER=STAMPED BRAKE	FOR 42" MACHINES ONLY
	26	02 15999H	84346B NUT=ADJ+SPACER STAMP 4226QHE	FOR 48" MACHINES ONLY
all	27	15G205	HXNUT 3/8-16UNC2B ZINC Gr2	
all	28	15G230	HXNUT 1/2-13UNC2B SAE ZINC Gr2	
all	29	15G231	HXFINJAMNUT 1/2-13UNC2B ZINC Gr2	
all	30	15G235C	HXNUT 9/16-12UNC2B SAE ZINC Gr2	


Centrifugal Switch Assembly

BMP701195/2000242V
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.





Parts List—Centrifugal Switch Assembly
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
N		EDC14003	92000Z*CENTSW + MTG BRKT 3621/26F	3621Q'S MANUFACTURED AFTER JAN. 6, 1993
P		EDC14002	90000Z CENTSW+MTG BRKT 36/42QG/J/P	3621/26+4226Q4'S, Q6'S
Q		G10 05000B	84412# CENTSW ASSY=FRAME NO-PLATE	3621CPE,BWP,NSP 4226DA1, 64040/64050E6N 64046E6N/J6N/D6N
R		G03 04500A	84412C CENTSWITCH=MOTOR MT NO-PLATE	6044,6442,6446,7244
T		SAE03 088	792571 ASSY=CENSW + MOUNTBKT 42	42031,42044,48032,48036
U		SAE03 088A	83417J ASSY=CENSW + MOUNTBKT 42DYA	5238 DYE
V		ADC11001	84122D ASSY=CENSW + MOUNTBKT4226QH	4226
W		ADC14001	90351C CENT SWITCH ASSY 3621F8P	3621F8P
X		EDC14801	86252C ASSY=CENSW+MTGBRKT RWP	3621/26,4226RWP/SYS 7
Y		SAE13 001	83246I ASSY=CENSW + MOUNTBKT SWE	3626SWE
Z		SAE13 001A	83417J CENTRIFUGAL SW ASSY 42QHE	4226,4832,4836
			-----COMPONENTS-----	
1	all	09X100	CARBON BRUSH 3/16"SQ=CENSW	
2	all	ESC0001	82281B* CENT SWITCH BRUSHOLDER ASSY	
3	all	15G071	MACHSCRLOKNUIT 6-32 NM SER ZINC	
4	all	03 IF2X3	85046B INSUL.AUTOSPOT/CENTRIFUGL.SW	
5	all	60E005E	TUBING VINYL 3/8IDX.025"W #HT105C *	
6	all	12P015C	CABLECLAMP 5/16-1/2	
7	all	15G070	HXMACHSCRNUIT 6-32UNC2B ZINC GR2	
8	all	15N045	RDMACHSCR 6-32UNC2AX3/8 ZINC GR2	
9	all	15U100	LOKWASHER MEDIUM #6 ZINCPL	
10	all	15P010	12Z PHILPAN TRDCUTSCRTP10-24X1/2SS	
11	all	SAE03 012B	83407#*SLIPRING+CENT SW.ASSY(LORES)	
12	all	15U342	FLTWASH .255/.260IDX.750DX.125T SS	
13	all	15K036	05Z SKSELLOKCP SCR 1/4-20X5/8	

Parts List, cont.—Centrifugal Switch Assembly

Used In	Item	Part Number	Description	Comments
all	14	02 15582	COVER=CENSW-CADSTL	
N-R	15	03 01147	HOUSING FOR CENTRIFUGAL SWITCH	
all	15	A33 11000	75675B\$ HOUSE+BKT+SHAF=CENSW CWM	00S
T	15	A03 01300	75491C*HOUSE+BKT+SHAFT=CENSW 42+52U	
U	15	A03 01300A	75491#* HOUSE+BKT+SHAF=CENSW 42DYA	
V	15	A03 11000	82506T*CENTSWITCH=HOUSING+BRKT 42Q	
W	15	ADC14001A	93381C*C-SWITCH=MNT BRKT+HOUSING	
X	15	ADC14801	86246C*CENT SW HOUSING & BRKT ASSY	
Y	15	A13 02700	83246C\$ HOUSE+BKT+SHAF=CENSW SWE	
Z	15	A13 02700A	83246# CENSW HSG+BRKT ASSY 2SPD WAS	
T-Z only	16	17B059W	RETAIN RING-ROTOR CLIP# SH-62-ST	
T-Z only	17	A03 01400	71103B SHAFT ASSY=CENTSWITCH	
T-Z only	18	03 01147	HOUSING FOR CENTRIFUGAL SWITCH	
T-Z only	19	17B059W	RETAIN RING-ROTOR CLIP# SH-62-ST	
T	20	02 15359	CENSW MOUNTBRACKET	
U	20	03 25417	76154C BRKT=CENT SWITCH MT	
V	20	02 11452	94222D CENTRIFUGAL SWITCH BRKT-42Q	
W	20	02 14609	93381D+BRKT=CENTRIF SWITCH 3621F8P	
X	20	02 14836	89391C CENT=SW MTG BRKT	
Y	20	02 13111	77481C BRKT=CENT-SWITCH MT BND@PRNT	
Z	20	03 48170	83246C BRACKET=CENT.SW.MT.2SP WASH	
all	21	15N117	RDMACSCR 10-24UNC2X3/8SS18-8	
all	22	15U130	FLAWAS#10 .031X7/16ODX.203ID ZINCPL	
all	23	15U150	LOKWASHER MEDIUM #10 ZINCPL	
all	24	15G201	01Z HXLKNUIT 3/8-16 NYL/SS TYPE NE	

V-BELT TENSION ADJUSTMENTS FOR 30" AND 36" B-TYPE MACHINES AND 42" Q-TYPE MACHINES

This instruction is to be used for adjusting the belt tension on the following machine codes:

30016BWE	42026QHE
36021BWE	42026QTG
360326QWE	42026QTH
42026QWE	

A belt tension testing device (Milnor® part number 30T001) and a straight edge are required when using these instructions.

Tension Settings

Set the o-rings on the tension testing device (see FIGURE 1) as follows:

1. Move the upper o-ring to the topmost position, resting against the bottom edge of the cap.
2. Find the proper belt deflection setting (by machine model and belt function) in the appropriate table below.
3. Move the lower o-ring on the tension tester to this deflection setting on the inches scale.

NOTE 1: The tension testing device is marked on the one side in inches and pounds and on the other side in centimeters and kilograms. All values in the tables are marked.

NOTE 2: The instruction sheet provided with the tension testing device should not be used. Use only the instructions provided herein.

NOTE 3: The reference (ref.) codes shown in the tables are for factory use only.

Belt Tension Measurements

1. Place a straight edge along the top edge of the belt to be tested so that it spans both pulleys. Place the tension tester in the center of the belt and press and down on the cap until the lower o-ring is in line with the straight edge, as shown.
2. Read the setting of the upper o-ring on the LBS scale of the tension tester.
3. Compare this value with the acceptable range in the appropriate table. If the belt is brand new (has never been run), use the range in the Initial Tension column. If the belt is not brand new, locate the acceptable range in the Final Tension column.




FIGURE 1 (MSSM0204AE)
Tension Tester Scales




FIGURE 2 (MSSM0204AE)
Taking Measurements with the Tension Tester

4. If the reading on the tension tester is less than the range shown in the table, the belt is too loose and must be tightened. If the reading is greater than the range shown in the table, the belt is too tight and must be loosened. Adjust the belt until the reading falls within the acceptable range in the table.

30016BWE

36021BWE

	Belt Deflect. (inches)	Initial Tension (lbs.)		Belt Deflect (IN)	Initial Tension (lbs.)		Initial Tension (ref.)
		(lbs.)	(ref.)		(lbs.)	(ref.)	
WASH/2 SPEED WASH	5/16	6.6 – 9.2	KP3	13/32	5.1 – 7.1	KN	2 – 2.4 DN
	11/32	2.4 – 2.84	DP2	13/32	2.0 – 2.4	DN	2 – 2.4 DN
DRAIN	5/16	9.6 – 13.0	MP3	25/64	7.4 – 10.0	MN	7.4 – 10.0 MN
	11/32	2.8 – 4.0	EP2	13/32	2.4 – 3.37	EN	2.4 – 3.4 EN
HIGH SPEED EXTRACT	25/64	10.5 – 14.3	NP3	27/64	8.1 – 11.0	NN	8.1 – 11.0 NN
	25/64	8.0 – 11.0	LP3	27/64	6.2 – 8.5	LN	7.4 – 10.0 MN
LOW SPEED EXTRACT	11/64	9.0 – 13.0	MP3	11/64	7.4 – 10.0	MN	6.6 – 9.2 KP3
	5/32			11/64			5.1 – 7.1 KN

36026QWE

42026QWE

	Belt Deflect. (inches)	Initial Tension (lbs.)		Belt Deflect (IN)	Initial Tension (lbs.)		Initial Tension (ref.)
		(lbs.)	(ref.)		(lbs.)	(ref.)	
WASH/2 SPEED WASH	13/32	2.4 – 2.84	DP2	11/32	2.0 – 2.4	DN	7.4 – 10.0 MN
	13/32			23/64			MP3
DRAIN	25/64	9.6 – 13.0	MP3	23/64	7.4 – 10.0	MN	2.8 – 4.0 EP2
	13/32	2.8 – 4.0	EP2	23/64	2.4 – 3.34	EN	10.5 – 14.3
HIGH SPEED EXTRACT	7/16	9.6 – 13.0	MP3	7/16	7.4 – 10.0	MN	9.6 – 13.0 NP3
	7/16	8.0 – 11.0	LP3	7/16	6.2 – 8.5	LN	9.6 – 13.0 MP3
LOW SPEED EXTRACT	3/16	9.6 – 13.0	MP3	1/4	7.4 – 10.0	MN	7.4 – 10.0 MN
	3/16			1/4			6.6 – 9.2 KP3

42026QHE, QTG, QTH

	Belt Defl. (inches)	Initial Tension (lbs.)		Final Tension (lbs.)
		(lbs.)	(ref.)	
WASH/2 SPEED WASH	19/64	9.62 – 13.0	MP3	7.4 – 10.0 MN
DRAIN	5/32	10.5 – 14.3		8.1 – 11.0 NN
MAIN	31/64	10.5 – 14.3	NP3	8.1 – 11.0 NN
	15/32			
OPTIONAL LOW SPEED EXTRACT	19/64	8.0 – 11.0	LP3	6.2 – 8.5 LN

V-BELT TENSION ADJUSTMENTS FOR 48", 52", 60" AND 72" WASHER-EXTRACTORS

This instruction is to be used for adjusting the belt tension on the following machine models:

48032BHE	48032BTG	48032BTH	48036QHE	48036QTG	48036QTH		
52038WE1	52038WTF	52038WTB	52038WTG	52038WTH			
60036WE2	60036WE3	60036SG2	60036SG3	60044WE2	60044WE3	60044SG2	60044SG3
72044SG2	72044SG3	72044WE2	72044WE3	72044WTB	72044WTG	72044WTH	

A belt tension testing device (Milnor[®] part number 30T001) and a straight edge are required when tensioning unbanded belts.

Tension Settings—Unbanded Belts

Set the o-rings on the tension testing device (see FIGURE 1) as follows:

1. Move the upper o-ring to the topmost position, resting against the bottom edge of the cap.
2. Find the proper belt deflection setting (by machine model and belt function) in the appropriate table below.
3. Move the lower o-ring on the tension tester to this deflection setting on the inches scale.

NOTE 1: The tension testing device is marked on one side in inches and pounds and on the other side in centimeters and kilograms. All values in the tables are in inches (in.) and pounds (lbs.).

NOTE 2: The instruction sheet provided with the tension testing device should not be used. Use only the instructions provided herein.

NOTE 3: The reference (ref.) code shown in the tables are for factory use only.




FIGURE 1 (MSSMA405AE)
Tension Settings

Belt Tension Measurements

Unbanded Belts

1. Place a straight edge along the top edge of the belt to be tested so that it spans both pulleys. Place the tension tester in the center of the belt and press down on the cap until the lower o-ring is in line with the straight edge, as shown.
2. Read the setting of the upper o-ring on the lbs scale of the tension tester.
3. Compare this value with the acceptable range in the appropriate table. If the belt is brand new (has never been run), use the range in the Initial Tension column. If the belt is not brand new, locate the acceptable range in the Final Tension column.
4. If the reading on the tension tester is *less* than the range shown in the table, the belt is *too loose* and must be tightened. If the reading is *greater* than the range shown in the table, the belt is *too tight* and must be loosened. Adjust the belt until the reading falls within the acceptable range in the table.




FIGURE 2 (MSSMA405AE)
Measuring Belt Tension

Tensioning Banded Belts

48032BHE, BTG, BTH

48036QHE, QTG, QT

	Belt Deflect. (inches)	Initial Tension		Initial Tension		Belt Deflect (in.)	Initial Tension		Initial Tension	
		(lbs.)	(ref.)	(lbs.)	(ref.)		(lbs.)	(ref.)	(lbs.)	(ref.)
WASH/ 2 SPEED WASH	9/32	6.6 - 9.2	KP3	5.1 - 7.1	KN	5/16	5.7 - 7.6	JP3	4.4 - 5.9	JN
DRAIN	5/32	5.7 - 7.6	JP3	4.4 - 5.9	JN	5/32	6.6 - 9.2	KP3	5.1 - 7.1	KN
MAIN	50C 35/64	10.5 - 14.3	NP3	8.1 - 11.0	NN	17/32	10.5 - 14.3	NP3	8.1 - 11.0	NN
	60C 17/32									
LOW SPEED EXTRACT	13/64	6.6 - 9.2	KP3	5.1 - 7.1	KN	3/16	9.62 - 13.0	MP3	7.4 - 10.0	MN

52038WE1, WTF, WTB, WTG, WTH

60036 + 60044WE2 + WE3

	Belt Deflect. (inches)	Initial Tension		Initial Tension		Belt Deflect (in.)	Initial Tension		Initial Tension	
		(lbs.)	(ref.)	(lbs.)	(ref.)		(lbs.)	(ref.)	(lbs.)	(ref.)
WASH/ 2 SPEED WASH	25/64	10.5 - 14.3	NP3	8.1 - 11.0	NN	3/16	5.7 - 7.6	JP3	4.4 - 5.9	JN
DRAIN	5/32	10.5 - 14.3	NP3	8.1 - 11.0	NN	13/32	6.6 - 9.2	KP3	5.1 - 7.1	KN
E1	1/4	6.6 - 9.2	KP3	5.1 - 7.1	KN	17/64	6.6 - 9.2	KP3	5.1 - 7.1	KN
E2	1/2	6.6 - 9.2	KP3	5.1 - 7.1	KN	11/32	6.6 - 9.2	KP3	5.1 - 7.1	KN
MAIN	50C 11/16	18.2 - 26.0	SP3	14.0 - 20.0	SN	43/64	16.9 - 20.8	RP3	13.0 - 16.0	RN
	60C 23/32	16.9 - 20.8	RP3	13.0 - 16.0	RN	45/64				

48032BHE, BTG, BTH

48036QHE, QTG, QT

	Belt Deflect. (inches)	Initial Tension		Initial Tension		Belt Deflect (in.)	Initial Tension		Initial Tension	
		(lbs.)	(ref.)	(lbs.)	(ref.)		(lbs.)	(ref.)	(lbs.)	(ref.)
WASH/ 2 SPEED WASH	1/4	5.7 - 7.6	JP3	4.4 - 5.9	JN	17/64	5.7 - 7.6	JP3	4.4 - 5.9	JN
DRAIN	3/64	6.6 - 9.2	KP3	5.1 - 7.1	KN	33/64	6.6 - 9.2	KP3	5.1 - 7.1	KN
E-1	9/32	6.6 - 9.2	KP3	5.1 - 7.1	KN	17/64	6.6 - 9.2	KP3	5.1 - 7.1	KN
E-2	39/64	6.6 - 9.2	KP3	5.1 - 7.1	KN	5/8	6.6 - 9.2	KP3	5.1 - 7.1	KN
UPPER JACK TO LOWER JACK LOWER JACK TO UPPER JACK	BANDED BELTS NEED SPECIAL INSTRUCTIONS					BANDED BELTS NEED SPECIAL INSTRUCTIONS				

52038WE1, WTF, WTB, WTG, WTH

60036 + 60044WE2 + WE3

	Belt Deflect. (inches)	Initial Tension		Initial Tension		Belt Deflect (in.)	Initial Tension		Initial Tension		
		(lbs.)	(ref.)	(lbs.)	(ref.)		(lbs.)	(ref.)	(lbs.)	(ref.)	
WASH/ 2 SPEED WASH	15/64	5.7 - 7.6	JP3	4.4 - 5.9	JN	15/64	5.7 - 7.6	JP3	4.4 - 5.9	JN	
DRAIN	13/32	6.6 - 9.2	KP3	5.1 - 7.1	KN	25/64	6.6 - 9.2	KP3	5.1 - 7.1	KN	
E1	17/64	6.6 - 9.2	KP3	5.1 - 7.1	KN	17/64	6.6 - 9.2	KP3	5.1 - 7.1	KN	
E2	5/16	6.6 - 9.2	KP3	5.1 - 7.1	KN	5/16	6.6 - 9.2	KP3	5.1 - 7.1	KN	
MAIN	50C	45/64	16.9 - 20.8	RP3	13.0 - 16.0	RN	3/4	16.9 - 20.8	RP3	13.0 - 16.0	RN
	60C	11/16	16.9 - 20.8	RP3	13.0 - 16.0	RN	23/32	16.9 - 20.8	RP3	13.0 - 16.0	RN


Section
Bearing Assemblies

4




MAIN BEARING ASSEMBLY - 48032/48036


BMP820066
94036D




SECTION B-B



SECTION C-C




SECTION D-D




SECTION F-F


NOTE: THIS MAIN BEARING ASSEMBLY USED AFTER MARCH, 1985. FOR MAIN BEARING ASSEMBLY USED PRIOR TO MARCH, 1985 SEE BMP890050.




SECTION A-A



NOTE: SEE PREVENTATIVE MAINTENANCE/LUBRICATION PROCEDURES IN TECHNICAL MANUAL FOR INSTRUCTIONS ON LUBRICATING AND FLUSHING BEARINGS AND SEALS.



SECTION E-E



HARDWARE NOT SHOWN FOR CLARITY

Main Bearing Assembly

BMP820066R/91446A
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List Main Bearing Assembly

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	V	GBM48003	94167# MAIN BRG INSTALL LGBRG 48	ONLY
	W	GBM48003D	85000Z MAIN BEARING INSTAL 48DYE	ONLY
	X	ABM48003FE	94167E*MAIN BEARING ASSY=VRING 48	OPTIONAL VITON SEALS
	Y	ABM48003FV	94167#*BEARASY=V-RING 48 VITON	
	Z	ABM48003DV	94167@*MAIN BEARING ASSY=VRING 48D	
-----COMPONENTS-----				
all	1	X3 48203	92367D MAIN SHAFT-FORGED 48 MACHINE	
all	2	X3 64052	95103C SLEEVE=SEAL 6442BHE	
all	3	15K173A	HXCAPSCR 1/2-13UNC2AX1.75 GR5 PLATD	
all	4	15U310	LOKWASHER REGULAR 1/2 SS18-8	
X-Y	5	X3 64049A	89396# SEALHOLDER-MACH V-RINGSEAL	
Z	5	X3 64049E	89396# SEALHOLDER-S/S MACH V-RING	
X-Y	6	03 64053	92627C GASKET=F-BRG SEAL HLDER 6442	
Z	6	03 64053D	92627# GASKET=FTBRGSEALHOLDER 64DAN	
all	7	54AU254	02Z CUP TIMKEN HH228310 1/BOX + PT	
all	8	54AT127	01Z CONE TIMKEN HH228349 1/BX 20639	
all	9	X3 48202	94167# BEARHOUSE LG BRGS 48 MACHINE	
all	9	X3 48202D	88302D BEARHOUSE LG BRG MACH 48D	
all	10	03 64050	90477C FRONT BRG GREASE RET 6442BHE	
all	11	54AT101	01Z CONE TIMKEN HH221449 1/BOX+PTNO	
all	12	54AU190	01Z CUP TIMKEN HH221410 1/BOX+PT NO	
all	13	X3 48201	92292# CARRIER=REAR BNG 48 MACHINE	
all	14	15U315	LOKWASHER MEDIUM 5/8 ZINCPL	
all	15	15K223	14Z HXCPCS-5/8-11X2 GR9 2NC	
all	16	03 64051	83473C SEAL HOLD-REAR BRG 6442BHE	
all	17	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	18	15K095	HXCPCS 3/8-16UNC2AX1 GR5 ZINC/CAD	
all	19	56ATW20	TONGUE WASHER TIMKEN K91520 / AN20	
all	20	56AHW20	W20 BEARING LOCKWASHER	
all	21	56AHN20	AN20 BEARING LOCKNUT	
all	22	24S112	03Z SEAL 3.75X4.75X.500 CS/BUNA	



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List, cont.óMain Bearing Assembly

Used In	Item	Part Number	Description	Comments
all	23	15K181	05Z SKCPSCR-1/2-13X2 FULTHD BK	
all	24	15U316	05Z FLAT WASHER 5/8 GR9 ZN DICHR	
all	25	15K222A	04Z HXCPSR 5/8-11X3/4 GR8	
all	26	15K232A	04Z HXCPSR 3/4-10X2 GR8 ZC	
all	27	15U321H	03Z FLATWSH 1.500,.813ID	
all	28	60C185C	ORING 15"IDX3/16CS BUNA-N 70 #384	
X-Y	29	60C175	ORING 9.734IDX1/8CS BUNA-N 70 #273	
Z	29	60C175D	ORING 9.734IDX1/8CS VITON #273	
all	30	60C190	ORING 13.9"IDX1/4CS BUNA-N 70 #457	
all	31	5SP0CFESSV	NPT PLUG 1/8SQSOLIDBLKSTL LVENT125#	
all	32	53A059A	NUT 1/4"COMP.HOLYOKE ANDERSON#61A-4	
all	33	53A501	TUBEINSERT .170"OD	
all	34	53A500	1/4" SLEEVE-DELRIN	
all	35	53A005B	BODY=MALECONN 1/4X1/8COMP #B68A-4A	
all	36	60E004TC	02Z TUBING NYL(NAT)1/4"ODX.17 ID *	
all	37	15U281A	83286B WASHER=CLIPPED 1/2 ID .06THK	
all	38	5SL0EBEC	NPT ELBOW 90DEG STRT 1/4" BRASS 125	
all	39	53A007B	BODY=FEMCONN 1/4X1/4 COMP W#B66X4X4	
all	40	X3 64049S	92061# MACH=V-RING SEAL COVER	
all	41	03 64049G	92627C GASKET=V-RING SEAL HOLDER	
X	42	24S128FN	02Z SEAL 6.1-6.5X5.67X.31 NTL V160A	
Y-Z	42	24S128FV	03Z SEAL 6.1-6.5X5.67X.31 V1T V160A	
all	43	01 10025C	84513B BEARING+SEAL LUBEPLATE 48+64	
all	44	54M025	HYDRAULICFIT 1/8"-90 ALEMITE#1613-B	
all	45	5SB0E0CBEO	HEXPIPBUSH 1/4 X 1/8 BRASS 125#	
all	46	24S128	06Z SEAL 6.25X7.5X.5 JM8804 NITRILE	
all	47	24S128	06Z SEAL 6.25X7.5X.5 JM8804 NITRILE	
all	48	15N158	HEXCAPSCR 1/4-20NCX1/2SS18-8	
all	49	15U181	LOCKWASHER MEDIUM 1/4 SS18-8	

Section

5

Frame, Pivots, and Suspension

Footguard Assembly 4226QTH, 4832BTH, 4836QTH


BMP840019/84153B
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP840019/84153B (1 of 1)

Litho in U.S.A.



Footguard Assembly

42 + 48

BMP840019R/84276B
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Footguard Assembly

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
none				
-----COMPONENTS-----				
all	1	02 11513	93112# BRKT=FRONT STABILIZER 42QTH	
all	1	03 48181	93112E BRKT=FRONT STABILIZER 48QTH	4832,4836 ONLY
all	2	02 11505	89342D FOOTGUARD=REAR 4226 QTG&QTH	
all	2	03 48177	89417E REAR FOOTGUARD-48TG,TH	4832,4836 ONLY
all	3	W2 11516	89343#*WLDMT=FOOTGUARD-LEFT 42QTH	
all	3	W3 48180	92411#*WLDMT=FOOTGUARD-LEFT 48T	4832,4836 ONLY
all	4	W2 11515	89343#*WLDMT=FOOTGUARD RIGHT 42QTH	
all	4	W3 48179	92411#*WLDMT=FOOTGUARD-RIGHT 48T	4832,4836 ONLY
all	5	W2 11544	89091D*WLDMT=FRONT FOOTGUARD 42T	
all	5	W3 48183	89091#*WLDMT=FRONT FOOTGUARD 48T	4832,4836 ONLY
all	6	02 11538	83436C BRKT=FRT.FOOTGRD STOP 42&48T	
all	7	02 11539	91437D SIDE=FRT TILTGUARD-RIGHT	
all	8	02 11539A	91437# SIDE=FRT TILTGUARD LEFT	
all	9	02 11540	83437B STOP BRKT=FRT TILTGRD 42&48T	
all	10	03 48195	87481CBUMPER BRKT=SHLDOOR 48T	
all	11	W4 30330A	83466# HINGE WLDT=FRT.FOOTGRD42+48T	
all	12	60C075	TRUCK BUMPER 2+1/2"OD+3/8"HOLE #613	
all	13	15K151	HXCAPSCR 1/2-13UNC24X1.25 GR5 PLATE	
all	14	15U280	01Z FL+WASHER(USS STD)1/2 ZNC PL+D	
all	15	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	16	15G235	HEXNUT 1/2-20UNF2B SAE ZINC GR2	
all	17	15K105	HXCAPSCR 3/8-16UNC2A1.25 GR5 PLATED	
all	17	15K085	HEXCAPSCR 3/8-16UNC2AX3/4 GR5 ZINC	
all	18	15U240	FLATWASHER(USS STD) 3/8" ZNC PLT	
all	19	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	20	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	21	15K039	HXCAPSCR 1/4-20UNC2AX3/4 GR5 ZNC/CD	
all	22	15G177	HXNUT 1/4-28UNF2B SAE ZINC GR2	



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List, cont.—Footguard Assembly

Used In	Item	Part Number	Description	Comments
all	23	15U180	LOCKWASHER MEDIUM 1/4 ZINCPL	
all	24	15K086	HXCAPSCR 3/8-16NCX3/4 SS18-8	
all	25	15G177	HXNUT 1/4-28UNF2B SAE ZINC GR2	
all	26	15U180	LOCKWASHER MEDIUM 1/4 ZINCPL	
all	27	02 11522	86427C ENCL.=INCOMING POWER 42+48T	
all	28	W2 11517	845162*WLDMT=TILT BASE RIGHT 42QTH	
all	28	W3 48178	92297D*WLDMT=TILT BASE RIGHT 48TH	4832,4836 ONLY
all	29	W2 11518	84516\$*WLDMT=TILT BASE LEFT 42QTH	
all	29	W3 48178A	92297#*WLDMT=TILT BASE LEFT 48TH	4832,4836 ONLY
all	30	02 11514	89012# BRKT=STABILIZER+LIFT,42QTG,H	
all	30	03 48173	89012E BRKT=STABILIZER+LIFT 48TG,TH	4832,4836 ONLY

42+48 Tilt Wheel Lock Down
42026QTG, 48032BTH, 48036QTG




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP840018/99471V (1 of 1)

BMP840018/99471V
(Sheet 1 of 1)

Litho in U.S.A.



Parts List—Tilt Wheel Lock Down

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" Comments

Used In	Item	Part Number	Description	Comments
all	1	02 11552	83426CBRKT=LOCKDOWN ADJ BOLT	
All	2	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
all	3	02 11553	84143CBRKT=TILT WHEEL LOCKDOWN RGT	
all	4	02 11500A	83476BSHIM=TILT WHEEL 42&48T	
all	5	02 11506	83452BTILT WHEEL SHAFT 42,48QTG,H	
all	6	27A031B	UBOLT 1"PIPE 5/16-18.3INC	
all	8	X2 11500	85236#TILT ROLLER 42,48QTG,QTH	
all	9	15U210	LOKWASHER MEDIUM 5/16 ZINCPL	
all	10	15G185	HXNUT 5/16-18UNC2B SAE ZINC GR	
all	11	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
all	12	15U280	01ZFL+WASHER(USS STD)1/2 ZNC PL+D	
all	13	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	14	15U240	FLATWASHER(USS STD) 3/8" ZNC P	
all	15	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	16	15K151	HXCAPSCR 1/2-13UNC24X1.25 GR5	
all	17	02 18666	67273AHOLD DOWN SPACER (ROUND)	
all	18	15U255	LOKWASHER MEDIUM 3/8 ZINCPL	
all	19	15K095	HXCAPSCR 3/8-16UNC2AX1 GR5 ZINC	
all	20	15K198	HXCAPSCR 1/2-13UNC2AX3 GR5-ZIN	
all	21	15U280	01ZFL+WASHER(USS STD)1/2 ZNC PL+D	

SUSPENSION ADJUSTMENTS FOR OPEN POCKET, HYDRO-CUSHION[®] MACHINES

The suspension system on Milnor[®] Hydro-cushion[®] machines is adjusted and thoroughly tested at the factory. It should not require subsequent adjustment unless the machine is distorted during shipment or installation or unless some component of the system, such as a Hydro-cushion[®] cylinder is replaced.

There are two primary objectives when adjusting the suspension system on any Hydro-cushion[®] machine model:

1. To position the shell in the proper location within the frame (hanging dimensions) to maximize freedom of movement of the shell and to insure proper draining, and
2. To adjust the length of up and down travel at each of the push-down locations (push-down travel) so the shell will not be distorted (racked) when pushed down.

All Milnor[®] Hydro-cushion[®] machines contain these suspension system components (see FIGURE 1):

1. Hydro-cushion[®] cylinders—which suspend the shell and cylinder within the frame and provide vibration damping during extraction.
2. Pneumatic push-down devices (air bags)—which when inflated, force the shell downward where it is held against rigid pads during loading, unloading, washing, and draining.
3. Metal or rubber pads—some rigidly fixed to the shell and some rigidly fixed to the frame, which come in contact when the shell is pushed down.

The actual configuration of these components varies from model to model.

How Shell Adjustments are Made

Regardless of machine model, repositioning of the shell is always accomplished by adjusting the nuts at the top of the upper Hydro-cushion[®] shafts. To move the shell up or down at the location of any Hydro-cushion[®], see FIGURE 2 and proceed as follows:

▲ CAUTION ▲

These procedures should be accomplished with power to the machine locked off.

1. Straighten the tongues on the keyed lock washer using pliers, screw driver, etc.
2. Loosen the lock nut (upper hex nut) and move it all the way up to the top of the shaft, but do not remove it.
3. Use the adjusting nut (lower hex nut) to “crank” the shaft up or down as required.
4. Once final adjustment is made, while holding the adjusting nut to prevent it from turning, retighten the lock nut against the adjusting nut (with the lock washer between).
5. Rebend the tongues on the lockwasher as before, to prevent movement of the nuts.




FIGURE 1 (MSSM0208AE)
Hydro-cushion® Suspension System Components
 (Does not depict a specific machine)




FIGURE 2 (MSSM0208AE)
Hydro-cushion® Upper Shaft
and Adjusting Nuts

Adjustments to 42" and 48" Machines

Shell Hanging Dimensions and Adjustment Procedures—These machine models have three Hydro-cushion[®] cylinders: one on each front corner and one centered in the rear. Locate the shell hanging dimensions for your machine in FIGURE 3 and adjust your machine accordingly. The front dimension from the bottom edge of the lower frame cross brace vertically to the center of the door hinge should be repeated on the left and right sides of the door hinge to assure that the shell is horizontal, left to right.




FIGURE 3 (MSSM0208AE)
Shell Hanging Dimensions for 42" and 48" Open-Pocket Machines
(Right side view of 42" machine shown)

Push-Down Travel Dimensions and Adjustment Procedures—The arrangement of push-down stops on these machines is as shown in FIGURE 4. Each of the two rubber rest pads on the front of the machine may be raised or lowered by adding shims to or removing them from beneath the rubber pads. The rear rest pad may be adjusted by loosening the bolts on the adjustable bracket, adding shims to or removing them from between the adjustable bracket and the lower rear frame cross member, then retightening the bolts. (Extra shims and adhesive for securing them was provided with your machine.) The push-down travel dimension must be as shown for your machine in the table in FIGURE 4.

▲ CAUTION ▲

Some of the following procedures require power to the machine. Take the necessary precautions to assure that no-one operates the machine controls while personnel are adjusting the push-down components.

To adjust the push-down travel, proceed as follows:

1. With the *Master switch* set to *off* and the shell hanging free, verify that gaps A and B as shown in FIGURE 4 are correct for your machine. If not, adjust the shims as required.
2. Once the proper arrangement of shims is established, secure the shims and rest pads in position with the adhesive provided.




FIGURE 4 (MSSM0208AE)
Push-down Travel Adjustments for 42" and 48" Open Pocket Machines
(42026QWE shown)

Adjustments to 52" and 72" Machines

Shell Hanging Dimensions and Adjustment Procedures—To adjust the shell, see FIGURES 5 and 6 and proceed as follows:

1. Locate the shell hanging dimensions for your machine in the table and illustration in FIGURES 5 and 6 and adjust your machine accordingly. Take measurements on the left and right sides of the shell, to assure that the shell is horizontal, left to right.





FIGURE 5 (MSSM0208AE)
Shell Hanging Dimensions for 52" Open-Pocket Machines
(Right Side View of 52wtb Shown)

2. Check the slope of the cylinder with a 28" bubble level as shown in FIGURES 5 and 6. Note that with the appropriate size shim under one end of the level as shown, the bubble indicator should read level.
3. If further adjustment is required to achieve the proper slope of the cylinder, make small adjustments at all four corners. For example, if the cylinder slope is too slight, try raising the two front corners by 1/16" (2mm) and lowering the two rear corners by 1/16" (2mm). Always split the difference.

NOTE: Only slight deviations from the dimensions shown should be used to achieve the proper slope of the shell. If large deviations are required, this may indicate that the frame is not properly set. (Check base plate or tilt base as appropriate for level.) If not, this condition should be corrected before attempting to adjust the shell.

Push-Down Travel Dimensions and Adjustment Procedures—These machines have push-down stops on the four corners of the frame. When pushed down, the ring weldments (which move with the shell) must seat firmly onto the plugs which are mounted atop the base pads. The push-down travel dimension must assure



*This dimension applies to all 72" Open-pocket machine models.

72044WE1
72044WTG
72044WTH
72044WTB

NOTE: On these machines, the frame slopes as well as the shell and cylinder.

FIGURE 6 (MSSM0208AE)
Shell Hanging Dimensions for 72" Open-Pocket Machines
(Right Side View of 72WTB Shown)

that 1) the ring weldments and plugs are far enough apart when the shell is not pushed down, so as not to interfere with the free movement of the shell, and 2) that all four stops are in solid contact when the shell is pushed down.

▲ CAUTION ▲

Some of the following procedures require power to the machine. Take the necessary precautions to assure that no one operates the machine controls while personnel are adjusting the push-down components.




FIGURE 7 (MSSM0208AE)
Shimming and Reconnecting Ring Weldments

To adjust the push-down travel, proceed as follows:

1. With the *Master switch* set to *off* and the shell hanging free, remove the bolts securing the ring weldments to the mounting brackets. Set each ring weldment on top of its respective plug, removing any shims which may have been used and placing them next to the ring weldment.
2. Measure the gap between the top of the ring weldment and the bottom of the mounting bracket, at each location.
3. Stack shims on top of the ring weldment as required to make each gap exactly 2 inches as shown in FIGURE 7. If the gap at any location is less than 2 inches without shims, the shell must then be raised in the frame, using the procedures previously described.
4. Once the proper arrangement of shims is made, remount the ring weldment and shims to the mounting bracket (FIGURE 7). Any extra shims may be stacked on the top side of the mounting bracket plate to which the ring weldment is attached.

52" and 72" machines have valves which control the air flow to the push-down air bags. On 52" machines this is a globe valve, located on the left side of the machine, behind the waist high, front to back frame member. Throttling of this valve causes variations in the flow of air between the left side and right side push-downs. On 72" machines, a needle valve located on each push-down air bag, is used to throttle the air flow to each individual push-down.

5. While observing the movement of the shell, cycle the *Master switch* between *off* and *manual*.
6. If any rocking or twisting motion of the shell is detected as the shell pushes down, throttle the air supply valve(s) as required, to achieve a smooth even downward motion of the shell.

NOTE: On 72" open pocket machines, if any rocking or twisting motion is present when the shell pushes down, the balancing system may not function properly.

Step 7 which follows applies to 52" machines only. On these machines only, the push-down mounting brackets are adjustable up and down and must be positioned such that the air bags function within their limits of expansion and contraction. This adjustment is made as follows:

7. With the *Master switch* set to *off* and the shell hanging free, measure the gap between the push-down mounting bracket and the ring weldment mounting bracket at each location. Adjust the push-down mounting bracket to achieve a gap of 6 3/8" (162). (The gap must not drop below 6 3/8" (162) when shell is not pushed down nor exceed 8 3/8" (213) when it is pushed down as shown in FIGURE 8.)




FIGURE 8 (MSSM0208AE)
Push Down Bracket Adjustment: 52" Machines
***(Shell Shown Pushed Down)**

Adjustments to 64" Machines

Applicable Models—The procedures herein apply to the following machine models:

64042BHP

64042BTL (AAC) and later models

64042BTN (AAC) and later models

For adjustments to 64042BTL (AAA) or (AAB) models and 64042BTN (AAA) or (AAB) models consult the Milnor[®] factory.

Shell Hanging Dimensions and Adjustment Procedures—64042BHP, BTL and BTN machine models have three Hydro-cushion[®] cylinders: one on each front corner and one centered in the rear. Adjust the position of the cylinder in the frame to achieve the dimensions shown in FIGURE 9. The front dimension from the bottom edge of the base plate (not the tilt base) vertically to the centerline bolt on the shell front ring should be repeated on the left and right sides of the door hinge to assure that the shell is horizontal, left to right.

Push Down Travel Dimensions and Adjustment Procedures—64" machines have a push-down stop on each front corner and two push-down stops under the cylinder tail. When pushed down, the ring weldments (which move with the shell) must seat firmly onto the plugs which are mounted atop the lower cross braces. The push-down travel dimension must assure that 1) the ring weldments and plugs are far enough apart when the shell is not pushed down, so as not to interfere with the free movement of the shell, and 2) that all four stops are in solid contact when the shell is pushed down.




FIGURE 9 (MSSM0208AE)
Shell Hanging Dimensions for 64" Machines
(Right side view)

▲ CAUTION ▲

Some of the following procedures require power to the machine. Take the necessary precautions to assure that no one operates the machine controls while personnel are adjusting the push-down components.

To adjust push-down travel, see FIGURE 10 and proceed as follows:

1. With the *Master switch* set to *off* and the shell hanging free, unbolt the ring weldments from their mountings. On the rear push-downs only, unbolt but do not remove the plugs from their mountings, also.

2. Set the ring weldments on top of the plugs then measure the gap between each ring weldment and its mounting.
3. Remove or add shims where shown in FIGURES 10 and 11 to achieve the gaps shown. If the gap at any location is less than that specified, without shims, the shell must then be raised in the frame, using the procedures previously described.
4. Once the proper arrangement of shims is made, remount the ring weldments. On the rear members, also remount the plugs.




FIGURE 10 (MSSM0208AE)
Shimming Ring Weldments (64" Machines)




FIGURE 11 (MSSM0208AE)
Reconnecting Ring Weldments (64" Machines)

Section

6

**Control and Sensing
Devices**

VIBRATION SAFETY SWITCH ADJUSTMENTS

B What the Vibration Safety Switch Does

The *vibration safety switch* pictured below is an important safety feature. If properly adjusted, the switch will momentarily actuate as a result of repeated machine movement caused by an out-of-balance condition. Table A below illustrates the effect of the *vibration safety switch* actuation.

Table A—Effect of Tripping Vibration Safety Switch

Machine Model	Function of Vibration Safety Switch
30015, 30020, and 30022	Disables high speed extract
All microprocessor-controlled washer-extractors not listed above, and all dye machines	De-energizes three-wire relay, effectively terminating machine operation

Adjustments

When the machine leaves Milnor[®], the actuator arm is tie-wrapped to prevent damage (except on 30015, 30020, and 30022 models). **This tie wrap must be removed after the machine is set into position but before the machine is operated.**

Adjustment of this switch from the factory setting is not recommended; however, it should be checked for proper functioning and adjusted if its proper setting is lost.

As shown at right in FIGURE 1, the unit consists of a *sensitive micro-switch* with an extended actuating arm supporting an eccentric weight. The weight may be adjusted by moving it up and down on the arm and by rotating it on the arm. In addition, the *micro-switch* itself may be tilted from side to side.

The sensitivity of the switch increases as the eccentricweight is raised on the actuating arm and decreases as the weight is lowered.

The unit should be adjusted so that the actuating arm will always reset by itself, this being accomplished by rotating either the switch or the weight to give just enough bias to cause the switch to reset. Check the adjustment by moving the arm to the left then slowly releasing it. Make sure the micro-switch clicks when the arm is **slowly** released, thus indicating




FIGURE 1 (MSSMA408BE)
Vibration Switch



that it has reset. In the released position the arm should rest **lightly** but definitely against the stop on the *micro-switch* case that prevents any further arm movement to the left.

For machines with rigid mounted shells, where the machine is bolted to a very substantial foundation, very little machine movement will occur for a given degree of out-of-balance. Under such conditions it may be better to adjust the switch to be very sensitive. With less substantial foundations (e.g., ones where the sub-soil is mushy or springy or otherwise not as desirable), considerably greater machine movement will occur for a given degree of out-of-balance, in which case a less sensitive *vibration switch* setting may be indicated.



VIBRATION SWITCH ASSEMBLY

BMP700613
83211A



Vibration Switch Assembly

BMP700613R/83211A
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Vibration Switch Assy.


Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	SAE03 151	80142B* ASSY-VIBRATION SWT=LG CONTR	CONTAINS 001,002, 005-009
-----COMPONENTS-----				
all	1	02 02038	85482A PLATE INSULATING SMALL9NOV51	
all	2	15P008	02Z TRDCUT PANHD 6-32X1 NIKSTL +WAX	
all	5	02 15119	BRACKET = VIBRATION SWITCH	
all	6	09R020	04Z SWITCH NC VIBR #WZ-2RW84429-P52	
all	7	03 01059	91046A VIBSWITCH CLAMP CADSTL	
all	8	03 01058	89417A VIBSWITCH WEIGHT-CADSTL	
all	9	15P101	04Z TRDCUT-F PANHD 8-32X3/8 NIKSTL	
all	10	02 02038	85482A PLATE INSULATING SMALL9NOV51	
all	11	02 10264	BRACKET=SAFESW CAD	



COMMUTATOR ASSEMBLY

BMP701253
89296A



SECTION "A"-"A"

COVER NOT SHOWN IN THIS VIEW FOR CLARITY.

NOTE: SEE INSTRUCTION MANUAL FOR SETTING POINT GAP.

Commutator Assembly

BMP701253R/89296A
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Commutator Assembly

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	V	GDC48001	84137Y COMMUTATOR INSTL ASSY 4832	CONTAINS 00Y
	W	GDC64001	86227@ COMMUTATOR INSTL ASSY 6442	CONTAINS 00Y
	X	G52 00600	84137U COMMUTATOR INSTL ASSY	CONTAINS 00Z
	Y	SAE10 022R	86193D* COMUTASSY(3,2,1)W/DRAWN HUB	4832, 4836, 6442
	Z	SAE10 022S	86193D*COMMUTATOR ASSY=W/DRWN HUB	7244
-----COMPONENTS-----				
All	1	15P010	12Z PHILPAN TRDCUTSCRTP10-24X1/2SS	
Y	2	02 10228A	84137B COMMUTATOR CAM 4832BHE 55 DEG	
Z	2	M2 10228	CAM=COMMUTATOR-POLISHED	
Y	3	02 10406R	84347C*INSULATOR-COMMUTATOR CCW ABC	
Z	3	02 10406	INSULPLATE=BREAKPT	
All	4	09A051	86503B POINT SET WELLS #JW1108A	
All	5	15G219NTE	HXTHINLOKNUT 3/87-24NF NYL STL/ZNC	
All	6	02 10346	GASKET=COMMUTATOR COVER	
All	7	02 10062	COVER-COMMUTHOUSE	
All	8	02 10487	BRACKET=COMMUTATOR CAD	
All	9	02 10507	BEARHOUSE-CUP	
All	10	02 10114	COMMUTATOR SHAFT	
All	11	02 10508	BEARHOUS-PLATE	
All	12	15N135	RDMACSCR 10-24UNC2AX5/8 ZINC Gr8	
All	13	15U150	LOCKWASHER MEDIUM #10 ZINCPL	
All	14	15G125	HXMACHSCRNUT 10-24UNC2B ZINC Gr8	
All	15	02 10486	66086C HOUSING COMMUTATOR ZINC PLATE	
All	16	15P175	04Z TRDCUT-F HXHD 1/4-20UNC2AX1/2 N	
V ONLY	17	03 48161	84067T COMMUTATOR SUPPORT 4832	
V ONLY	18	03 48162	89292D COMMUTATOR MT BKT 4832	
All	19	15U154	LOKVAS EXTTOOTH#10 (US STD) ZINC PL	

DESCRIPTION AND MAINTENANCE OF THE ELECTRONIC BALANCING SYSTEM FOR WASHER-EXTRACTORS AND TEXTILE MACHINES

Components of the Balancing System

The water balancing system consists of electrical and mechanical components which sense the location and magnitude of an imbalance in the cylinder, and by injecting water into the rib (or ribs) opposite that imbalance, re-balance the cylinder. The basic components (FIGURE 1) include:

- *The accelerometer and balance filter board.*
- *The proximity switch and target.*
- *The analog to digital balance board.*
- *Balancing water valves, rings, and ribs.*




FIGURE 1 (MSSMA401BE)
System Components

Accelerometer and Balance Filter Board— In a flexibly supported washer-extractor (after an initial excursion at the onset of extraction), the unbalanced cylinder rotates about the center of mass resulting in the “light side out” and the “heavy side in” as shown in FIGURE 2. This causes the shell front to oscillate. The door-latch mounted accelerometer (FIGURE 12), and the filter board produce a voltage which fluctuates with this oscillation. The fluctuating voltage can be represented as a sine wave (FIGURES 6 and 7).

Proximity Switch and Target—The target passes the proximity switch once per revolution (see FIGURE 4), thus producing a timing signal.

Analog to Digital Balance Board—This board uses the accelerometer sine wave and the timing signal to determine the magnitude and location of the imbalance, and in turn control the balancing valve and safety relays mounted on the board (see FIGURE 3), the three balancing water valve relays add water to the individual ribs opposite the imbalance. The machine excursion relay (not used on ExN, JxN, TxN machines) and balance excursion relay make a microprocessor input, causing a




FIGURE 2 (MSSMA401BE)
**Flexibly Supported Machine
(Hydro-cushion[®] shown)**

causing a




FIGURE 3 (MSSMA401BE)
Balance Board Details




FIGURE 4 (MSSMA401BE)
Proximity Switch and Target (64046 E6N shown)

recycle, if shell excursions or an out-of-balance condition exceed acceptable limits. The machine excursion input causes a recycle at any time in extract, whereas the balance excursion input is checked just before the onset of high speed extraction, and then again from a few seconds after the onset of high speed extract throughout the remainder of extraction.

Balancing Water Valves, Rings, and Ribs—The water from balancing water valves enters the ribs via individual injection nozzles aimed into respective pick-up rings on the back of the cylinder. Corresponding valves, nozzles, and rings must be connected as shown in FIGURE 5.

	48032	72044	64046	72046
Cylinder rib numbering as viewed through the loading door. All cylinders rotate clockwise in extract when viewed through load door				
Cylinder pickup ring location				
Balancing water nozzle when viewed from rear of machine				
Balancing water valve locations when viewed from rear of machine				

FIGURE 5 (MSSMA401BE)
Hydro-cushion and Suspended Machines

How the Balancing System Works

Determining where the imbalance is and correcting the imbalance takes place in two steps over several revolutions. FIGURE 6, *Step One—Finding the Imbalance*, describes in detail how the machine determines the location of the imbalance.

FIGURE 7, *Step Two—Cancelling the Imbalance*, explains how the machine cancels the imbalance in two stages. During the *first stage*, the machine adds water at the same rate to both ribs opposite the imbalance. The added water in the rib nearest the imbalance, together with the original imbalance, causes the center of mass to shift exactly opposite a rib. During the *second stage*, additional water is added to the counterbalancing rib until the cylinder again rotates about its geometric center. This causes accelerometer sine waves to again fall within the normal (balanced) range and shut off the balancing water valves. The ribs retain their water during the remainder of the extraction cycle, (except for some slight leakage from the ribs which is automatically replenished).






FIGURE 6 (MSSMA401BE)
Step 1—Finding the Imbalance

In this example, the high peak of the sine wave occurs at T_3 , telling the balancing system that an imbalance is located between ribs 1 and 3, and the imbalance is closest to rib 3. Self balancing takes place in two stages over several revolutions.



The maximum excursion force G^1 , occurs next to rib 3, exactly at the area of maximum imbalance. Since no counterbalancing rib is exactly opposite the imbalance, (a requirement for balancing) the maximum excursion force must be moved to a point opposite a rib.

Simultaneously filling ribs 1 and 2 creates a new opposing excursion force G^2 . This new G^2 force modifies the vector of the original force G^1 as shown above, resulting in moving the G^1 force to a point opposite rib 2. The second stage of balancing can now begin.



At the onset of the second stage of balancing, Rib 1 stops filling while Rib 2 continues to fill. This results in moving the opposing G^2 force to a point opposite the original G^1 force. Ultimately the, two forces equalize, reducing the shell front excursion, and the amplitude of the resulting accelerometer sine waves. All water valves shut off when sine waves fall within normal (balanced operation) range and the balancing system resumes monitoring operation.

FIGURE 7 (MSSMA401BE)
Step 2—Cancelling the Imbalance

Monitoring the Balancing System

Status panel lamps monitor balancing system functions. This status panel (FIGURE 8), includes:

Balance Excursion Lamp—This lamp illuminates whenever the three wire circuit is energized. If this lamp extinguishes during E1 (low extract), the machine will not enter E2 (high extract), but recycles instead (see “Recycle Circuit” in this section).




FIGURE 8 (MSSMA401BE)
Balancing System Status Panel

Balancing Valve Lamps—These three lamps go ON and OFF with their respective balancing valves. Lamps should be OFF once balancing is completed, except for intermittent valve operation as the balancing system compensates for changing imbalances (caused by varying load thickness, different absorption rates, etc.). All three lamps should never illuminate except at the onset of low speed extraction and again at the onset of high extraction. At all other times, only one or two of the three lamps should illuminate until balance is achieved, never all three. Continuous recycling over several loads may indicate a need for service.

Balancing System Maintenance

Aiming Injection Nozzles—When properly aimed and adjusted, the injection nozzles correctly deliver balancing water from each balancing water valve to the pickup ring for the appropriate rib. If not aimed or adjusted correctly, water may splash (or fall) into the wrong pick-up ring and enter the wrong rib, rendering the system unworkable. Aim the nozzles so that the water streams gently into the intended ring. Make sure that they are exactly centered in the pickup ring as shown in FIGURE 9. Any splashing causes water to enter the wrong ring, rendering the system inoperative. Periodically check nozzle alignment and for cracks, clogs, and debris in the rings.




FIGURE 9 (MSSMA401BE)
Aiming the Balancing Nozzles




FIGURE 10 (MSSMA401BE)
Water Pressure Gauge





FIGURE 11 (MSSMA401BE)
Proximity Switch

Checking Water Pressure—Check pressure regulator for 28 PSI (1.96 Kg/sq cm) water pressure when there is no water flow and approximately 10 - 15 PSI (0.70 - 1.05 Kg/sq cm) when water valves are operating. Clean screen and/or adjust regulator as required (FIGURE 10).

Positioning the Proximity Switch—Adjust a replacement proximity switch, (FIGURE 11), .187 - .25 inch (4.75 - 6.35) from the target plate.

Preparing to Set Accelerometer—Accelerometer voltage must be adjusted with the shellfront in the drain/extract position. In order to do this, put the machine in a valid formula and stop in an wash step. The machine will drain with the shellfront at the 10 degree tilt necessary for setting the accelerometer. The following displays are typical. They may appear differently according to machine model and/or options.

RUN FORMULA
00 OR OK POWER OFF

Machine is ready for load and the *Run Formula menu* is displayed, as shown at left,
 *Accesses formula 00 .*

FILLING MACHINE

Machine filling with water

RUN FORMULA
00 FORMULA 00

① **Silences the operator signal and starts the process.**

10:38 F0005S03 2:37
dF=A055/D140 * HC3

Alternates
With

10:38 STEP01 2:37
WAIT FOR LEVEL HC3

DRAINING TO SEWER



Cancels step. The water, chemical, and steam valves close, the drain opens (machines with normally open drain valves), and the shellfront tilts to the angle necessary for the correct adjustment of the accelerometer. Machines with normally closed drain valves must be drained before continuing (See VIEWING INPUTS/OUTPUTS AND ACTUATING OUTPUTS ON THE MARK III MICROPROCESSOR CONTROL...).

3 WIRE DISABLED
FAULT: SEE MANUAL



Disables the three wire circuit, preventing machine from entering intermediate extract, and displaying an error message. cancels the formula. *Cancel button*, silences the operator signal.




FIGURE 12 MSSMA401BE
Accelerometer

Adjusting the Accelerometer—Measure accelerometer voltage at balance filter board connector from 1MTA 86-4 to 1MTA 86-5 with the machine in a formula and the cylinder tilted to the drain/extract position as described in “Preparing to Set Accelerometer” in this section. The accelerometer is adjusted by the screw (FIGURE 12). Set accelerometer voltage between 2.3 - 2.5 VDC, the higher the voltage, the more sensitive the circuit. Output voltages beyond 5 VDC indicate a defective unit.

Additional Protection for Excessive Imbalance

Two devices, the recycle and the vibration circuits, independent of the balancing system, protect the machine from excessive imbalances.

Recycle Circuit—The recycle circuit automatically redistributes an out of balance load. It becomes operational when extract commences and is actuated by the machine excursion switch (FIGURE 13). Although the excursion switch initiates a recycle anytime it is actuated during extraction, the primary purpose of this switch is to sense an excessive imbalance during the onset of extraction. When a recycle is initiated, the cylinder comes to a full stop, rotates 16 seconds CCW in wash speed, 7.5 seconds in CW wash speed, and 7.5 seconds in drain speed, then re-enters extract. During a recycle, the program timing stops, and starts again 7.5 seconds after high extract has again been achieved. The machine recycles up to five times, before repeating the final bath (without chemicals) and re-entering extraction.




FIGURE 13 (MSSMA401BE)
Excursion Switch

NOTICE

The excursion switch actuator must be exactly in the center of the slotted hole - both when the machine is pushed down and when it is hanging free. If not, the switch will actuate prematurely (during the initial excursion at the onset of extraction), causing unnecessary recycles.

Vibration Circuit—The vibration safety switch (FIGURE 14) reacts to excessive vibration which is not contained by the balancing system, actuating a switch which de-energizes the three wire relay. When this occurs, the cause of the vibration should be determined and corrected. See “VIBRATION SAFETY SWITCH ADJUSTMENTS” elsewhere in this manual.




FIGURE 14 (MSSMA401BE)
Vibration Safety Switch




BALANCING VALVE SYSTEM 4832BHE

BMP830046
83221A

FITTINGS AND INTER-CONNECTING
PARTS ARE NOT SHOWN.

CONSULT MILNOR IF THESE
COMPONENTS ARE NOT AVAIL-
ABLE FROM LOCAL SOURCES.



Balancing Valve System

4832BHE

BMP830046R/83221A
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Balancing Valve System


Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
none				
-----COMPONENTS-----				
all	1	96J031D	01Z 3/4" PRESREGULTR SET 28# FEM-UN	
all	2	30N100	07Z PRESSGUAGE 1/8"BACKCONN 0-30PSI	
all	3	96P053A37	06Z 3/4"VAL 110V HAYS #2110-6021IS	
all	4	60E086C33A	79342N HOSE ASSY=3/4"X33"LG	
all	5	60E086C25K	78522N*WATERHOSE 3/4"=25.5"LG+ENDS	



EXCURSION SWITCH ASSEMBLY

BMP830043
83207A



THIS SWITCH IS TERMED AN EXCURSION SWITCH ON ALL BUT THE BALANCING MACHINES. IT IS TERMED A RECYCLE SWITCH ON BALANCING MACHINES.

Excursion Switch Assembly

BMP830043R/83207A
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Excursion Switch Assembly

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
	A	ESL11001	83173C EXCURSION SWITCH ASSY 42+48"	CONTAINS 001-005
			-----COMPONENTS-----	
all	1	02 18542A	84372C ACTUATOR=EXCURSION SW SHELMT	
all	2	02 11436	84142B WINDOW BAR-EXCRSN SWTH 42QHE	
all	3	02 11396	83056C EXCURSION SWITCH BKT	
all	4	02 15783A	83173A*PLATE=EXCURSION SW MTG	
all	5	02 10391	COVERSTRIP-ELECTROPOL	

Pressure Regulators


BMP900031/96081V
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400


BMP900031/96081V (1 of 2)

Litho in U.S.A.



TO CLEAN OR REPLACE PARTS:

1. Remove spring cage and all parts above diaphragm.
2. Loosen and remove diaphragm lock nut, lock washer, pressure plate, and diaphragm from valve stem.
3. Unscrew seat cylinder from body and remove entire assembly.
4. While disassembled open gate valve to flush out collected sediment.



TO CLEAN OR REPLACE PARTS:

1. Remove bottom plug and gasket.
2. Loosen disc holder with screwdriver or socket wrench.
3. Inspect disc and clean or replace.
4. Seat can be removed, if necessary, with an allen wrench or socket wrench.
5. Unscrew and remove adjusting screw, check nut, and spring cage screws. Lift off spring cage, spring washer and adjusting spring.
6. Loosen and remove lock nut, washer, plate, and diaphragm.
7. Lift stem assembly upwards to remove from body.
8. To reassemble valve follow above instructions in reverse. Tighten or loosen adjusting screw for the required pressure of 28 P.S.I.



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400


Litho in U.S.A.

Parts List—Pressure Regulators


Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	X	96J030FF	01Z 1/2"PRESS REG SET 28# FEM X FEM	(NO REPAIR KIT)
	Y	96J030D	01Z 1/2" PRESREGULTR SET 28# FEM-UN	(FOR KIT, SEE BELOW)
	Z	96J031D	01Z 3/4" PRESREGULTR SET 28# FEM-UN	(FOR KIT, SEE BELOW)
-----COMPONENTS-----				
all	1	96V158B	REPAIRKIT #14510=1/2 PRESSREG EB86	(KIT/DISCONT.VLV1/2 EB72)
all	2	96V158C	REPAIRKIT #10341 FOR E24U (96J030C)	(KIT/DISCONT.VLV1/2 E24U)
Y	3	96V158D	REP.KIT #14649FOR 1/2"E72U& E86U	
all	4	96V159B	REPAIRKIT C/A#14511=3/4PRESREG EB72	(KIT/DISCONT.VLV3/4 EB72)
Z	5	96V159D	REP KIT #14648 FOR 3/4"E72U +E86U	


FOR ADJUSTMENT
PROCEDURES, SEE
MSSMA401AE.



STEP 1
RETRACT PLUNGER FULLY AND INSTALL
DIAPHRAGM. DIAPHRAGM MUST BE
FLAT AND FREE FROM WRINKLES BEFORE
INSTALLING CLAMPING RING.




STEP 2
ADVANCE PLUNGER UNTIL DIAPHRAGM
CENTER IS FLUSH WITH CLAMPING RING.
CLAMP PLUNGER IN THIS POSITION.



STEP 3
INSTALL DIAPHRAGM CLAMPING WASHER.
INSTALL DIAPHRAGM STOP WITH TWO
10 FLAT WASHERS UNDER EACH SCREW
AS SHOWN.

INNER DIAPHRAGM INSTALLATION



HYDRAULIC SENSING DEVICE ASSEMBLY
PELLERIN MILNOR CORPORATION

BMP700847
91523B

LITHO IN U.S.A.

Hydraulic Sensing Device Assembly

BMP700847R/92492A
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Hydraulic Sensing Device Assembly

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
none				
-----COMPONENTS-----				
all	1	SAE10 017	84343E* SENSING DEVICE ASSY =BWE'S	(BWE+NSE+3621 DYE ONLY)
all	1	SAE10 017A	84343#* HYD SENSING DEVICE ASY	(72 TILTS ONLY)
all	2	15G071	HXLOKNUT 6-32UNC3B ESNA#22NM-62 G2	
all	3	15G185	HXNUT 5/16-18UNC2B SAE ZINC GR2	
all	4	15G219NTE	HXTHINLOKNUT 3/8-24NF NYL STL/ZNC	
all	5	15K005	04Z SKCPSCR 6-32X3/8 SELFOK	
all	6	15N203	HXTAPSCR 5/16-18X3+1/2 ZINC FLTHDG2	
all	7	15K082	HXTAPSCR 5/16-18X4+1/2 FULTHRD ZCG5	
all	8	15N140	RDMACSCR 10-24UNC2AX3/4 ZINC GR2	
all	9	15U130	FLAWAS#10 .031X7/16ODX.203ID ZINCPL	
all	10	60C300	BOOT MICRO SEAL MS#DD10000	
all	11	5SB0E0CBEO	HEXPIPBUSH 1/4 X 1/8 BRASS 125#	
all	12	SAE10 017S	84343D* SENSDEV SWITCHMOUNT SUBASSY	
all	13	96H018	NEEDLE VALVE	
all	14	02 10246	82426B SPRING=SENS DEV RTRN 36" BLK	
all	15	15U210	LOKWASHER MEDIUM 5/16 ZINCPL	
all	16	5SP0EGFSS	NPT PLUG 1/4 SQSOLID GALSTL	
all	17	54A700	01Z BALLBUSHING-LINEAR-IK0#LBB 4	
all	18	90A020	COPPERTUBE 5/16"X.032X50' EA=1 ROLL	
all	19	02 10197	92601A INNER DIAPHRAM=SENS DEVICE	
all	21	X2 10203	70236D CHAMBER=FLUID SENSING DEVICE	
all	22	02 10205	OUTCLAMPRING=SENDEV ZNC	
all	23	02 10233	76571A RING=INNER DIAPHRAM CLAMP	
all	24	AD 10 003	70246B* OUTER DIAPHRAM CLAMPPLATE	(001A ONLY)
all	24	W5 20077	79461B*OUTER DIAPHRAM PLATE MACH.	
all	25	02 10237	89011B PLUNGER=INDIAFRAM=SENDEV+OIL	

Hydraulic Sensing Device Assembly

BMP700847R/92492A
(Sheet 2 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List, cont.—Hydraulic Sensing Device Assembly


Used In	Item	Part Number	Description	Comments
all	26	02 10247	65124ASTOP=INNERDIAPHRAM	
all	27	02 10282	85482A6 OUTER DIAFRAM=SENSDEVICE	
all	28	02 10320	76571A SCREW=SENSDEVICE ADJ#6-32	
all	29	02 10410	80253B CLAMPWASHER=INDIFRAM=SENSDEV	
all	30	02 10416	83293A WASHER=SENSDEV RETURNSPRING	
all	31	02 10454	71325A SPRING=SENSDEV CADSTL	
all	32	17B013	INTRETRING IND#3000-X50-ST-ZD-ZINC	
all	33	15G177	HXNUT 1/4-28UNF2B SAE ZINC GR2	
all	34	15P002	TRDCUT-F PAN HD 6-32UNC2AX1/4" PLTD	
all	35	15N070	FLATMACSCR 6-32UNC2AX1.75 ZINC GR2	
all	36	15U060	01Z FLAT WASHER#6 ANSI TYPEB BRASS	
all	37	15U100	LOKWASHER MEDIUM #6 ZINCPL	
all	38	02 10459	65105A SPRING-PIVOTPIN=SENSDEV CAD	
all	39	15U342	FLTWASH .255/.260IDX.750DX.125T SS	
all	40	17B006	EXTRETRING IND#1000-25-ST-ZD ZINC	
all	41	02 02038	85482A PLATE INSULATING SMALL9NOV51	
all	42	02 10198	76571A LEAF SPRING=SENSING DEVICE	
all	43	02 10455	65025A ADJSCREW=SENSDEV 1/4-28X2.75	
all	44	20L609	91213B LABEL=BALANCE.SENSING.SWITCH	
all	45	02 10320	76571A SCREW=SENSDEVICE ADJ#6-32	
all	46	02 10444	91032C BRACKET-FIXED=MICSW=SENSDEV	
all	47	02 10447	87516C MOUNT=SENSDEVSWITCH CADPLATE	
all	48	02 10448	65025A PIVOTPIN=SENSINGDEVICE S/S	
all	49	02 10456	65025A BUSHING=SENSDEV PIVOTPIN	
all	50	27B205	SPACER ROLL.178ID.313L.021T STL/ZNC	
all	51	09R021	02Z MICSW SPDT SENSING BZ-RQ-A2 (03	
all	52	15G070	HXMACHSCRNUT 6-32UNC2B ZINC GR2	



4226QTH, 4832BTH, 4836QTH
TILT LIMIT SWITCH ASSEMBLY

BMP840020
84186A

NEWER DOWN LIMIT
SWITCH MOUNTING



Tilt Limit Switch Assembly

4226QTH, 4832BTH, 4836QTH

BMP840020R/85482A
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Tilt Wheel Lockdown Assembly

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
none				
-----COMPONENTS-----				
all	1	02 11552	83426C BRKT=LOCKDOWN ADJ.BOLT	
all	2	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
all	3	02 11553	84143C BRKT=TILT WHEEL LOCKDOWN RGT	
all	4	02 11500A	83476B SHIM=TILT WHEEL 42&48T	
all	5	02 11506	83452B TILT WHEEL SHAFT 42,48QTG,H	
all	6	27A031B	01Z UBOLT 1" PIPE 5/16-18 ZINC PLAT	
all	8	X2 11500	85236# TILT ROLLER 42,48QTG,QTH	
all	9	15U210	LOKWASHER MEDIUM 5/16 ZINCPL	
all	10	15G185	HXNUT 5/16-18UNC2B SAE ZINC GR2	
all	11	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
all	12	15U280	01Z FL+WASHER(USS STD)1/2 ZNC PL+D	
all	13	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	14	15U240	FLATWASHER(USS STD) 3/8" ZNC PLT	
all	15	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	16	15K151	HXCAPSCR 1/2-13UNC24X1.25 GR5 PLATE	
all	17	02 18666	67273A HOLD DOWN SPACER (ROUND)	
all	18	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	19	15K095	HXCPSR 3/8-16UNC2AX1 GR5 ZINC/CAD	
all	20	15K198	HXCAPSCR 1/2-13UNC2AX3 GR5-ZINC	
all	21	15U280	01Z FL+WASHER(USS STD)1/2 ZNC PL+D	

UP AND DOWN LIMIT SWITCH ADJUSTMENTS FOR 42", 48", AND 64" TILTING MACHINES

The down limit switches prevent the machine from operating unless it is fully seated in the cradle. On tilt both way machines, each pair of front and rear down limit switches also prevent the opposing tilt cylinders from actuating if the adjacent tilt wheels are not fully seated (i.e., the front down limit switches won't allow the machine to tilt forward unless the front tilt wheels are fully seated). Each pair of down limit switches is connected in series to assure that the right *and* left tilt wheels are both seated. The up limit switch(es) determines the limit of tilt electrically but are set close to the point where the tilt cylinders would bottom out and mechanically prevent further tilting.

All limit switches were properly set at the Milnor[®] factory and *do not normally require adjustment when the machine is installed*. The up limit switch(es) should however, be adjusted if the tilt limits vary from those called for herein, especially if the hydraulic cylinders bottom out. The down limit switches must be checked and adjusted, if any down limit is preventing machine operation when the machine is fully seated.

FIGURE 1 shows the limit switch locations:




FIGURE 1 (MSSM0203AE)
Switch Locations (Views looking down from above)

Up Limit Switch Adjustment (Front and Rear Same)

The proper tilt limits are shown in the figures and table below. Measurements are taken from the base vertically to the center of the appropriate tilt wheel.




FIGURE 2 (MSSM0203AE)
Right Side Views Of Machine Tilted

Machine (size)	Dimension A	Dimension B
All 42" machines (e.g., 42026QTG/QTH, etc.)	24" (610)	29 9/16" (751)
All 48" machines (e.g., 48032BTG, 48036QTH, etc.)	23 13/16" (605)	27 3/4" (705)
64042BTL, suffix AAA or AAB. 64042BTN, suffix AAA	41 1/4" (1048)	46" (1168)
64042BTL, suffix AAC or higher. 64042BTN, suffix AAB or higher	32 1/2" (825)	33 3/4" (857)

To adjust either up limit switch; refer to FIGURE 3 and proceed as follows:

▲ WARNING ▲

Before performing maintenance on a tilted machine always 1) install the factory-supplied support brackets 2) lock power off and 3) have an assistant assure that no one attempts to energize or operate the machine controls.




FIGURE 3 (MSSM0203AE)

Up Limit Switch Assembly (64" Machine in Down position shown)

1. Set the up limit switch mounting bracket such that the switch is at its farthest position away from the actuating device (allowing for greatest travel of machine).
2. Energize the washer.
3. Using the tilt controls (see "NORMAL OPERATION . . ." elsewhere), tilt the machine until the limit of tilt shown in the above table is achieved.
4. Lock power *off* and install the factory supplied support brackets.
5. Reset the up limit switch mounting bracket, such that the switch is depressed by the actuating device *just enough to make the switch actuate and no more* (listen for the click). This is to insure that the switch does not bottom out and become damaged before the tilt cylinder reaches its maximum stroke. Also check to be sure that at the instant of actuation, the switch is straight with respect to the actuating device, not at an angle. Adjust if necessary.
6. Remove the support brackets and energize the machine.
7. Test the up limit switch by returning the machine to the *down* position then tilting it, allowing it to be stopped by the limit switch. Readjust if necessary.

**Down Limit Switch Adjustment
(Front and Rear Same)**

To adjust any down limit switch, see FIGURE 4 and proceed as follows:

1. Place the machine in the *down* position.
2. With the machine fully seated in the cradle, de-energize the machine.
3. Add or remove shims as needed to make switch actuating lever horizontal (see figure). This is very important.
4. Place a 3/16" shim between the switch actuating lever and the switch and reset the switch mounting bracket such that the switch bottoms out with the shim in place.
5. Remove the 3/16" shim.




FIGURE 4 (MSSM0203AE)

Down Limit Switch Assembly (64" Machine in Down position shown)

UP AND DOWN LIMIT SWITCH ADJUSTMENTS FOR 52" AND 72" TILTING MACHINES

The down limit switches prevent the machine from operating unless it is fully seated in the cradle. On tilt both way machines, each pair of front and rear down limit switches also prevent the opposing tilt cylinders from actuating if the adjacent tilt wheels are not fully seated (i.e., the front down limit switches will not allow the machine to tilt forward unless the front tilt wheels are fully seated). Each pair of down limit switches is connected in series to assure that the right *and* left tilt wheels are both seated. The up limit switch(es) determines the limit of tilt electrically but are set close to the point where the tilt cylinders would bottom out and mechanically prevent further tilting.

All limit switches were properly set at the Milnor[®] factory and *do not normally require adjustment when the machine is installed*. However, the up limit switch(es) should be adjusted if the tilt limits vary from those called for herein, especially if the hydraulic cylinders bottom out. The down limit switches must be checked and adjusted, if any down limit is preventing machine operation when the machine is fully seated.

FIGURES 1 and 2 show the limit switch locations.




FIGURE 1 (MSSMA415AE)
Switch Locations
(Views Looking Down From Above)

Up Limit Switch Adjustment (Front and Rear Same)

The proper tilt limits are shown in FIGURES 2, 3, and 4. Measurements are taken from the base vertically to the center of the appropriate tilt wheel.




FIGURE 2 (MSSMA415AE)
Right Side Views of Machine Tilted

To adjust either up limit switch, see FIGURE 3 and proceed as follows:

▲ CAUTION ▲

Before performing maintenance on a tilted machine always 1) install the factory supplied support brackets, 2) lock power *off*, and 3) have an assistant assure that no one attempts to energize or operate the machine controls.

1. Set the up limit switch mounting bracket such that the switch is at its farthest position away from the hydraulic cylinder that depresses it (allowing for greatest travel of machine).
2. Energize the washer.
3. Using the tilt controls (see "NORMAL OPERATION . . ." elsewhere), tilt the machine until the limit of tilt, shown in FIGURE 2, is achieved.
4. Lock power *off* and install the factory supplied support brackets.




FIGURE 3 (MSSMA415AE)
Up Limit Switches
(52" machine in down position)

5. Reset the up limit switch mounting bracket, such that the switch is depressed by the actuating device *just enough to make the switch actuate and no more* (listen for the click). This is to insure that the switch does not bottom out and become damaged before the tilt cylinder reaches its maximum stroke. Also check to be sure that at the instant of actuation, the switch is perpendicular to the hydraulic cylinder that depresses it, not at an angle. Adjust if necessary.
6. Remove the support brackets and energize the machine.
7. Test the up limit switch by returning the machine to the *down* position then tilting it, allowing it to be stopped by the limit switch. Readjust if necessary.

Down Limit Switch Adjustment (Front and Rear Same)

To adjust any down limit switch, see FIGURE 4 and proceed as follows:

1. Place the machine in the *down* position.
2. With the machine fully seated in the cradle, de-energize the machine.
3. Place a 1/8" shim between the switch actuating rod and the switch and reset the switch adjusting bracket on the mounting bracket such that the switch bottoms out with the shim in place.
4. Remove the 1/8" shim.




FIGURE 4 (MSSMA415AE)
Down Limit Switch Assembly
(52" machine in down position)

Section

7

Chemical Supply Devices

RULES FOR THE FIELD INSTALLATION OF PUMPED-TYPE LIQUID SUPPLY SYSTEMS


APPLICABILITY: All Washer-Extractor Models

GENERAL

Pellerin Milnor Corporation does not guarantee machines against damage from corrosion caused by improper installation and/or operation of pumped-type liquid supply systems. The following precautions must be observed when pumps are used:


1. Always install the pumping unit lower than the discharge end of the chemical delivery tube as shown at right. This will prevent any excess chemical concentrate from dribbling out of the tube and onto unprotected machine surfaces when the machine is idle.

Merely putting a "drip loop" in the delivery tube won't help much. (It might reduce the dribble a little, but not enough to prevent damage.) **The real solution is to install the pumps below the discharge end of the delivery tubes so excess chemical won't dribble out of the tube long after the pumps stop.**



2. If the machine is also equipped with a flushing supply injector:

- a. Always wire the new system so the appropriate flushing valve also operates whenever chemical is being injected. This will dilute the concentrated chemical with obvious advantages. If possible, the water flushing valve should remain on for a minimum of 30 seconds after the longest injection time for that chemical.
- b. Always inject the chemical into a plastic cup (and direct the flushing water into the same cup). This way, any chemical that dribbles out



of the tube after the pump stops will be diluted by the water remaining in the cup.

3. Never inject any concentrated chemical directly onto any metal, rubber, or plastic surface of the machine other than the plastic cups provided.


It is not enough to merely inject the chemical onto a surface that will be subsequently flushed or wetted sometime during the wash process. This is because the "culprit" is the chemical which dribbles out later. The damage occurs when the residue of a chemical (even a diluted chemical) dries on a surface—as when a chemical dribbles out of the delivery tube after the last wash cycle is finished. As the chemical dries, the water content evaporates—leaving a deposit of a very concentrated chemical which is then free to attack the host surface throughout the night (or over the weekend) or until the machine is returned to service.

The only realistic solution is to make sure that the discharge end of each chemical delivery tube is above the pump so excess chemical left in the tube after the pump stops cannot dribble out later.



SUPPLY INJECTOR & MANIFOLD ASSY.
4226QHE+QTG, 4832BHE+BTG+BTH, 4836QHE+QTG+QTH

BMP830024
83171C



Supply Injector & Manifold Assembly

4226QHE,QTG 4232BHE,BTG,BTH

4836QHE,QTG 4836QTH

BMP830024R/83426A
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Supply Injector & Manifold

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	AWP11001	88167D\$SUPPLY INLET MANIFOLD 42QHE	
	B	AWS11002	89183D*\$SUPPLY INJECTOR ASSY 42QHE	
	C	AWS11003	83093TSUPLY INJECT DOOR ASSY 42QHE	
-----COMPONENTS-----				
	1	96TCC2AA24	04Z3/8" N/C 2WAY 24V50/60C VALVE	
	2	27A002	NOZZLE BRASS 3/8" SPRAYSYSTEMS	
	3	96M001	02Z1/2X3/8" RELIEF VALVE SET31#	
	4	96J030D	01Z1/2"PRESSREG SET28# FEMXUN	
	5	30N100	08ZPRESSGAUGE 1/8"BACKCN.0-30PSI	
	6	27A017	PIPESTRP 1/2"1-HOLE R.COND.	
A	7	02 11406	90482D SUPLY INJECT BRCE UPR 42QHE	
B	7	03 48076	88291Y SUPPLY INJECTOR BRACE UPPER	
A	8	02 11355	89473D BRACE=SUPINJ 4226QHE	
B	8	03 48077	83136D SUPPLY INJECTOR BRACE LOWER	
	9	60C001	RUBBER BUMPER-BLKW/WASHER #698	
	10	W2 11353	93351D*\$WELDMENT=SUPINJ 4226+4238QHE	
	11	02 11359	88253D PARTITION SUPPLY 42+48QHE	
	12	02 11354	89183C SIDE RT LOWER COVER SUPINJ	
	13	02 11362	96206D DOOR=SUPINJ 42+48 QHE	
	14	W2 11361	93411D *SUPINJ TROUGH WLMT 42+48QHE	
	15	02 11356	86462C DIVIDER=SUPPY INJECTOR	
	16	02 11419	95243D SUPPLY INJECT VALVE COVER	
	17	03 01133C	83232C HINGE=SUPPLY INJECTOR 42+48	
	18	02 11352	88271C SUPPLY CUP HOLDER LARGE	
	19	27A125	01Z MEASURE CUP 16 OZ.STOWAY #925P	

Section

8


**Water and Steam Piping
Assemblies**



COOLDOWN INLET ASSEMBLY

BMP830042
90152A

DOTTED CONFIGURATION SHOWS
COOLDOWN INLET W/VACUUM
OPTION



FITTINGS AND INTER-CONNECTING
PARTS ARE NOT SHOWN.
CONSULT MILNOR IF THESE COMPONENTS
ARE NOT AVAILABLE FROM LOCAL SOURCES.

Cooldown Inlet Assembly

BMP830042R/90152A
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Cooldown Inlet Assembly

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	AVC11002P	92137B VACBREAK FOR COOLDOWN 42QHP	
	B	AVC11003P	92137# COOLDOWN INLET-ELEC 42QHP	
	C	AVC48001A	92137# VACBREAK FOR COOLDOWN 4832/36	
	D	AVC48002A	92137# COOLDOWN INLE-ELEC 4832/36	
	E	AVW64005A	85476L*COOLDOWN ASSY WITH VAC BRKR	
	F	AVW64005	85441L*COOLDOWN VAL ASSY NO VAC BRK	
	H	AVW14009	91176C ASSY=COOLDOWN 3621F8P	
-----COMPONENTS-----				
00g,H	1	60E086C60A	80362N*HOSE ASSY=3/4"X60"LG+ENDS	
all	2	51T030	01Z Y-STRAINER 3/4" CAST IRON	
A,B,C,D	3	96D050A	01Z 3/4"BALLVALVE BRZ WATTS#B6100	
E,F	3	96D084	01Z BALL VALVE 1" WATTS#B6100 BRZ	
A,B,C,D	4	96P053A37	06Z 3/4"VAL 110V HAYS #2110-6021IS	
E,F	4	96P151A37	05Z 1+1/4" VAL 110V HAYS2110-6021IS	
A,C,E,	5	96M022	3/4"VACBREAK	00G
00g,H	6	60E086C22A	80043N HOSE ASSY=3/4"X22"LG+ENDS	


Water Level Float Chamber

BMP810111/2003262V
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



Parts List—Water Level Float Chamber
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			ASSEMBLIES	
A		A03 03100	FLOAT CHMBR ASSY=8.25"CLDCON	DYE TANKS
B		ALL11001	*FLOAT CHAMBER INSTAL=4226QHE	4832,4836
C		A14 07200C	\$ ASSY=FLOAT SPRAY 42DAZ	3621CPE,BWP
D		ALL48001	*FLOAT CHAMBER ASSY 4832-36	4231,4244
E		AD 14 046	*FLOAT CHMBR INSTAL=35#+60#W	4226Q
F		AD 15 047	FLOAT CHMBR 25.25ASY=42+72WE	6044
G		ALL11000	*FLOAT CHMBR 33.25ASSY=4226Q	7244
H		G28 18700A	FLOAT CHAMBER 25.25 INST=60"	5238
I		G36 07500A	FLOAT CHAMBER 25.25 INST=72"	6446
J		G25 02600A	FLOAT CHAMBER INSTAL=5238	6446
K		GLL64002	FLOAT CHAMB=FRAME INSTL 64NP	6446
L		ALL64002	FLT CHAMBR ASSY64NP W/90D 1N	
			COMPONENTS	
1	aIL	W2 14432	* FLOAT-TUBE L=25.25"	FOR USE WITH REUSE SUMP
1	aIL	X2 14432K	FLOAT CHAMBER 96"LG REUSE	
1	aIL	W2 14432M	*FLOAT CHAMBER=33.25"W/90DIN	
2	AIL	X2 02239	FLOAT=PLAST LVL CONT(SANDED)	TO ORDER SEE ITEMS 30+31
3	aIL	02 02146	LEVEL CONTROL FLOAT ROD=25"L	TO ORDER SEE ITEM 30
3	aIL	02 02146E	LEVEL CONTROL FLOAT ROD=66"L	TO ORDER SEE ITEM 31
3	aIL	02 02146B	COUPLING=FLOAT ROD	FOR USE WITH REUSE SUMP
4	aIL	17N050	10-24 SPEDNUT #C10733-1024-373	TO ORDER SEE ITEMS 30+31
6	aIL	02 15642A	CLAMP-3"FLOAT CHAMBERED	
7	aIL	02 15097C	BRACKET LEVCONT PER PRINT	
8	aIL	15K039	HXCAPSCR 1/4-20UNC2AX3/4 GR5 Z	
9	aIL	15U180	LOCKWASHER MEDIUM 1/4 ZINCPL	
10	aIL	15G165	HXNUT 1/4-20UNC2BSAE ZC GR2	
11	aIL	5N0KCLSG42	NPT NIP 1/2XCLS TBE GALSTLSK40	COOLDOWN OPT.
12	aIL	5SLOKNFA	NPTTEL 90DEG 1/2 GALMAL 150#	COOLDOWN OPT
13	aIL	5N0K04AG42	NPT NIP 1/2X4 TBE GALSTL SK40	COOLDOWN OPT.
14	aIL	5SR0K0CNF	NPT RED 1/2X1/8 GALMAL 150#	COOLDOWN OPT.
15	aIL	5S0KNFA1A	NPT TEE 1/2X1/2X1" GALMAL 150#	4226,4832,4836,6442
16	aIL	5SP0KGFSS	NPT PLUG 1/2 SOSOLID GALSTL	4226,4832,4836,6442



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List, cont.—Water Level Float Chamber					
Used In	Item	Part Number	Description	Comments	
ail	17	5N1A07AG42	NPT NIP 1X7 TBE GALSTL SK40	4226,4832,4836,6442	
ail	18	5SR1A0ENF	NPT RED 1X1/4 GALMAL 150#	4226,4832,4836,6442	
ail	19	5N0KCLSG42	NPT NIP 1/2XCLS TBE GALSTLSK40	4226,4832,4836,6442	
ail	20	5SL0EBEA	NPTLNB 90DEG 1/4 BRASS 125#	SPRAY-DOWN /DYE MACHINES	
ail	21	5N0E03KBE2	NPT NIP 1/4X3.5 TBE BRASS STD	SPRAY-DOWN /DYE MACHINES	
ail	22	51V015	TEE 1/4 FGDBRASS 101T7-444	SPRAY-DOWN /DYE MACHINES	
ail	23	12P014KK	CABLE CLMP NONMTL 1/2IDX1/2WID	SPRAY-DOWN /DYE MACHINES	
ail	24	53A008B	BODYMALECON.25X.25COMP#B68A-4B	SPRAY-DOWN /DYE MACHINES	
ail	25	27A003	NOZZLE 1/4" BRASS SQUARE PATTE	SPRAY-DOWN /DYE MACHINES	
ail	26	02 10506	BRACKET-BOTTOM FLOAT=CHAMBER	3016,3621	
ail	26	02 15663	BRKT=FLOAT CHAMBER MTG	4231,4241,7244	
ail	26	02 15649	BRKT=FLOAT CHAMBER MTG	6036,6044	
ail	26	03 25298A	FLOAT CHAMBER BRACK	4832,4836,6442	
AIL	27	02 10505	BRACKET=TOP FLOATCHMBR+\$8 SU	3016,3621	
ail	27	02 15649	BRKT=FLOAT CHAMBER MTG	4231,4241,6036, 6044,7244	
ail	27	08 01065	BRACKET=LEVEL CNTRL MT 90DEG	4226DYA	
ail	27	03 25298A	FLOAT CHAMBER BRACK	4832,4836,6442	
ail	30	SA 02 011	*FLOAT ASSY L=25"-STD LEVEL	ITEMS 002,003A,004	
ail	31	SA 02 011B	*FLOAT ASSY L=66" 42DA+52DYA	ITEMS 002,003B,004	

Water Level Switch Assembly




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

BMP800186/2002226V
(Sheet 1 of 1)

Notes:

1. Disconnect power at main switch before operating this enclosure.
2. Wiring must not interfere with movement of item 8.
3. To order complete water level switch assembly, see items A-G.
4. When item 20 is used in assembly G, flange will be on top (shown).
When item 20 is used in assembly F, flange will be on bottom.



SECTION "A-A"

Parts List—Water Level Switch Assembly

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			ASSEMBLIES	
	A	ELL000MK1	*LIQUOR LEVEL SW ASSY CBW	1 UP + 0 LO
	B	ELL000MK2	*WATER LEV SW ASSY: 1 UP+ 1LO	1 UP + 1 LO
	C	ELL000MK2A	*CONVEYOR E-STOP ASSY 1UP-1DN	1 UP + 1 LO
	D	ELL000MK2S	*MK2 WATER LEVE SWITCH ASSYSS	1 UP + 1 LO SS
	E	ELL000MK3	WATER LEV SW ASSY:0 UP +1 LO	0 UP + 1 LO
	F	ELL000MK4	*WATER LEV SW ASSY:1 UP +2 LO	1 UP +2 LO
	G	ELL000MK5	\$WATER LEV SW:2UP +1LO	2 UP + 1 LO
			COMPONENTS	
A-D,F-G	1	09R014A	MINI-SW SPDT STAKON #V15G1C26K	
B-G	2	09R014A	MINI-SW SPDT STAKON #V15G1C26K	
F-G	3	09R014WS	MICROSW SPDT STAKON V3-2101-D8	
004-C,E-G	4	02 02150M	SW MOUNTPLATE=LEVCONT ZINCPL	
D only	4	02 02150S	PLATE=SWITCH MNT LEVEL S/S	
all	5	01 10227	LABEL=WATER LEVEL SWITCH ASMB	
all	6	02 02152	BUSHING=FLOAT LEVER	
all	7	02 02164	INSULATION=V3-1 MICROSWITCH	
all	8	02 02190	FLOATLEVER=LEVEL SW	
A-C-E-G	9	02 02553	BASE=LEVEL CONTROL	
D only	9	02 02553S	BASE=LEVEL CONTROL ENCL S/S	
A-B-E-G	10	02 02554	COVER=LEVEL CONTROL-PLTD	
C only	10	02 02554A	COVER=CONVEYOR E-STOP-PLATED	
D only	10	02 02554S	WATER LEVEL CONTROL ENCL S/S	
all	11	15N019	RDMACSCR 4-40UNC2AX5/8 ZINC GR	
all	12	15U021	LOKWASH EXTTOOTH #4 (US STD) ZI	
A-C-E-G	13	15N055	RDMACHSCR 6-32UNC2AX5/8 ZINC G	
A-C,E-G	14	15G070	HXMACHSCRNUT 6-32UNC2B ZINC GR	
D	14	15G075	HEX MACH SCREW NUT 6-32UNC2 S	
all	15	15U060	FLAT WASHER#6 ANSI TYPEB BRASS	
A-C,E-G	16	15U100	LOKWASHER MEDIUM #6 ZINCPL	
D only	16	15U102	LOKWASHER MEDIUM #6 SS18-8	
A-C,E-G	17	15P105	TRDCUT-F PANHD 8-32X5/8 NIKSTL	
D only	17	15P103	TRDCUT-F RDHDSLOT 8-32UNCX1/2	
all	18	15P100	#8 X 3/8 PHILPANHD TYPE B SMS	
F-G only	19	15N021	RDMACSCR 4-40 UNC2X1 ZINC PLT	
F-G only	20	03 01462C	ANGLE=H20 LEVEL ACTUATOR	
F-G only	21	15J051	POPRIVET 1/8DIAX.265 LONG S/S	

3 & 4 Inch Dump Valve Assembly

BMP800228/2002226V
(Sheet 1 of 2)




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

▲ WARNING ▲



EXPLOSION HAZARD--Air cylinder can burst apart with great force. Circled items are under high spring tension. Follow maintenance instructions MSSM0130AE carefully.



Parts List—3 & 4 Inch Dump Valve Assembly
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			ASSEMBLIES	
N	W2	15997	BODY=4" DUMPVALVE=4231WE+SG	CBW REUSE TANK
P	AVD	14003	91000Z ASSY DMPVALVE 36QU	3621/26Q4G/J/P, Q6G/J/P
Q	AVD	14001A	89000Z ASSY=DUMP VALVE 42S6P	4226Q4G/J/P,Q6G/J/P
R	AVD	14001	89000Z ASSY=DUMP VALVE 3621F8P	3621F8P
S	A14	06500B	82341T*DUMP VALVE ASSY=4S/S 4226QHE	4840F7J,F7W,F7N,F7B 48/42QTL/N/H/P, 48BTL/N/H/P
T	A15	15100	84242C 4"SGL.DUMPVALVE 4231WE+SG	4231WP2,WP3WW CBW@.4232F7J,P,W 3630F8J,W,P
U	A14	06500	84242@*DUMP VALVE ASSY=4"NPT SS	3621NSP
V	A14	06500A	84242J* 4"SS DUMPVALVE=3621+4226DYA	4226DA1
W	A14	06500F	84266@ DUMPVALVE=10GA 4" S/S	4226DP1,DYP
X	SA	09_013A	84242C*DUMP VALVE ASSY-3"NPT SS	3016NSE
Y	A14	06400	89457U* BONNET+CYL=4"SS DIVCYL DUMP	00N-00T(CONTAINS 1-23)
Z	A14	06400A	89457%* BONNET+AIRCYL=4"DYA DUMPVAL	00U-00X(CONTAINS 1-23)
			COMPONENTS	
all	1	02 02101	71334A CYLHEAD W/TAPPED HOLE	
Y	2	15U210	LOKWASHER MEDIUM 5/16 ZINCP	
Z	2	15U205	LOCKWASHER MEDIUM 5/16" 18-8SS	
Y	3	60C132	ORING 2"ID 3/16CS BUNA 70 DURO #329	
Z	3	60C132V	ORING 2 ID 3/16CS VITON 75 # 329	
all	4	02 02068	94266A AIRCYL-STAINLESS=DUMPVALVE	
Y	5	02 10585D	91142# TIE BOLT=5/16-18X7.875 PLTD	
Z	5	02 10585	91142B TIE BOLT=5/16-18X7.875LG SS	
all	6	03 01313	70219A STOP=AIR CYL W/2+11/16STROKE	
all	7	15G220	02Z LTHX THIN LOKNUT 3/8-24 SSNTE	
all	8	02 02085	75161A UP WASHER=2"OD=PISTONCUP	
all	9	02 02194	93217B PISTONCUP=DUMPVALVE 2+3/8"	
all	10	02 02105B	92253B 2.38"ACYL BRASS PISCUP WASHR	
Y	11	60C106	ORING 5/16ID 1/16CS BN 70 DURO #011	
Z	11	60C106V	O-RING 5/16"IDX1/16"CS VITON 11-011	
all	12	02 18651	73171A WASHER=2WAY BRAKECYL	
all	13	02 02185	79237A WASHER=PISTON CUP COMP LIMIT	
all	14	02 17023	83392B SPRING-SS=DUMP 1.50D8FL21#"	



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List, cont.—3 & 4 Inch Dump Valve Assembly

Used In	Item	Part Number	Description	Comments
All	15	02 16021I	94191# DUMPVAL STEM-4"+8" DYE 316L	
Y	16	X2 02743	87382B BONNET=2"DUMP VALVE	
Z	16	X2 02743S	73141B BONNET=2"DUMP VALVE-SS	
all	17A	15G168	SQNUT 1/4-20UNC2 SS18-8	
all	17B	24G020N	ROLLED WASHER .252"ID NYLTITE #25W	
all	17C	15K041S	HEXCAPSCR 1/4-20UNC2AX1 SS18-8	
all	17D	15U181	LOCKWASHER MEDIUM 1/4 SS18-8	
all	18	02 14447	92037B BONNET=4"S/S DUMP VALVE	
Y	19	02 18931F	93362B GASKET=DUMPVALVE-1/60+72WEHU	
Z	19	02 18932B	93362# GASKET=DUMPVAL 1/8"RED SILIC	
Y	20	02 16021E	94323B WASHER 3/8IDX1.250D DUMPVAL	
Z	20	02 18651A	83526B WASHER=DUMP VALVE DISC	
Y	21	02 16021C	92051B BUMPER=DUMP VALVE BONNET	
Y	21	02 16021D	92632B DUMP VALVE BUMPER RETAINER	
Z	21	02 16021S	84206B BUMPER=DUMP VAL BONT S/S	
all	22	02 14446	87503B DISC-4"S/S DUMP VALVE	
all	23	15U245	01Z FLTWASH 3/8 STD COMM 18-8 SS	
(P-V,X)	24	02 14443	93362B GASKET-4"S/S DUMP VAL BONNET	
W	24	02 14443E	91067B GASKET=DUMP/VENT VAL N-8090	
all	25A	15K086	HXCAPSCR 3/8-16NCX3/4 SS18-8	
all	25B	24G030N	ROLLED WASHER .379"ID NYLTITE #37W	
P-T	25C	15U200	FLATWASHER(USS STD) 5/16"ZNC PLT	
R	26	W2 14740	94261D*WLMT=DUMP VALVE 3621F8P	
S	26	W2 11304	89417T*DUMP VALVE BODY WELDMT 4226	
N,T	26	W2 15997	91383@* BODY=4"DUMPVALVE=4231WE+SG	
U	26	W2 14445S	80433@*DUMPVALVE WLMT=SCREWED 4"NPT	
V	26	W2 14445	91383Y* BODY=4"DUMPVALVE=36BWE+QTS	
W	26	W2 14445F	91383@*DUMP VALVE WLDMT 4226DYP	
X	26	W2 14445J	80433T*DUMPVALVE WLMT=SCREWED 3"NPT	
Q	26	W2 14740A	91446Y*WLDMT=DUMP VALVE 42S6P	
P	26	W2 11943	93071D*WLMT=DUMPVAL DRN TO REAR 36Q	
(Q-T)	27	5SP0KGFSS	NPT PLUG 1/2 SOSOLID GALSTL	
(U-X)	27	5SP0KSFHC	NPT PLUG 1/2 HEX 304SS 150#	
all	28	02 14166	77131A SEAT 4" DUMP VALVE BUNA-N	
all	29	96DB0PNA	01Z HOSE BIBB 3/4" MALE INLT CELCON	ONLY ON SOME MODELS

Section

9

**Pneumatic Piping and
Assemblies**


SERVICING AIR CYLINDERS

This is the general procedure for rebuilding an air cylinder using a Milnor[®] furnished repair kit, once the air cylinder has been removed from the machine. See the specific air cylinder and major assembly parts drawing(s) for component identification and removal/replacement information.

Maintenance procedures require:

- Two threaded rods and nuts, twice the length of the tie bolts.
- The appropriate repair kit.

▲ CAUTION ▲



EXPLOSION HAZARD—Spring tension can cause air cylinder to burst apart with great force during disassembly. You can be struck by air cylinder parts.

☞ **Follow maintenance instructions carefully.**

☞ **Wear eye protection.**

NOTE: Use a new locknut when re-assembling air cylinder (see the appropriate parts drawing).

1. Replace two diagonally opposite tie bolts with threaded rods and nuts as shown in FIGURE 1.
2. Tighten nuts on the threaded rods until they contact the air cylinder.
3. Remove the other two tie bolts and the nuts, washers, clips, and actuators from the external end of piston stem.




FIGURE 1 (MSSM0130AE)
Using Threaded Rods

- Loosen nuts on threaded rods evenly, permitting cylinder heads to separate. Use only a few turns on one nut before moving to the other one. Continue until springs have no tension.




FIGURE 2 (MSSM0130AE)
Correct Piston Cup Shape




FIGURE 3 (MSSM0130AE)
Distorted Piston Cup Shape

- Note position and orientation of piston cup(s), washers, and springs. Replace worn parts, then reassemble in reverse order. Tighten locknut until it is just barely possible to turn the piston cup and washer assembly on the stem. Correct piston cup shape is shown in FIGURE 2. **DO NOT** overtighten, as this causes the piston cup to deform to the shape shown in FIGURE 3 and may cause piston to bind in cylinder.

3-Way Pilot Valves

BMP900032/91182V
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP900032/91182V (1 of 1)


Litho in U.S.A.

(VALVES SHOWN DE-ENERGIZED)

Parts List—3-Way Pilot Valves

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			ASSEMBLIES	
			none	
			COMPONENTS	
all	1	96R301A37	05Z 1/8" AIRPILOT 3W NC 120V/50/60	
all	1	96R301A24	06Z 1/8" AIRPILOT 3W NC 24V/50/60	
all	3	96R302A37	06Z 1/8" AIRPILOT 3W NO 120V/50/60	
all	3	96R302A24	07Z 1/8" AIRPILOT 3W NO 24V/50/60	



NORMALLY
CLOSED

NORMALLY
OPEN

FOR REPAIR OR REPLACEMENT PARTS FOR PILOT VALVES
USED ON WASHER EXTRACTORS GENERALLY PRIOR TO
JUNE 1, 1985, SEE BMP701359.

Asco 3-way Solenoid Valves

Applicable Models




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP701359/97086V (1 of 2)

Litho in U.S.A.

BMP701359/97086V
(Sheet 1 of 2)



FLOW DIAGRAMS:

ENERGIZED	DE-ENERGIZED	VALVE
		NORMALLY CLOSED
		NORMALLY OPEN

OPERATION

NORMALLY CLOSED VALVE – OPEN WHEN ENERGIZED
CLOSED WHEN DE-ENERGIZED

NORMALLY OPEN VALVE – CLOSED WHEN ENERGIZED
OPEN WHEN DE-ENERGIZED

COMPONENTS LABELED (*) ARE CONTAINED IN KIT "00Q", SEE PARTS LIST FOR OTHER AVAILABLE KITS.

Identification and Description

Check nameplate for correct catalog number, pressure, voltage, and service.

Safety Instructions



⚠ DANGER ⚠

SHOCK HAZARD - will cause death or severe injury.

☞ Lock OFF - and tag out power at wall disconnect before servicing. Power switches on machine and control box disable only control circuit power in electrical boxes.



⚠ WARNING ⚠

EXPLOSION HAZARD- may cause serious injury.

☞ Release pressure to valve before disassembly.



⚠ CAUTION ⚠

BURN HAZARD - Solenoid enclosures become too hot to touch when energized for a long period. This will not damage the solenoid, but may cause a painful burn.

☞ Allow solenoids to cool before servicing the valves.

Cleaning - Clean all solenoid valves periodically. If the voltage to coil is correct, sluggish valve operation usually indicates that cleaning is required.

Maintenance

READ ALL SAFETY STATEMENTS ABOVE BEFORE PROCEEDING ANY FURTHER!

Coil Replacement

1. Remove retaining clip. NOTE: When metal retaining clip disengages, it springs upwards.
2. Slip yoke containing coil and sleeves off solenoid base sub-assembly.
3. Replace coil.
4. Reassemble in reverse order.

Valve Disassembly and Reassembly

1. Remove retaining clip.
2. Slip entire solenoid enclosure off the solenoid base sub-assembly.
3. Remove solenoid base sub-assembly, core assembly and core spring.
4. Remove diaphragm spring, diaphragm assembly and gasket.
5. Replace all worn or damaged parts
- 6.

Troubleshooting

Control Circuit: Listen for a metallic click when energizing the solenoid. Absence of the click indicates loss of power to the solenoid. Check for loose connections, blown fuses, open or grounded coil circuit, and broken lead wires.

Faulty Coil: Check for open circuit in coil. Replace coil if necessary.

Low Voltage: Voltage across coil leads must be at least 85% of nameplate rating for proper operation.

Incorrect pressure: Pressure to valve must be within range specified on nameplate.

Excessive leakage: Disassemble valve and clean all parts. Replace all worn parts for best results.



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP701359/97086V (2 of 2)

Litho in U.S.A.

BMP701359/97086V
(Sheet 2 of 2)

		Parts List—Asco 3-way Solenoid Valves		
Used In	Item	Part Number	Description	Comments
<p>Parts List—Asco 3-way Solenoid Valves Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.</p>				
			-----ASSEMBLIES-----	
	A	96TAC3AA24	04Z 1/8" N/C 3WAY 24V50/60C VALVE	COMPLETE VALVE ASSEMBLY
	B	96TAC3AA37	04Z 1/8" N/C 3WAY 120V50/60C VALVE	COMPLETE VALVE ASSEMBLY
	C	96TAC3AA71	04Z 1/8" N/C 3WAY 240V50/60C VALVE	COMPLETE VALVE ASSEMBLY
	G	96TBC3BA24	04Z 1/4" N/C 3WAY 24V50/60C VALVE	COMPLETE VALVE ASSEMBLY
	J	96R300AAM	78183L*NC VALVEBODY+HARDWARE	VALVE BODY+HARDWARE 00A,00B,00C
	Q	96V304A	PARTKIT 8320 1/8" ASCO#K260767	VALVE REPAIR KIT ALL SEE PARTS WITH (*) FRONT
	R	96V236B	PARTKIT 8320 1/4 ASCO#K302142P	00G
-----COMPONENTS-----				
J	1	96V300	1/8" VALVEBODY ASCO #UX8320B13	
all	1	96R300AB	73111F 1/8"BODY-3WAY.06D NORM OPEN	00K
A,	2	96T1002A24	SOLENOID 24V ASCO#260283-005	00D
B,	2	96T1003A37	COIL 120V50/60C ASCO#162-919-1	00E
C,	2	96T1003A71	COIL 120V50/60C ASCO#162-919-2	00F
all	2	96T1003A24	COIL 24V50/60C ASCO *162-919-3	
all valves	3	96V300GB	SLEEVE ASCO#101400-1	00P
+ kits J-				
all	4	15UJ275	SPRINGWASHER 7/16" GAR#3W-325 ZINC	
all valves except G	4	96V1002WSH	STARWASHER MXX ASCO#238589-1	
all valves except G	5	96V300GA	YOKE ASCO#78-345-1	
all valves except G	6	96V300F	METAL CLIP ASCO #92-059-1	
G	6	96V1002CLP	METAL CLIP MXX ASCO#176-993-1	
G	7	96V1002PLT	NAMEPLTE,BLK MXX ASCO#258775-1	
all	8	96V300L	SPRING-DISC N/O ASCO#90-083	00K






Quick Exhaust Valves

BMP701406/2002382V
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.





Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Quick Exhaust Valves

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	MESSAGE B2	REPAIR KITS ONLY <>	DELTROL
	B	96M051	USE KZK5B00100	WABCO
	C	96M054	QWIKEXHAUSTVLV 3/4"URETHANE	PARKER
	D	MESSAGE B1	PARTS NO LONGER SOLD	ASCO
	E	MESSAGE B2	REPAIR KITS ONLY <>	GOYEN
	F	96M055	QUICK EXHAUST VALVE 1/4"	DELTROL
-----COMPONENTS-----				
all	1	96M053A	KIT,QWIKRELVLV EV20A#10091-18	DELTROL VALVE ONLY
all	3	96M051B	DIAPHRAM,QWIKREL WAB#PS112-12	WABCO VALVE ONLY
all	4	96M051A	GASKET,WABCO QUICK EXHAUST VLV	WABCO VALVE ONLY
all	5A	96M052A	REPKIT,QES#M1319 (FOR 96M052)	GOYEN VALVE ONLY
all	5B	96M055A	REPAIR KIT FOR 96M055# 10128-99	DELTROL VALVE ONLY
all	6	96M054K	REPKIT 3/4"QWIKEXHAUSTVLV	PARKER VALVE ONLY



Air Cylinder Assemblies

BMP830078/2005525B
(Sheet 1 of 3)




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.








A WARNING



EXPLOSION HAZARD - Air cylinder can burst apart with great force.
Circled items are under high spring tension.
Follow maintenance instructions MSSM0130AE carefully.

AIR CYLINDER MOUNTING HARDWARE





Parts List—Air Cylinder Assemblies				Parts List, cont.—Air Cylinder Assemblies					
Used In	Item	Part Number	Description	Comments	Used In	Item	Part Number	Description	Comments
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.									
ASSEMBLIES									
A		SA 36 035	89483V* AIRCYL=BRAKE ASSY	72WP2,WP3,WE3		8	02 02185	79237A WASHER=PISTON CUP COMP LIMIT	
B		SA 28 128	89483T* BRAKE AIRCYL 2-WAY 60+72SGU	60+72SP2,SP3		9	02 18651	73171A WASHER=2WAY BRAKECYL	
C		SA 28 152	89483V* BRAKE AIRCYL 2-WAY 60WE2+3	60WP2,WP3,D3A,DA3		10	03 01313	70219A STOP=AIR CYL W/2+11/16STROKE	
D		SA 10 019A	89483U* BRAKE AIRCYL,2-WAY=42WE+DAU	4231/4244 WP2/WP3		11	02 15880	96471B SPRING=BRAKE1.5OD10.3FL17#"	
F		A52 00200	89463U* BRAKE AIRCYL=7244 TILT ONLY	CP2/CP3 NP2/NP3					
G		SA 10 019Q	89483T*BRAKE CYL ASSY=4226QWE+DYA	SP2/SP3					
H		AAC14001A	90000Z AIRCYL-LONG= 4256PFG	72DA1/L/N,DBN,					
I		A76AC001A	89463T AIR CYL.2-3/8 BORE 2"STROKE	WTL/N,WP1					
J		A76AC001B	89463@ AIR CYL.2-3/8 BORE 3"STROKE	4226DP1,DA1,DYPD5P					
K		A75 01200	89463T*AIR CYL. DAMPER = 3"STROKE	3621+26Q6X 4226Q4X,Q6X					
L		A75 01300	89463U*AIR CYL. DAMPER = 2"STROKE	5840TG2,TS1,TT1					
M		SA 10 019	89497U* BRAKE AIRCYL=BALCOM+DIVCYL	5858+80TG1/2,TS1,TT1					
N		AAC14001	90041U*AIRCYL=RATE 50-91 STRK 2.09	3621F8P					
P		A25 00600	89457V* BRAKE AIRCYL=52WE1 +52TILT	52LWN/H,WTL/N,WP/E1,DYA					
Q		AAC64001	894613*AIRCYL=BRAKE ASSY 6442	64BTL,BTN,BHP,					
R		AAC65001	93481B AIRCYL=BRAKE ASSY 6446E6N	DA1,DAL,DAN					
S		AAC58001	95000Z AIRCYL=BRAKE ASSY 7258J2N	6446,7246,7258,M7E					
COMPONENTS									
A-D	1	W2 18646	93344L CYLINDER-AIR=DOUBLEACT BRAKE	4244SP2 SM					
F-S	1	02 02068	94266A AIRCYL-STAINLESS=DUMPPALVE	7258J2N					
A-D,F-G,S, I-K,M-Q	2	02 18650	96431B STEM=2 WAY AIRCYLINDER BRAKE						
H	2	03 06313A	96431# STEM=AIR CYL 304SS						
L	2	02 18650A	96417B STEM-AIRCYL UPLOCK PRESS						
R	2	02 18650B	97362B STEM=2WAY AIRCYL BRAKE 7.88L						
A-D	3	02 18660	CYLHEAD-BRASS=2WAY AIRCYL						
F-Q	3	02 02546	CYLHEAD=SLIDESTEM						
R	3	06 20702E	91227B FLOW NOT ACTUATOR CYL HEAD						
S	4	02 02101	71334A CYLHEAD W/TAPPED HOLE						
ALL	5	02 02105	91522A PISTON CUP WASHER STNLS STL						
S	5	02 02105B	92253B 2.38"ACYL BRASS PISCUP WASHR						
ALL	6	02 02194	93217B PISTONCUP=DUMPPALVE 2+3/8"						
ALL	7	02 02085	75161A UP WASHER=2"OD=PISTONCUP						

Used In	Item	Part Number	Description	Comments
ALL	8	02 02185	79237A WASHER=PISTON CUP COMP LIMIT	
A-D,F-Q,S	9	02 18651	73171A WASHER=2WAY BRAKECYL	
A-D,F-Q,S	10	03 01313	70219A STOP=AIR CYL W/2+11/16STROKE	
A-C,F-L,P-Q S	11	02 15880	96471B SPRING=BRAKE1.5OD10.3FL17#"	
A,D,F-M,Q,S	12	02 15881	96471# SPRING=BRAKE2.1OD11FL15.5#"	
N	13	02 17023	83392B SPRING-SS=DUMP 1.5OD8FL21#"	
ALL	14	60C132	ORING 2"IDX3/16CS BUNA70 #329	
A-D	15	60C110	ORING 1/2IDX3/32CS BUNA70 #112	
ALL	16	60C106	ORING 5/16ID 1/16CS BUNA70#011	
D,G-J,L-N Q,S	17	27B240	SPCRROLL.5ID.813L.062T STLZNC	
A,C-D,F-Q,L S	18	27B250	SPCRROLL.5ID1.5L.062T STLZNC	
S	19	02 10585E	91142# TIE BOLT=5/16-18X8.25LG PLTD	
ALL	19	02 10585E	91142# TIE BOLT=5/16-18X8.25LG PLTD	
R ONLY	19	W6 20702F	90293B*FLOW NOT VLV=AIR-CYL ROD WLD	
ALL	20	15U200	FLATWASHER(USS STD) 5/16"ZNC PLT	
ALL	21	15U210	LOKWASHER MEDIUM 5/16 ZINCPL	
F-Q	22	15G185	HXNUT 5/16-18UNC2B SAE ZINC GR2	
ALL	23	15G220	02Z LTHX THIN LOKNUT 3/8-24 SSNTE	
A,C,F-G,I-J L,Q,S	24	15U243	FLAWASHER 7/8ODX33/64IDX16GA ZINCPL	
F-N	25	15U520	FLAT WASHER 2+3/8X1+4/164X12GA ZINC	
F-Q,S	26	54E220	NYLNR 8L2FF BUSH 1/2X9/16X.140	
F,K,I-J,Q,S	27	17B012	EXTRETRING IND#1000-50-ST-ZD ZINC	
A	28	20L601R	ID TAG NAT'L #1614 ALUM EMB LET "R"	
B	28	20L601U	ID TAG NAT'L #1614 ALUM EMB LET "U"	
C	28	20L601P	ID TAG NAT'L #1614 ALUM EMB LET "P"	
D	28	20L601X	ID TAG NAT'L #1614 ALUM EMB LET "X"	
S	28	20L601J	ID TAG NAT'L #1614 ALUM EMB LET "J"	
F,H,Q,S	28	20L601A	ID TAG NAT'L #1614 ALUM EMB LET "A"	
G	28	20L601Q	ID TAG NAT'L #1614 ALUM EMB LET "Q"	
M	28	20L601F	ID TAG NAT'L #1614 ALUM EMB LET "F"	
N	28	20L601D	ID TAG NAT'L #1614 ALUM EMB LET "D"	
P	28	20L601V	ID TAG NAT'L #1614 ALUM EMB LET "V"	
K	28	20L601V	ID TAG NAT'L #1614 ALUM EMB LET "V"	
I-J,L	28	20L601E	ID TAG NAT'L #1614 ALUM EMB LET "E"	
F,I-L	29	20L601A	ID TAG NAT'L #1614 ALUM EMB LET "A"	
G-H	29	20L601F	ID TAG NAT'L #1614 ALUM EMB LET "F"	



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List, cont.—Air Cylinder Assemblies

Used In	Item	Part Number	Description	Comments
N	29	20L601C	ID TAG NAT'L #1614 ALUM EMB LET "C"	
Q	29	20L601D	ID TAG NAT'L #1614 ALUM EMB LET "D"	
ALL	30	03 06309	70310C RIGHTMOUNT=BRAKE CYL ZNC	RIGHT
ALL	31	03 06308	70310C LEFTMOUNT=BRAKE CYL ZINC	LEFT
ALL	32	02 02550	97437ABRKT=AIRCYL-RIGHT ZINC/CAD	RIGHT
ALL	33	02 02547	LT BRACKET=AIRCYL CAD	LEFT
ALL	34	02 02556	SUPPORT=AIRCYL CADSTL	
ALL	35	27B2750LOT	01Z SPC RROLL.562ID.937L.048T ZNK	
ALL	36	15K206	HEXCAPSCR M5-.8X40MM 18-8SS	
ALL	37	15G235F	HXFNJAMNUT 9/16-12UNC2B ZINC GR2	
ALL	38	15U280	01Z FL+WASHER(USS STD)1/2 ZNC PL+D	
ALL	39	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
ALL	40	17A020	ADJ CLEVIS MACHINED 1/2-13 ZINC PLT	
ALL	41	17A065	01Z EYEEND 1/2-13 X2.25 ZINC	
ALL	42	17A040	CLEVISPIN 1/2"X1+3/8" DRILLED	
ALL	43	15H030	STDCOTTERPIN 3/32X3/4 ZINCPL	
ALL	44	27B34010SZ	SPCRROLL.512ID.625L.062T STLZC	
ALL	45	02 17024	94302B SPRING-SS=DUMP 1.5OD4FL40#"	




AIR VALVES & MOUNTING HARDWARE

BMP780087
83457B


DETAIL A

00AA
00AB




DETAIL B

00BA
00BB
00BC



DETAIL C

00CA
00CB
00CC




DETAIL D

00DA



DETAIL E

00EA
00EB
00EC
00ED
00EE
00EF



Air Valves & Mounting Hardware

BMP780087R/83457A
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Air Valves & Mounting Hardware

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	AA	AVA030537	78173S ONE 1/8 AIRVALVE REG.AIR120V	
	AB	AVA030571	84386S ONE 1/8 AIRVALVE REG.AIR240V	
	BA	AVA030324	79066S1/4"NC24V ASCO AIRVAL+MTG HWD	
	BB	AVA030337	79066S1/4"NC120VASCO AIRVAL+MTG HWD	
	BC	AVA030371	79066S1/4"NC240VASCO AIRVAL+MTG HWD	
	CA	AVA030224	78173S1/8"NC24V ASCO AIRVAL+MTG HWD	
	CB	AVA030237	84386S1/8"NC120VASCO AIRVAL+MTG HWD	
	CC	AVA030271	84386S1/8"NC240VASCO AIRVAL+MTG HWD	
	DA	AVA0304	78136# TWO PLUGS+MTG HWD	
	EA	AVA030124	78173S TWO 1/8"AIRVALVE+MTG HWD 24V	
	EB	AVA030124A	78182S TWO 1/8AIRVAL+MTG HWD 1-NO	
	EC	AVA030137	82183S TWO 1/8 AIRVALVE+MTG HWD120V	
	ED	AVA030137A	78182S TWO 1/8AIRVAL+MTG HWD 1-NO	
	EE	AVA030171	78173S TWO 1/8"AIRVALVE+MTG HWD240V	
	EF	AVA030171A	78182S TWO 1/8AIRVAL+MTG HWD 1-NO	
-----COMPONENTS-----				
	all	1	03 01524	79177B CHANNEL=PLUG HOLDER
	all	2	03 01509	77362A PLUG=MANIFOLD PORTS
	all	3	60C105	ORING 1/4 ID 1/16CS BN 70 DURO #010
	all	4	15P105	05Z TRDCUT-F PANHD 8-32X5/8 NIKSTL
	AA,CB,EC, ED	5	96T1001A37	SOLENOID 120V50/60C ASCO#260283-002
	AB,CC,EE, EF	5	96R300B02	COIL 220/50SFT-240/60SFT#162-919-26
	EA,EB,CA	5	96T1001A24	SOLENOID 24V50/60C ASCO#260283-001
	all	6	03 01182B	78036B ANGLE=SUPPORT AIR VALVE
	all	7	03 01538	86053B CHANNEL=OIL SHIELD-1/8AIRVAL
	all	8	15P101	04Z TRDCUT-F PANHD 8-32X3/8 NIKSTL
	all	9	15U120	LOCKWASHER MEDIUM #8 ZINCPL
	all	10	53A031B	BODY-MAL90ELL1/4X1/8COMP#269C-42B
	AB only	11	53A032	MAL90ELL 5/16X1/8POLYFLO #169P-5-2
	all	12	96R300AAM	78183L*NC VALVEBODY+HARDWARE
	BA only	13	96T1002A24	SOLENOID 24V50/60C ASCO#260283-005
	BB only	13	96T1002A37	SOLENOID 120V50/60C ASCO#260283-006
	BC only	13	96T1002A71	SOLENOID 240V50/60C ASCO#260283-007
	all	14	53A031XB	BODY=MAL90EL 1/4X1/4COMP #269C-4-4B



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.


Parts List, cont.—Air Valves & Mounting Hardware

Used In	Item	Part Number	Description	Comments
all	15	96V350	1/4" VALVEBODY ASCO #UFTX8320A89	
all	16	03 01523	85096C BRKT=LOCK AIR VALVE	
all	17	53A005B	BODY=MALECONN 1/4X1/8COMP #B68A-4A	
all	18	53A059	SLEEVE 1/4" COMP IMP #60F BRASS	
all	19	53A059A	NUT 1/4"COMP.HOLYOKE ANDERSON#61A-4	
EB,EC,EF	20	96R300ABM	78183@*NO VALVEBODY+HARDWARE	
all	21	03 01508	77362A FITTING-SCREW 7/16 HEX	



UNIVERSAL AIRVALVE BOX ASSEMBLY

BMP780088
83457C













A B C D E →

← **V W X Y Z**

DETAILS A-E SHOW SOME POSSIBLE CONFIGURATIONS ON THIS END OF THE AIRVALVE BOX.

DETAILS V-Z SHOW SOME POSSIBLE CONFIGURATIONS ON THIS END OF THE AIRVALVE BOX.



P/L UNIVERSAL AIRVALVE BOX

BMP780088R/93046N
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—P/L UNIVERSAL AIRVALVE BOX

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
none				
-----COMPONENTS-----				
	1	03 01180A	84232D ENCL=AIR VALVE FORMED	
all	2	03 01180B	84136B PLATE=BOTTOM AIRVALVE BOX	
all	3	17C051	01Z RECP BKT #2 FAST CAMLOCK	
all	4	15J051	01Z POPRIVET 1/8DIAX.265 LONG S/S	
all	5	51P013	PLUG HXCNTRSUNK 1/4"BRASS	
all	6	12P1AHSB	SNAPBUSH.437MHX.312 T=1/8HEYCO#2043	
all	7	X3 01507A	88462# MANIFOLD BLOCK MACH 12PORTS	
all	8	5N0E11ABE2	NPT NIPPLE 1/4X11 TBE BRASS 125#	
all	9	51E507	HOSESTEM BRASS 1/4 MPTX1/2 HOSE I.D	
all	10	51V015	03Z TEE PIPE 1/4"FGDBRASS101-T7-444	52DRA+DYA ONLY
all	10	5SX0EBF	NPT CROSS 1/4" BRASS 150# 2205P-4	52WE1;60;72;WE2+WE3
all	11	5N0E05KB42	NPT NIPPLE 1/4X5.5 TBE BRASS STD	
all	12	51T020	STRAINER-T 1/4"ANCHOR #101ST-4	
all	13	60E004TE	04Z 1/4"OD X.170"ID NYLON TUBING *	
all	14	53A008B	BODY=BRMALCON 1/4X1/4COMP W#B68X4X4	52DRA+DYA ONLY
all	14	53A031XB	BODY=MAL90EL 1/4X1/4COMP #269C-4-4B	52WE1;60;72;WE2+WE3
all	15	5SB0E0CBEO	HEXPIPBUSH 1/4 X 1/8 BRASS 125#	
all	16	30N100	07Z PRESSGUAGE 1/8"BACKCONN 0-30PSI	60;72;WE3 ONLY
all	16	30N101	08Z PRESSGAUGE 1/8"BACKCONN O-60PSI	60;72;WE2 ONLY
all	17	96J019BE	78486T*PRESSURE REG=EPOXY SET 28PSI	
all	18	5N0ECLSBE2	NPT NIPPLE 1/4XCLS TBE BRASS 125#	
all	19	15U185	FLATWASHER(USS STD) 1/4" ZNC PLT	
all	20	02 10456	65025A BUSHING=SENSDEV PIVOTPIN	
all	21	12K005	01Z 1/2 CONDUIT NIPL-CHASE"LONG TYP	
all	22	5N0E02ABE2	NPT NIPPLE 1/4X2TBE BRASS 125#	
all	23	5SLOCBEC	NPT ELBOW 90DEG STRT 1/8"BRASS 125#	



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List, cont.—P/L UNIVERSAL AIRVALVE BOX

Used In	Item	Part Number	Description	Comments
all	24	96J019E	1/4"PRESSREG2-50PSI #R07-200-RNEA	
all	25	30N095	03Z PRESSGAUGE 1/8"BACKCONN 0-15PS1	
all	26	5N0E03KBE2	NPT NIPPLE 1/4X3.5 TBE BRASS 125#	
all	27	5S0EBEA0G	NPT TEE 1/4X1/4X3/8 BRASS 125#	
all	28	5SL0EBEC	NPT ELBOW 90DEG STRT 1/4" BRASS 125	
all	29	27A090	HOSECLAMP,11/16-1.5" CADSCR HS-16	
all	30	60E085	07Z H0SE WATER 1/2" DAY 7192-50250*	
all	31	5SB0G0EDE0	NPTHEXBUSH 3/8X1/4 GALCI 125#	
all	31	5SL0EBEA	NPT ELBOW 90DEG 1/4" BRASS 125#	(USED ON 52 DRA ONLY)
all	32	12K070	1/2" CONDUIT LOCKNUT PECO #201J	
all	33	96TCC3AA71	04Z 3/8" N/C 3WAY 240V50/60C VALVE	
all	34	27A005	MUFFLER 3/8" ALLIED #B38 "BANTAM"	
all	35	15K039	HXCAPSCR 1/4-20UNC2AX3/4 GR5 ZNC/CD	
all	36	15U180	LOCKWASHER MEDIUM 1/4 ZINCPL	
all	37	5N0E07AB42	NPT NIPPLE 1/4X7 TBE BRASS STD	

Burket Steam Valve




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP800020/96066V (1 of 1)

Litho in U.S.A.

BMP800020/96066V
(Sheet 1 of 1)



Parts List—Burket Steam Valve
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
	W	96D0009ER1	02Z REPAIRKIT 3/4" STEAM VALVE	KIT FOR 001A
	X	96D0011ER1	02Z REPAIR KIT 1.25" STEAM VALVE	KIT FOR 001B
	Y	96D0011ER2	ACTUATOR HOUSING FOR BURKET #251	KIT FOR 001B
	Z	96D0011ER3	REPAIR KIT MULLER 1.25 VALVE #554	KIT FOR 001B
			-----COMPONENTS-----	
all	1	96D0009E	03Z 3/4"NPT N/C STEAMVAL ANGLE BODY	3/4"
all	1	96D0011E	08Z 1/25"NPT N/C STEAMVAL ANGLEBODY	1-1/4"
all	2	96H018	NEEDLE VALVE	
all	3	51T030	01Z Y-STRAINER 3/4" CAST IRON	USED WITH 001A
all	3	51T060	01Z Y-STRAINER 1+1/4" CAST IRON	USED WITH 001B

Section


10

**Hydraulic Schematics
and Devices**



**HYDROCUSHION CYLINDER ASSEMBLY
W/BYPASS 4226, 4832, 4836, 4840**

**BMP890047
94476C**





PARTS LIST

(See other page for drawing.)

HYDROCUSHION CYLINDER ASSEMBLY WITH BYPASS

BMP890047R/97266V (Page 2)

ITEM	PART NUMBER	DESCRIPTION	HOW PART IS USED IN ASSEMBLY (Only if pertinent)	ITEM	PART NUMBER	DESCRIPTION	HOW PART IS USED IN ASSEMBLY (Only if pertinent)
00U	GHC11001A	89336@ HYDROCUSH CYL INST W/BYP 42U	REFERENCE ONLY	033	15K203	HXTAPSCR 1/2-13UNC2AX5 GR5 ZINC	
00V	GHC48001A	89336Y HYDROCUSH CYL INST W/BYP 48U	REFERENCE ONLY	034	15N037	HXCAPSCR 1/2-13UNC2AX6.5 GR5 ZNC/CD	
00W	AHC11002L	874461*LF HYDCSHNCYLASY W/BYP210#1"	4226	035	27B250	SPACER ROLL.5ID1.5L.062T STL/ZNC	
00X	AHC11002R	87446J*RT HYDCSHNCYLASY W/BYP210#1"	4226	036	15G231	HXFJNJAMNUT 1/2-13UNC2B ZINC GR2	
00Y	AHC48002L	87446J*LF HYDCSHNCYLASY W/BYP350#1"	4832,4836+4840	037	02 18571A	90063A PISTON ROD WASHER-.25"TK	
00Z	AHC48002R	87446J*RT HYDCSHNCYLASY W/BYP350#1"	4832,4836+4840	038	02 18534	HOLDPLATE=BALLBUSH CAD	
001A	W3 48065L	90452C*LFT HYDCUSHCYL W/DMT 4"W/BYP	(00W,00Y)	039	X3 06252	87387B RETAINER - BALBUSH = 4/72 WEDU	
001B	W3 48065R	90452C*RT HYDCUSH CYL W/DMT 4"W/BYP	(00X,00Z)	040	02 18256	LOKWASH-TONGUE 8WEH-CAD	
002	X3 48069	86043T PISTON=HYDRO CUSHION CYL 4"	(00W,00X)	041A	02 18795A	92641B WASH-TIMING=HYDRO CYL 45DEG	
003A	03 48070	85127B SPRING=3+5/EOD 210#/IN	(00Y,00Z)	041B	02 18795B	92641# WASH-TIMING=HYDRO CYL 75DEG	
003B	03 48070A	82426B SPRING=3+5/8 O.D. 350 #/IN		042	15G268	HXFJNJAMNUT 1+1/2-12UNF2B ZINC GR2	
004	02 175034	70148B SHIELD-BALLBUSH-4/HYDRO MACH		043	54M025	HYDRAULICFIT 1/8"-90 ALEMITE#1613-B	
005	02 02230	85482A6 WATER BARRIER (NEOPRENE)		044	54A705	05Z BUSH-BALL 1.5 RBC# B24L BUSH #1	
006	60C145	ORING 3+1/2ID 3/16CS BN70 DURO #341				***** END OF PARTS LIST *****	
007	03 48068	85301B BUSHING=PISTON ROD 4"CYL					
008	15K227	HXCAPSCR 5/8-11UNC2AX4 GR5 ZINC/CAD					
009	15U315	LOKWASHER MEDIUM 5/8 ZINCPL					
010	03 48071	85403C CAP=UPPER CYL END 4"HYDCUSH					
011	15G236	SQ Nut 5/8-11UNC2B SAE ZINC GR2					
012	02 18243	89091# BOLT=HYDCYL 22+1/8LG+KEYWAY					
013	03 48072	82166B RETAINER=4"HYDROCUSHION SEAL					
014	24S040	03Z SEAL URETHANE 1-7/16 2.25 13/32					
015	5SP0KDEHK	NPT PLUG 1/2 HXCTRSNK GALSTL					
016	X2 11477	92297B CAP1.25NPT HYDCYL BYPASSVLVE					
017	15A010	67346A CARRSCR 3/8-16UNC2X1 SPECIAL					
018	96H020	NEEDLEVAL 5/16X1/8-90					
019	X2 11473	92096B PISTON-HYDCYL BYPASS VALVE					
020	15G219NTE	HXTHINLOKNUT 3/8-24NF NYL STL/ZNC					
021	53A031B	BODY-MAL90ELL1/4X1/8COMPPH#269C-42B					
022	X2 11476	94191B PISTON ROD HYDCYL BYPASSVLVE					
023	02 11472	87402B COMPRESSION LMTG WSHR-BRASS					
024	02 11475	87446B FLAT MACHWSHR-PISTONCUP					
025	02 11479	87431B PISTCUP 1.25X.5HOLE URETHANE					
026	02 11471	90327BMACHWSHR1.07ODX.385ID CHMFRD					
027	60C106	ORING 5/16ID 1/16CS BN 70 DURO #011					
028	02 11480	87506B SPRING HYDROCUSHION BYPASS ASSY					
029	5SCA1ENF	NPT CAP 1.25 GALMAL 150#					
030	15K191	HXCAPSCR 1/2-13UNC2AX2.5 GR5 ZNC/CD					
031	15U300	LOKWASHER REGULAR 1/2 ZINC PLT					
032	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2					

How to Read Parts List

Reference Item Numbers—Items 00A, 00B, 00C, etc., or 00X, 00Y, 00Z, etc., appearing at the top of some parts lists, are for reference and provide:


1. The part number for the entire assembly depicted in the drawing or a major sub-assembly thereof, and/or
 2. The range of machine models this drawing applies to.
- If more than one reference item appears, this usually means this drawing applies to more than one assembly (and thus to more than one range of machines).

Component Item Numbers—For any item on the drawing (e.g., item ①), there may be several corresponding items on the parts list (e.g., 001A, 001B, 001C, etc.) which are similar components on different assemblies. "How Part Is Used In Assembly" identifies which components apply to your machine, by listing either the machine model, or the reference item number from the top of the parts list (e.g., 00A, 00B, 00C, etc.), or a particular characteristic (e.g., bronze or stainless steel), or special ordering information, such as a repair kit number.



HYDROCUSHION CYLINDER ASSEMBLY
4226QHE, 4832BHE, 4836QHE

BMP820068
94476C



Hydrocushion Cylinder Assembly

4226QHE, 4832BHE, 4836QHE

BMP820068R/97266V
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Hydrocushion Cylinder Assembly


Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	Y	AHC11002	85207D*HYDROCUSH CYLASSY 210#/IN #1	4226
	Z	AHC48002	85207#*HYDROCUSH CYLASSY 350#/IN #2	4832,4836+4840
-----COMPONENTS-----				
all	1	W3 48065	90452C*HYDROCUSHION WLMT 4" DIA	
all	2	X3 48069	86043T PISTON=HYDRO CUSHION CYL 4"	
Y	3	03 48070	85127B SPRING=3+5/EOD 210#/IN	
Z	3	03 48070	85127B SPRING=3+5/EOD 210#/IN	
all	4	02 175034	70148B SHIELD-BALLBUSH-4/HYDRO MACH	
all	5	02 02230	85482A6 WATER BARRIER (NEOPRENE)	
all	6	60C145	ORING 3+1/2ID 3/16CS BN70 DURO #341	
all	7	03 48068	85301B BUSHING=PISTON ROD 4"CYL	
all	8	15K227	HXCAPSCR 5/8-11UNC2AX4 GR5 ZINC/CAD	
all	9	15U315	LOKWASHER MEDIUM 5/8 ZINCPL	
all	10	03 48071	85403C CAP=UPPER CYL END 4"HYDCUSH	
all	11	15G236	SQNUT 5/8-11UNC2B SAE ZINC GR2	
all	12	02 18243	89091# BOLT=HYDCYL 22+1/8LG+KEYWAY	
all	13	03 48072	82166B RETAINER=4"HYDROCUSHION SEAL	
all	14	24S040	03Z SEAL URETHANE 1-7/16 2.25 13/32	
all	15	5SP0KDEHK	NPT PLUG 1/2 HXCTRSNK GALSTL	
all	16	15A010	67346A CARRSCR 3/8-16UNC2X1 SPECIAL	
all	17	15G268	HXFINJAMNUT 1+1/2-12UNF2B ZINC GR2	
all	18	02 18256	LOKWASH-TONGUE 8/WEH-CAD	
all	19	X3 06252	87387B RETAINER - BALBUSH=4/72 WEDU	
all	20	54A705	06Z BALLBUSH 1.5 SKF#GEZ108ESAVE467	
all	21	02 18571A	90063A PISTON ROD WASHER-.25"TK	
all	22	54M025	HYDRAULICFIT 1/8"-90 ALEMITE#1613-B	
all	23	02 18534	HOLDPLATE=BALLBUSH CAD	
all	24	02 18795A	92641B WASH-TIMING=HYDRO CYL 45DEG	
all	24	02 18795B	92641# WASH-TIMING=HYDRO CYL 75DEG	
all	25	96H020	NEEDLEVAL 5/16X1/8-90	



4226QTH, 4832BTH, 4836QTH HYDRAULIC ASSEMBLY

BMP840023
84186D



BMP840023

Hydraulic Assembly

4226QTH, 4832BTH, 4836QTH

BMP840023R/85106A
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Hydraulic Assembly

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
none				
-----COMPONENTS-----				
all	1	52XY0GR010	ADUNION EL-90 EXT.SWIVEL PH2107-6-6	
all	2	52XY0GR003	ADAPTUNION 1/4MX3/8F.SWIV. STEEL	
all	3	52JY0GR005	ELBOWPIPE 3/8 STREET STL. A5502-6	
all	4	52LY0ER001	HEX PIPE NIPPLE 1/4"M X 1/4"M STEEL	
all	5	52VY0GR005	TEE PIPE 3/8 FEM.STEEL AIR#5605-6	
all	6	52JY0ER005	ELBOWPIPE 1/4 STREET AIRWY#5502-4	
all	7	52AY0GR004	HEXPIPEBUSH 3/8MX1/4F UNITED912X6X4	
all	8	5N0E03AS82	NPT NIPPLE 1/4X3 TBE 304SS SK 80	
all	9	96RH706A01	PARKER SUBPLATE #SPD2320	
all	10	96RH706E71	01Z VALVE PARKER 220-50/240-60 7GPM	
all	11	27E162A19A	03Z HYD CYL. D/A 2" BOREX19"STROKE	
all	12	17A097	CLEVISPIN=1"X2+3/4"DRILLED ZINCPLTD	
all	13	02 18666	67273A HOLD DOWN SPACER (ROUND)	
all	14	03 48174	83407D BRKT=CYL.MT.FRT.(BEND-UP)48T	
all	15	03 48174A	83407# BRKT=CYL.MT.FRT.(BEND-DN)48T	
all	16	17A093	CLEVISPIN=1"X1+3/4"DRILLED ZINCPLTD	
all	17	W2 11554	89207D*WLDMT=BASE-TILT CYL.42+48T	
all	18	03 48176	88221D BRKT=CYL.MT.REAR TOP42,48T	
all	19	02 11531	86212D MTG.BRKT=HYD VALVES 42&48T	
all	20	27E5400A74	09Z HYPWRUNIT3GPM@900P200/480V3P60C	
all	21	27E731500	01Z LIQFILL GAGE 0-1500PSI/BAR BRZ	
all	22	52FY0ER01S	STEM-MALE=3/16IDX1/4M JONES#203-104	
all	23	52FY0ER01F	FERRULE-NONSKIVE=3/16 JONES#503-500	
all	24	52XY0GP00X	3/8"QUICK DISCONN.FEM. PH#H3-62	
all	25	52XY0GP00Y	3/8"QUICK DISCONN.MALE PH#H3-63	
all	26	27E7110	HYD IN-LINE FILTER ARROW #9053	
all	27	52JY0ER003	ELBOWPIPE 1/4 FEM.STL AIR#5504-4	



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.


Parts List, cont.—Hydraulic Assembly

Used In	Item	Part Number	Description	Comments
all	28	60EH15	01Z HYD.HOSE 3/16" SAE100R1 *	
all	29	60EH25C80A	84167N*HYD HOSE 3/8"+ENDS= 80"	
all	30	60EH25C143	84192N*HYD-HOSE 3/8"+ENDS=143"	
all	31	60EH25C21A	84167N*HYD HOSE 3/8"+ENDS= 21"	
all	32	60EH25C55A	84167N*HYD HOSE 3/8"+ENDS= 55"	4226 ONLY
all	32	60EH25C51A	84167N*HYD HOSE 3/8"+ENDS= 51"	4832+4836 ONLY
all	33	60EH25C93A	84167N*HYD HOSE 3/8"+ENDS= 93"	4226 ONLY
all	33	60EH25C113	84167N*HYD HOSE 3/8"+ENDS=113"	4832+4836 ONLY
all	34	60EH25C63A	84167N*HYD HOSE 3/8"+ENDS= 63"	
all	35	60EH25C103	84167N*HYD HOSE 3/8"+ENDS=103"	
all	36	60EH25C93A	84167N*HYD HOSE 3/8"+ENDS= 93"	
all	37	60EH25C43A	84167N*HYD HOSE 3/8"+ENDS= 43"	
all	38	60EH25C63A	84167N*HYD HOSE 3/8"+ENDS= 63"	4226 ONLY
all	38	60EH25C74A	84167N*HYD HOSE 3/8"+ENDS= 74"	4832+4836 ONLY
all	39	52AY0KR006	HEXPIPEBUSH 1/2MX3/8F UNITD#912X8X6	
all	40	96DH40D0KA	09Z BYPASS RESTR.VALVE PRINC AJ-424	



4226QTG, 4832BTG, 4836QTG
HYDRAULIC POWER UNIT SCHEMATIC

BMP84DD24
84196A





4226QTH, 4832BTH, 4836QTH
HYDRAULIC POWER UNIT SCHEMATIC

BMP840009
84193A

