

**30015/30022C4E**  
**GPD305 VARIABLE SPEED CONSTANTS (LOW VOLTAGE)**  
**AND SINGLE PHASE FOR 30015 ONLY**

GPD305 CONSTANT	GPD305 VALUE	GPD305 CONSTANT	GPD305 VALUE
NO01	10 initialize 1 program 0 lockout	N036	2
		N037	6
NO02	1	N038	7
NO03	1	N039	11
NO04	1	N040	0
NO07	1	N046	2
NO09	130	N047	2
NO10	230	N048	10
NO11	60	N063	1.3
NO12	3	N077	0
NO13	12		
NO14	1.5		
NO15	12		
NO16	30		
NO18	120		
NO21	10.9		
NO22	19		
NO23	130		
N024	19		
N033	2		

**Note 1: FOR FACTORY ONLY**

- a) Verify N009 is 114
- b) Verify N77 is 0
- c) Go to N76 and scroll to VFY. Press ENTER and verify that VFY blinks. After this it should say END.
- d) This verifies that the download was correct.