

**30015/3022C4E (LOW VOLTAGE) 3 Phase and Single Phase
V1000 INVERTER**

CONSTANT	VALUE	CONSTANT	VALUE
A1-01	2 Note 3	D1-01	11
A1-02	0	D1-02	133
A1-03	Note 2	D1-05	21
B1-01	0	D1-06	21
B1-02	1	H1-03	7
B1-03	1	H1-04	4
B1-17	1	H1-05	3
C1-01	30	H1-06	5
C1-03	120	H2-01	E
C2-01	1.0	L1-01	0
C4-01	1.3	L2-01	2
C6-01	1	L3-01	0
C6-02	2	L3-04	0
E1-01	230.2	L3-05	0
E1-03	F	L8-05	0
E1-04	133	L8-07	0
E1-05	230.2	H1-01	40
E1-06	60	H1-02	41
E1-07	3		
E1-08	12		
E1-09	1.5		
E1-10	12		
E2-01	Note 1		

Note 1: Enter Ampere rating of inverter

Note 2: 2220 is initialize - otherwise 0

Note 3: Set to 0 after programming

Release Date: June 9, 2010

Revision C