

**30015 & 30022T6X (LOW VOLTAGE) AND SINGLE PHASE  
V1000 INVERTER**

CONSTANT	VALUE	CONSTANT	VALUE
A1-01	2 Note 3	D1-01	8.8
A1-02	2	D1-02	135 Note 4
A1-03	Note 2	D1-03	54
B1-01	0	D1-04	54
B1-02	1	D1-05	15
B1-03	0	D1-06	54
B6-01	.5	D1-07	55
B6-02	.3	D1-08	17
C1-01	60	H1-03	7
C1-02	35	H1-04	4
C1-03	80	H1-05	3
C1-04	40	H1-06	5
C2-01	1.0	H1-07	A
C4-01	1.0	H2-01	E
C6-01	1	H2-02	16
C6-02	2	L1-01	0
E1-01	220	L2-01	2
E1-03	F	L3-01	0
E1-04	135 Note 4	L3-04	0
E1-05	220	L3-05	0
E1-06	60	L8-05	0
E2-01	Note 1	L8-07	0
E2-07	.47	H1-01	40
E2-08	.73	H1-02	41

- Note 1: Enter Ampere rating of inverter  
 Note 2: 2220 is initialize - otherwise 0  
 Note 3: Set to 0 after programming  
 Note 4: If Gear Guardian, set to 114.  
 Nameplate max speed at 485 RPM

Release Date: March 5, 2014      Revision D