

**3022T5E/J/X SINGLE PHASE
GPD315 VARIABLE SPEED CONSTANTS (LOW VOLTAGE)**

CONSTANT	VALUE	CONSTANT	VALUE
NO01	10 initialize 4 program 0 lockout	NO27	19
NO02	0	NO37	2
NO03	1	NO80	2
NO04	1	NO50	1
NO05	1	NO51	2
NO08	1	NO54	8
NO11	143.1	NO52	6
NO12	230.1	NO55	11
NO13	60	NO53	7
NO14	3	NO56	5
NO15	12	NO77	0
NO16	1.5	NO81	2
NO17	12	NO82	10
NO19	30	N103	1.3
NO21	120	NO80	2
NO24	10.5		
NO25	19		
NO26	143		

NOTE; ENTER IN THE ORDER LISTED

Note 1: FOR FACTORY ONLY

- a) Verify NO12 is 230.1
- b) Verify N177 is 0
- c) Go to N176 and scroll to VFY. Press ENTER and verify that VFY blinks. After this it should say END.
- d) This verifies that the download was correct.