

**30022V6J 200G with accelerometer
GPD315 VARIABLE SPEED CONSTANTS (LOW VOLTAGE)**

GPD315 CONSTANT	GPD315 VALUE	GPD315 CONSTANT	GPD315 VALUE
NO01	10 initialize 4 program 0 lockout	NO27	51
		NO28	81
NO02	0	NO29	95
NO03	1	NO30	134
NO04	1	NO31	12.3
NO05	0	NO37	2
NO08	1	NO80	2
NO11	134	NO50	1
NO12	230.1	NO51	2
NO13	60	NO54	8
NO14	3	NO52	6
NO15	13	NO55	11
NO16	1.5	NO53	7
NO17	10	NO57	16
NO19	30	NO56	15
NO20	35	NO58	4
NO21	80	NO77	0
NO22	40	NO81	2
NO24	8.5	NO82	10
NO25	7.5	NO95	110
NO26	12.3	N103	1.3

NOTE: ENTER IN THE ORDER LISTED

Note 1: **FOR FACTORY ONLY**

- a) Verify N012 is 230.1
- b) Verify N177 is 0
- c) Go to N176 and scroll to VFY. Press ENTER and verify that VFY blinks. After this it should say END.
- d) This verifies that the download was correct.