

**3621C4E (HIGH VOLTAGE) 5 HP 6 POLE MOTOR ONLY  
V1000 INVERTER**

CONSTANT	VALUE	CONSTANT	VALUE
A1-01	2 Note 3	D1-01	14.2
A1-02	0	D1-02	175
A1-03	Note 2	D1-05	21.5
B1-01	0	D1-06	21.5
B1-02	1	H1-03	7
B1-03	1	H1-04	4
B1-17	1	H1-05	3
C1-01	41	H1-06	A
C1-02	20	H2-01	E
C1-03	140	L1-01	0
C1-04	80	L2-01	2
C2-01	1.0	L3-01	0
C4-01	.7	L3-04	0
C6-01	1	L3-05	0
C6-02	2	L8-05	0
E1-01	460	L8-07	0
E1-03	F	H1-01	40
E1-04	175	H1-02	41
E1-05	460		
E1-06	60		
E1-07	3		
E1-08	22.4		
E1-09	1.5		
E1-10	15		
E2-01	Note 1		

Note 1: Enter Ampere rating of inverter

Note 2: 2220 is initialize - otherwise 0

Note 3: Set to 0 after programming