

36026X8W, X8R (LOW VOLTAGE) V1000 INVERTER			
CONSTANT	VALUE	CONSTANT	VALUE
A1-00	0	E1-08	12/10.4
A1-01	2	E1-09	1.5
A1-02	0	E1-10	7.5/6.5
A1-03	Note 2	E2-01	Note 1
B1-01	1	H1-01	40
B1-02	1	H1-02	41
B1-03	0	H1-06	7
B1-17	1	H1-07	A
C1-01	35	H2-02	16
C1-02	20	H3-03	104 Note 3
C1-03	255	H3-04	.1 Note 3
C1-04	80	H3-13	.5
C2-01	1.0	L1-01	0
C4-01	1.3	L2-01	2
C6-01	0	L3-01	0
C6-02	2	L3-04	0
E1-01	240/208	L3-05	0
E1-03	F	L3-06	150
E1-04	205	L4-03	167
E1-05	240/208	L4-04	10
E1-06	60	L8-05	0
E1-07	3	L8-07	0

Note 1: Enter Ampere rating of inverter

Note 2: 2220 is initialize - otherwise 0

Note 3: Adjust for final speed – MilTouch only

Motor wiring: Wire motor for 208V for 200-208V
Wire motor for 240V for 220-240V

Release Date: April 29, 2014

Revision I