

**36030F8J (LOW VOLTAGE) – 300G
F7 INVERTER**

CONSTANT	VALUE	CONSTANT	VALUE
A1-00	0	E1-05	240/208 Note 3
A1-01	2	E1-06	60
A1-02	0	E1-07	3
A1-03	Note 2	E1-08	15/13 Note 3
B1-01	0	E1-09	1.5
B1-02	1	E1-10	8/7 Note 3
B1-03	0	E2-01	Note 1
C1-01	35	H1-01	7
C1-02	20	H1-02	4
C1-03	120	H1-03	3
C1-04	80	H1-04	5
C2-01	1.0	H1-05	B
C6-01	0	H2-01	0
C6-02	0	H3-05	1F
D1-01	10	L1-01	0
D1-02	112	L2-01	2
D1-03	11.5	L3-01	2
D1-04	164	L3-02	200%
D1-05	17	L3-03	100%
D1-06	188	L3-04	0
D1-08	17	L3-05	0
E1-01	240/208 Note 3	L3-06	200
E1-03	F	L8-05	0
E1-04	188	L8-07	0

Note 1: Enter Ampere rating of inverter

Note 2: 2220 is initialize - otherwise 0

Note 3: Value is entered for 240 or 208 volts.

Motor Wiring: Wire motor for 208V for 200-208V.

Wire motor for 240V for 220-240V.

Release Date: January 23, 2007

Revision A