

**36030F8S (LOW VOLTAGE) – 300G
F7 INVERTER**

CONSTANT	VALUE	CONSTANT	VALUE
A1-00	0	E1-07	3
A1-01	2	E1-08	13
A1-02	0	E1-09	1.5
A1-03	Note 2	E1-10	8
B1-01	1	E2-01	Note 1
B1-02	1	H1-04	7
B1-03	0	H1-05	B
B2-02	100	H2-01	E
B2-04	.3	H3-05	1F
C1-01	35	H3-12	.5
C1-02	20	L1-01	0
C1-03	120	L2-01	2
C1-04	145	L3-01	0
C2-01	1.0	L3-02	200%
C6-01	0	L3-03	100%
C6-02	0	L3-04	0
E1-01	230	L3-05	0
E1-03	F	L3-06	200
E1-04	186	L8-05	0
E1-05	230	L8-07	0
E1-06	60		

Note 1: Enter Ampere rating of inverter

Note 2: 2220 is initialize - otherwise 0