



	CW		CCW	
	CRWCM	CRWAM	CRCLM	CRDEM
WASH 1	X			
WASH 2	X		X	
DRAIN	X			X
RINS SAVE	X		X	X
EXTRACT 1	X			X
EXTRACT 2	X		X	X
EXTRACT 3	X			X
OUT OF EXTRACT				X

- NOTES:
1. TBV IS LOCATED ON VARIABLE SPEED CONTROLLER CONTROLLER.
  2. Kxx REFERS TO THE LABEL ON THE BOARD MOUNTED RELAY. OUTPUT# REFERS TO WHAT IS SHOWN ON THE MACHINE'S DISPLAY.

# W7V6JVPA

MICRO 7 SYSTEMS MARK V  
 FOR 36 AND 42 V#J ONLY  
 FOR GPD315/505/506/V1000/A1000 INVERTER  
 SCHEMATIC: VARIABLE SPEED CONTROLLER  
 PELLERIN MILNOR CORPORATION