

**42026V6Z MILTOUCH (LOW VOLTAGE) 300G with Accelerometer  
V1000 INVERTER**

CONSTANT	VALUE	CONSTANT	VALUE
A1-01	2 Note 3	E1-10	8
A1-02	0	E2-01	Note 1
A1-03	Note 2	H1-01	40
B1-01	1	H1-02	41
B1-02	1	H1-03	7
B1-03	0	H1-04	4
B1-17	1	H1-05	3
C1-01	35	H1-06	5
C1-02	20	H1-07	A
C1-03	120	H2-01	E
C1-04	80	H2-02	16
C2-01	1.0	H3-03	102.5 (Note 4)
C4-01	1	H3-04	-1.0 (Note 4)
C6-01	1	L1-01	0
C6-02	2	L2-01	2
E1-01	230	L3-01	0
E1-03	F	L3-04	0
E1-04	183	L3-05	0
E1-05	230	L4-03	125
E1-06	60	L4-04	10
E1-07	3	L8-05	0
E1-08	11.5	L8-07	0
E1-09	1.5		

- Note 1: Enter Ampere rating of inverter
- Note 2: 2220 is initialize - otherwise 0
- Note 3: Set to 0 after programming
- Note 4: Modify to set speeds when D/A is used

Release Date: April 4, 2013

Revision A