

M7V4836C EXTRACTOR (LOW VOLTAGE) 380G

F7 INVERTER

CONSTANT	VALUE	CONSTANT	VALUE
A1-00	0	E1-08	15
A1-01	2	E1-09	1.5
A1-02	0	E1-10	10
A1-03	2220	E2-01	NOTE 1
B1-01	0	H1-01	3
B1-02	1	H1-02	4
B1-03	0	H1-03	5
C1-01	60	H1-04	22
C1-02	30	H1-05	A
C1-04	30	H1-06	F
C6-01	0	H2-01	E
C6-02	1	H2-02	16
D1-01	6	H3-05	1F
D1-02	10.3	L1-01	0
D1-03	10.6	L2-01	2
D1-04	92	L3-01	1
D1-05	119	L3-02	120
D1-06	133	L3-03	100
D1-17	4	L3-04	0
E1-01	240	L3-05	0
E1-03	F	L3-06	200
E1-04	133	L4-03	106
E1-05	240	L4-04	10
E1-06	60	L8-05	0
E1-07	3	L8-07	0

NOTE 1: Enter Ampere rating of inverter