

MXV4232 EXTRACTOR (HIGH VOLTAGE)			
F7 INVERTER			
CONSTANT	VALUE	CONSTANT	VALUE
A1-00	0	E1-09	1.5
A1-01	2	E1-10	20/17
A1-02	0	E2-01	NOTE 1
A1-03	2220	H1-01	3
B1-01	0	H1-02	4
B1-02	1	H1-03	5
B1-03	0	H1-04	22
C1-01	60	H1-05	A
C1-02	15	H1-06	F
C1-04	15	H2-01	E
C6-01	0	H2-02	16
C6-02	1	H3-05	1F
D1-01	3.3	L1-01	0
D1-02	6.2	L2-01	2
D1-03	19	L3-01	0
D1-04	38	L3-02	200
D1-05	76	L3-03	100
D1-06	105	L3-04	0
E1-01	460/400	L3-05	0
E1-03	F	L3-06	200
E1-04	105	L4-03	80
E1-05	460/400	L4-04	10
E1-06	60	L8-05	0
E1-07	3	L8-07	0
E1-08	30/25		

NOTE 1: Enter Ampere rating of inverter

Release Date: September 13, 2011

Revision: B