

**42026V6J**

**GPD506 (LOW VOLTAGE)**

G5 CONSTANT	G5 VALUE	G5 CONSTANT	G5 VALUE
NO01	Note 1	NO27	133
NO02	SEQ=TRM REF=OPR	NO28	16
NO03	230.2	NO29	155
NO04	Ramp to Stop	NO34	Disabled
NO10	User Defined V/F pattern	NO36	Reverse run, (2W)
NO11	155	NO37	ACC/DEC Switch
NO12	230.2	NO38	Multi-step SPD 2
NO13	060.0	NO39	Multi-step SPD 1
NO14	003.0	NO40	Multi-step SPD 3
NO15	11.2	N116	CT
NO16	001.5	NO54	5.0 kilohertz
NO17	7.5	NO55	2 seconds MAX
NO18	0035.0	NO59	2
NO19	20	NO60	10
NO20	120	NO71	.7
NO21	0080.0	NO72	Disabled
NO24	10.3	NO73	200
NO25	110	NO74	200
NO26	8.5	NO83	50

**YOU MUST PROGRAM IN THIS ORDER**

Note 1: Put in 8 to initialize to 2 wire control

Put in 3 to program

Put in 0 to lockout

Note 2: Software version can be viewed under monitor function constant U-10 or on control board.

Release Date: December 6, 2000

Revision D